Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MCHOSE L7 ULTRA

MCHOSE L7 ULTRA Wireless Gaming Mouse User Manual

Model: L7 ULTRA (MC-L7-8)

1. Introduction

Thank you for choosing the MCHOSE L7 ULTRA Wireless Gaming Mouse. This ultralight gaming mouse is engineered for competitive performance, offering precision, speed, and comfort. This manual provides detailed instructions on how to set up, operate, and maintain your device to ensure optimal performance.



Figure 1: MCHOSE L7 ULTRA Wireless Gaming Mouse (Black)

2. Package Contents

Please check the package for the following items:

- MCHOSE L7 ULTRA Wireless Gaming Mouse
- 8K Wireless Receiver (Dongle)
- USB-C Charging/Data Cable
- User Manual (this document)

3. Product Features

- **Ultralight Design:** Weighing approximately 39g, designed for swift movements and reduced fatigue.
- **High-Performance Sensor:** Equipped with the industry-leading PAW3395 optical sensor for unparalleled precision and tracking.

- **Customizable DPI:** DPI settings are customizable up to 26,000, allowing for fine-tuned sensitivity.
- **TOPSPEED Wireless Technology:** Achieves ultra-low latency (0.125ms) for a competitive edge in gaming.
- **8K Polling Rate:** Supports up to 8000Hz polling rate in both wired and wireless modes for extremely responsive input.
- **Ergonomic Design:** Features a high hump and small waist angle to fit various hand shapes and grip styles, optimizing weight balance for comfort and control.
- **Durable Switches:** Utilizes high-quality Omron switches with a lifespan of up to 70 million clicks, providing crisp tactile feedback.
- **Precise Scroll Wheel:** Features a TTC Gold Wheel Encoder for smooth, precise, and responsive scrolling.

4. Setup Guide

4.1 Charging the Mouse

Before first use, it is recommended to fully charge the mouse. Connect the USB-C end of the charging cable to the mouse and the USB-A end to a powered USB port on your computer or a USB wall adapter. The LED indicator on the mouse will show charging status (specific LED behavior may vary; refer to software for battery level).

4.2 Connecting the Wireless Receiver

1. Plug the 8K wireless receiver (dongle) into an available USB port on your computer. For optimal performance, use a USB 2.0 or 3.0 port and place the receiver as close to the mouse as possible, ideally using the included USB-C cable and adapter (if provided) to extend the receiver closer to your mousepad.
2. Turn on the mouse using the power switch located on the bottom of the mouse.



Figure 2: Bottom view of MCHOSE L7 ULTRA showing power switch and sensor.

4.3 Software Installation (MCHOSE HUB)

To unlock the full potential of your MCHOSE L7 ULTRA, download and install the MCHOSE HUB software from the official MCHOSE website. This software allows for DPI customization, button remapping, macro creation, polling rate adjustment, and firmware updates.

5. Operating Instructions

5.1 Power On/Off

Use the switch on the bottom of the mouse to power it on or off. Some models may have a 2.4G/OFF/Bluetooth switch. Select

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F3YN6KB9

More documents and user manuals: **https://manuals.plus/**