

[Manuals.plus](#) /

› [Groovz](#) /

› Groovz True Wireless Earbuds with Charging Case - Paisley - User Manual

Groovz 810186690083

Groovz True Wireless Earbuds with Charging Case - Paisley

Model: 810186690083

INTRODUCTION

Thank you for choosing Groovz True Wireless Earbuds. These earbuds are designed to provide a seamless audio experience with advanced features and a comfortable fit. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Groovz True Wireless Earbuds in Paisley design, showcasing the earbuds and their matching charging case.

WHAT'S IN THE BOX

- Groovz True Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- Ear Tips (Small, Medium, Large)
- User Manual

SETUP

1. Initial Charge

Before first use, fully charge your earbuds and charging case. Place the earbuds into the charging case and connect the USB-C cable to a power source. The LED display on the case will indicate the charging status.

Crystal-Clear Sound

13mm speaker produce
powerful bass and stunning




The charging case features an LED display to show the current battery percentage of the case and earbuds.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings.
3. Select "Groovz Earbuds" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

These earbuds utilize Bluetooth 5.3 technology for fast and stable connections with a range of up to 32 feet. They are compatible with both Apple and Android devices.



Bluetooth 5.3 Connectivity

Stay Connected, Always

Experience fast, seamless pairing with the latest Bluetooth 5.3 technology for smooth, uninterrupted listening. No more delays or drop-offs, no matter the device.

Experience fast, seamless pairing with the latest Bluetooth 5.3 technology for smooth, uninterrupted listening.

3. Choosing the Right Ear Tips


For optimal sound quality and comfort, select the ear tips that best fit your ears. The earbuds come with small, medium, and large ear tip sizes. A snug fit enhances bass and noise isolation.

OPERATING INSTRUCTIONS

Touch Controls

Your Groovz earbuds feature smart touch controls for easy management of your audio and calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either earbud.



Total Control, Effortless Freedom

Unleash Your Music, Cord-Free

Experience crystal-clear sound and wireless freedom. Enjoy bold looks, effortless control, and manage music and calls seamlessly with **Smart Touch Controls** wherever you go.

Manage music and calls seamlessly with Smart Touch Controls.

Audio Quality

Experience high-definition audio with balanced clarity and powerful bass, ensuring every note and beat resonates as intended. The earbuds feature dynamic drivers for an immersive listening experience.


IPX4 WATER RESISTANT



The 13mm speaker produces powerful bass and stunning crystal-clear sound.

Crystal Clear Calls

Communicate seamlessly with dual microphones featuring advanced noise reduction technology. This ensures every word is heard clearly, even in busy environments, providing clear sound on both ends of the call.



Dual microphones with advanced noise reduction technology ensure crystal-clear calls, even in noisy environments.

CHARGING

The Groovz True Wireless Earbuds and their charging case offer extended battery life for prolonged listening.

- **Earbud Playtime:** Up to 5 hours on a single charge.
- **Total Playtime with Charging Case:** Up to 27 hours (22 hours from the charging case).
- **Charging Port:** USB-C for quick and convenient charging.

The charging case features an LED battery display that shows the exact battery percentage in real-time, so you are always aware of your charge level.



Digital Power Display

Digital display to show the power of the charging case

Enjoy up to 5 hours of playtime on a single charge, with an additional 22 hours provided by the charging case, totaling 27 hours.



Charge Less, Play More

All-Day Battery Life

Stay powered without interruptions for all-day listening.

	5 Hours Single Charge		26 Hours With Charging Case
	Type-C Fast Charging		LED Intelligent Battery Display

Stay powered without interruptions for all-day listening with fast Type-C charging and an LED intelligent battery display.

MAINTENANCE

Water Resistance

Your Groovz earbuds are IPx4 water resistant, meaning they are protected against splashing water from any direction. This makes them suitable for workouts and outdoor activities where they might be exposed to sweat or light rain. However, they are not designed for submersion in water.

AI-ENHANCED CALLS

Via 2 Mics



The earbuds are IPx4 water resistant, offering protection against splashes and sweat.

Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth to wipe the surfaces. For ear tips, you can gently remove them and clean with a mild soap solution, then rinse and dry thoroughly before reattaching.

TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid to activate pairing mode. Check your device's Bluetooth settings and try reconnecting.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often resets the connection.
- **No sound:** Check the volume level on your device and ensure the earbuds are properly connected via Bluetooth.
- **Charging issues:** Ensure the USB-C cable is securely connected to both the case and the power source. Check the LED display for charging indicators.
- **Poor call quality:** Ensure the microphones are not obstructed. Move to an area with less background noise if possible.

SPECIFICATIONS

Model Name	810186690083
Connectivity Technology	Wireless (Bluetooth 5.3)
Water Resistance Level	IPx4 Water Resistant
Battery Life (Earbuds)	Up to 5 hours
Battery Life (with Case)	Up to 27 hours
Charging Port	USB-C
Control Method	Touch
Special Features	Noise Cancellation, Touch Control, LED Battery Display
Ear Placement	In Ear
Compatible Devices	Smartphones, Laptops, Tablets, Televisions (Apple and Android compatible)

WARRANTY AND SUPPORT

Groovz True Wireless Earbuds come with a **1-year warranty** from the date of purchase. For warranty claims, technical support, or any inquiries, please contact Groovz customer service through the retailer where the product was purchased or visit the official Groovz website.

OFFICIAL PRODUCT VIDEOS

Your browser does not support the video tag.

This video provides an overview of the Groovz True Wireless Earbuds, demonstrating their design and key features.

Your browser does not support the video tag.

This video highlights the features of the Groovz True Wireless Earbuds with Charging Case, including battery life and connectivity.