

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Uineer](#) /
- › [Uineer Vertical Wireless Mouse User Manual](#)

Uineer A06P

Uineer Vertical Wireless Mouse User Manual

Model: A06P

Your guide to comfortable and efficient computing.

PRODUCT OVERVIEW

The Uineer Vertical Wireless Mouse (Model A06P) is designed for comfort and reduced wrist strain, promoting a more natural hand posture. It features 2.4G wireless technology, adjustable DPI settings, and a convenient battery indicator for seamless use in various environments.



Figure 1: Uineer Vertical Wireless Mouse (White) with its USB receiver.

WHAT'S IN THE BOX

- 1 x Wireless Vertical mouse
- 1 x USB-A receiver (stored at the bottom of the mouse)
- 1 x 50CM Type-C charging cable
- 1 x User Manual

SETUP GUIDE

Follow these steps to set up your Uineer Vertical Wireless Mouse:

1. **Locate the USB-A Receiver:** The USB-A receiver is conveniently stored in a compartment at the bottom of the mouse. Gently slide open the cover to retrieve it.



Figure 2: Bottom of the mouse, highlighting the USB receiver compartment and power switch.

2. **Connect the Receiver:** Insert the USB-A receiver into an available USB-A port on your computer or device.
3. **Power On the Mouse:** Locate the ON/OFF switch on the bottom of the mouse and slide it to the "ON" position.
4. **Automatic Connection:** The mouse will automatically connect to your device. No additional drivers are required for instant use.

Your browser does not support the video tag.

Video 1: Demonstrates the setup process, including inserting the USB receiver and turning on the mouse.

OPERATING INSTRUCTIONS

Ergonomic Design

The Uineer Vertical Mouse is designed to provide an ergonomic solution with a comfortable grip, reducing wrist strain and promoting better posture during long periods of use. Its dimensions are L x W x H 11.6 x 7.2 x 7.5 cm (4.57 x 3.03 x 2.95 inches).

Ergonomic Vertical Design

for Comfort and Reduced Wrist Strain



Figure 3: Illustration of the ergonomic vertical design, showing how it reduces wrist strain compared to a traditional mouse.

DPI Adjustment

The mouse supports four adjustable DPI settings: 800, 1200, 1600, and 2400. You can easily switch between these settings by pressing the DPI button located on the top of the mouse, allowing you to customize sensitivity for various tasks from document editing to graphic design or gaming.

4 Levels DPI

Easily adjust the DPI to meet your different needs

800-1200-1600-2400



Figure 4: The DPI button and its four adjustable levels (800, 1200, 1600, 2400).

Button Functions

The mouse features several buttons for enhanced functionality:

- **Left Click:** Standard left mouse button.
- **Right Click:** Standard right mouse button.
- **Scroll Wheel:** For vertical scrolling.
- **DPI Button:** Adjusts mouse sensitivity (800/1200/1600/2400 DPI).
- **Forward Button:** Navigates forward in web browsers or file explorers. *(Note: Forward/Backward buttons are not compatible with Mac OS.)*
- **Backward Button:** Navigates backward in web browsers or file explorers. *(Note: Forward/Backward buttons are not compatible with Mac OS.)*



Figure 5: Detailed diagram of the mouse buttons and their functions.

Battery Indicator

The mouse includes a clear battery indicator light, allowing you to monitor the power level and avoid unexpected power loss during use.

Visual battery display

Continuous power supply ensures lag-free operation



Figure 6: Visual representation of the battery indicator on the mouse.

MAINTENANCE

Charging the Mouse

The Uineer Vertical Wireless Mouse is rechargeable. When the battery is low, connect the included 50CM Type-C charging cable to the Type-C charging port on the mouse and a USB power source (e.g., computer USB port, USB wall adapter). A full charge typically takes 2-3 hours.




Figure 7: Charging port location and charging process illustration.

Cleaning

To clean your mouse, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the internal components. Avoid using harsh chemicals or abrasive materials.

TROUBLESHOOTING

- **Mouse not responding:**
 - Ensure the USB-A receiver is securely plugged into a working USB port.
 - Check if the mouse is powered on (ON/OFF switch on the bottom).
 - Recharge the mouse if the battery indicator shows low power.
 - Try plugging the receiver into a different USB port.
- **Lag or intermittent connection:**
 - Ensure the mouse is within the 10-meter transmission range of the receiver.
 - Minimize interference from other wireless devices.
- **Forward/Backward buttons not working on Mac OS:**
 - Please note that the Forward/Backward buttons are not compatible with Mac OS. This is a system limitation.
- **DPI adjustment not changing sensitivity:**
 - Ensure you are pressing the correct DPI button.
 - Try restarting the mouse by turning it off and on again.

SPECIFICATIONS

Feature	Detail
Model Number	A06P
Connectivity Technology	2.4G Wireless (USB-A)
DPI Levels	800, 1200, 1600, 2400
Movement Detection Technology	Optical

Product Dimensions	11.6 x 7.2 x 7.5 cm (4.57 x 3.03 x 2.95 inches)
Item Weight	3.7 ounces
Battery	Rechargeable (internal battery)
Compatibility	Windows 11/10/8/7/XP/Vista, Mac OS X/Linux/Android/iOS(13+) (devices with USB-A ports)

WARRANTY AND SUPPORT

Uineer offers a **45-day no-reason refund policy** and a **12-month replacement service** for quality issues. This ensures a worry-free shopping experience.

For further assistance or support, please contact Uineer customer service through the platform where you purchased the product or refer to the contact information provided in your product packaging.