



Manuals.plus /

- › Aeitto /
- › Aeitto Cold Press Juicer Model 041 Instruction Manual

Aeitto 041

Aeitto Cold Press Juicer Model 041 Instruction Manual

Your Smart Companion for Healthy Juicing

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Aeitto Cold Press Juicer Model 041. This manual provides essential information for safe and efficient operation of your new appliance. Designed for optimal nutrient retention, this slow masticating juicer features a 5.3-inch extra-large feed chute, a powerful 250W motor, and a 7-stage upgraded auger to ensure high juice yield and minimal oxidation. Enjoy healthier, richer-tasting juice with ease.

Oversized Feed Chute

Reduce 50% Preparation Time




Image: The Aeito Cold Press Juicer in grey, showcasing its sleek design and large feed chute for whole fruits and vegetables.

2. PRODUCT COMPONENTS

Familiarize yourself with the components of your Aeito juicer:

- **Hopper Cover:** Secures the feed chute.
- **Hopper:** The main chamber where fruits and vegetables are fed. Features a 5.3-inch extra-large opening.
- **Auger:** The 7-stage masticating screw that crushes and presses produce.
- **Screen:** Filters pulp from juice.
- **Chamber:** Collects juice and separates pulp.
- **Juice Outlet with Flap:** Dispenses juice into the juice container.
- **Pulp Outlet:** Discharges dry pulp into the pulp container.
- **Housing/Motor Base:** Contains the 250W motor and control buttons.
- **Juice Container:** Collects extracted juice.
- **Pulp Container:** Collects discarded pulp.
- **Cleaning Brush:** For easy cleaning of components.

- **Power Cord:** Connects the juicer to an electrical outlet.

Faster Cleaning

Save 50% Washing Time



Image: An exploded view of the Aeito juicer, showing all its detachable parts for assembly and cleaning.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your juicer before first use:

1. Place the Chamber onto the top of the Housing/Motor Base. Ensure the silicone valve of the Chamber is closed before assembly to prevent juice leakage.
2. Insert the Auger firmly into the center of the Chamber.
3. Align the Hopper assembly guide mark with the Chamber assembly guide mark and press the lever to lock it into place.
4. Turn the Hopper clockwise up to the Chamber assembly guide mark to assemble them.
5. Close the Hopper Cover securely. The juicer will not operate if the Hopper Cover is not installed correctly.

Image: A visual assembly guide showing five steps to correctly set up the Aeito juicer components.

4. OPERATING INSTRUCTIONS

Using your Aeito Cold Press Juicer is simple and efficient:

1. Ensure the juicer is correctly assembled and the Hopper Cover is securely closed.
2. Place the juice container under the juice outlet and the pulp container under the pulp outlet.
3. Wash fruits and vegetables thoroughly. For best results, remove any hard seeds or pits.
4. With the 5.3-inch large feed chute, many whole fruits and vegetables can be inserted directly, reducing prep time. For larger items, cut them into appropriate sizes to fit.
5. Plug in the power cord and switch the juicer to the 'ON' position.
6. Slowly feed the produce into the hopper. The 7-stage auger will masticate the ingredients, extracting juice and separating pulp.
7. Allow the juicer to process all ingredients completely before adding more.
8. Once juicing is complete, switch the juicer to 'OFF'. If clogging occurs, use the 'R' (Reverse) function briefly to clear the blockage.



Image: The Aeito juicer's large 5.3-inch feed chute, capable of accommodating whole fruits and vegetables like apples, grapes, and carrots, significantly reducing preparation time.

High Juice Yield

Provide You with Purer Juice

99%

Juice Up to



Image: The Aeito juicer producing a high yield of pure green juice, with dry pulp collected in a separate container, illustrating efficient extraction.

7-stage Upgraded Auger

Max Juice Extraction



Aeito	Others
 <ul style="list-style-type: none">✓ Higher Juice Yield✓ Less Oxidation✓ More Nutrition	 <ul style="list-style-type: none">✗ Lower Juice Yield✗ More Oxidation✗ Less Nutrition

Image: A diagram illustrating the 7-stage upgraded auger of the Aeito juicer, detailing how it cuts, grinds, squeezes, and extracts juice for maximum yield and nutrition compared to traditional methods.

Operational Videos:

Your browser does not support the video tag.

Video: A short clip demonstrating the Aeito juicer in action, extracting juice from various fruits and vegetables, highlighting its efficiency and ease of use.

Your browser does not support the video tag.

Video: A user's perspective on the Aeito juicer, showing the juicing process and expressing satisfaction with the product's performance.

Your browser does not support the video tag.

Video: A brief demonstration of the juicer's operation, including a moment where it appears to struggle with certain produce, providing insight into potential challenges.

5. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygiene of your juicer:

1. Always unplug the juicer from the power outlet before cleaning.

2. Disassemble all removable parts: Hopper Cover, Hopper, Auger, Screen, Chamber, Juice Container, and Pulp Container.
3. Rinse all detachable parts under running water. Use the included cleaning brush to remove any pulp residue from the screen and other components.
4. All parts of the juicer, except the motor base, can be washed with water. **Note: The juicer is NOT dishwasher safe.**
5. Wipe the Housing/Motor Base with a damp cloth. Do not immerse the motor base in water or any other liquid.
6. Allow all parts to dry completely before reassembling or storing.

Faster Cleaning

Save 50% Washing Time



Image: A person cleaning the detachable parts of the Aeiito juicer under a faucet, emphasizing the ease of cleaning with fewer components.

6. TROUBLESHOOTING

If you encounter any issues with your juicer, please refer to the following common solutions:

- **Juicer does not turn on:** Ensure the power cord is securely plugged into a working outlet. Verify that the Hopper Cover is correctly and securely installed, as the juicer has a safety interlock mechanism.
- **Juicer stops during operation or clogs:** Switch the juicer to 'OFF', then to 'R' (Reverse) for a

few seconds to clear any blockage. If the issue persists, disassemble and clean the auger and screen for any lodged food.

- **Excessive pulp in juice:** Ensure the screen is clean and free from damage. Reassemble all parts correctly.
- **Leakage:** Check that all components, especially the Chamber and Hopper, are correctly assembled and locked into place. Ensure the silicone valve is closed.

For further assistance, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Aeitto
Model Name	041
Color	Grey
Special Feature	High Power, No Clogging, Fits Whole Fruits and Vegetables, High Juice Yield, Easy to Clean
Product Dimensions	13"D x 12"W x 8"H
Capacity	1.7 Liters
Voltage	120 Volts
Is Dishwasher Safe	No
Item Weight	9.75 pounds

8. WARRANTY AND SUPPORT

Aeitto is committed to providing high-quality products and excellent customer service.

- **Warranty:** We provide 12 months of repair & replacement services. Register your product for an additional 12 months of manufacturer's warranty.
- **Return Policy:** 30-day return period.
- **Technical Support:** Lifetime technical support is available.
- **Online Consultation:** 7*24 hours online consultation services.

For any product issues or inquiries, please reach out to us:

Email: support@aeitto.com

Website: www.aeitto.com

Warranty Registration: Visit www.aeitto.com/vipwarranty or scan the QR code on the product.



Image: Aeitto customer support details, including warranty information, contact methods, and a QR code for warranty registration.

9. SAFETY INFORMATION

Please read all safety precautions before using your Aeitto Cold Press Juicer:

- Always ensure the Hopper Cover is securely closed before operation. The juicer will not function if it is not properly assembled.
- Do not put your fingers or any other objects into the juicer while it is in operation. Use the food pusher only.
- Unplug the appliance from the power supply when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep hands and utensils away from moving blades or discs while processing food to reduce the risk of severe injury to persons or damage to the food processor.
- This appliance is not intended for use by children. Close supervision is necessary when any appliance is used by or near children.
- Do not use outdoors.