

[Manuals.plus](#) /

> [eufy security](#) /

> eufy Security eufyCam E40 2-Cam Kit (HomeBase 2) Instruction Manual

eufy security eufyCam E40 T8144

eufy Security eufyCam E40 2-Cam Kit (HomeBase 2) Instruction Manual

Model: eufyCam E40 (T8144) | Brand: eufy security

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your eufy Security eufyCam E40 2-Cam Kit with HomeBase 2. This wireless solar-powered security camera system offers 2K QHD resolution, MaxColor Night Vision, and local storage capabilities without monthly fees. Please read this manual thoroughly before using the product to ensure proper functionality and safety.



Image: The eufyCam E40 2-Cam Kit, featuring two white cameras with integrated solar panels and a white HomeBase 2 unit.

2. PACKAGE CONTENTS

Verify that all components are present in your package:

- eufyCam E40 Camera (2 units)
- HomeBase 2 (1 unit)
- Mounting Screws and Wall Anchors
- Mounting Bracket

- USB Charging Cable
- Power Adapter for HomeBase 2
- Ethernet Cable
- Quick Start Guide

Total säkerhet, inga månadsavgifter¹



Ingen prenumerationsavgift¹



Inga avgifter för smarta funktioner



Inget batteribyte krävs³

Spara upp till

3000 kr

under 3 år²



¹ Fullständig produktfunktionalitet ingår utan månadsavgift. Valfria eller premiumfunktioner kan kräva en prenumeration..

² Uppskattad kostnadsbesparing baserad på en jämförelse av prenumerationsavgifter för andra molnbaserade kamerasystem på marknaden.

³ eufyCam C37 har ett uppladdningsbart batteri. Inget byte krävs.

Image: A visual representation of the eufyCam E40 2-Cam Kit, showing the two cameras and the HomeBase 2 unit.

3. SETUP

3.1 Charging the Camera

Before initial use, fully charge the eufyCam E40 cameras using the provided USB charging cable and a standard USB power adapter. The camera features an integrated solar panel for continuous charging, but an initial full charge is recommended for optimal performance.

3.2 Installing the HomeBase 2

1. Connect the HomeBase 2 to your router using the supplied Ethernet cable.
2. Plug the power adapter into the HomeBase 2 and then into a power outlet.
3. Wait for the LED indicator on the HomeBase 2 to turn solid blue, indicating it is ready for setup.

Förbättra Din Upplevelse med HomeBase 2

16^{GB}

16 GB Inbyggd
Lagring



Image: The eufy HomeBase 2 unit, a white rectangular device with a blue LED indicator, shown with its 16 GB built-in storage capacity.

3.3 Mounting the Camera

Select a mounting location that provides a clear view of the area you wish to monitor and receives adequate sunlight for the solar panel. The camera is designed for outdoor use and is IP66 weatherproof.

1. Drill pilot holes at the desired mounting location.
2. Insert the wall anchors if mounting on masonry or drywall.

3. Secure the mounting bracket to the wall using the provided screws.
4. Attach the eufyCam E40 camera to the mounting bracket and adjust the angle for optimal coverage.

Drivs av Solen

SolarPlus 2.0-teknologi säkerställer oavbruten säkerhet med effektiv laddning. Använd det inbyggda solcellspanelen eller lägg till ett externt panel för att utöka energitäckningen. Njut av flexibel montering och tillförlitlig reservström för kontinuerlig energi.

13 000 mAh

Inbyggt
Uppladdningsbart Batteri

2 Timmars

Dagligt Soljus Håller Den
Laddad*

*Vid optimala ljusförhållanden kan den inbyggda solpanelen samla in och lagra 450 till 600 mAh per dag. Kameran förbrukar 150 till 200 mAh under en hel dags normal användning.



Image: Various views of the eufyCam E40 being mounted on an exterior wall, demonstrating the installation process.

3.4 Connecting to the eufy Security App

1. Download the eufy Security app from the App Store (iOS) or Google Play (Android).
2. Create an account or log in.
3. Tap the "+" icon to add a new device and select "eufyCam E40".
4. Follow the on-screen instructions to pair your cameras with the HomeBase 2.

4. OPERATING INSTRUCTIONS

4.1 Live View and Recording

Access the eufy Security app to view live footage from your cameras. Recordings are triggered by motion detection and stored locally on the HomeBase 2.

Se Natten i Full Färg med MaxColor Vision™

Dagsliknande nattsyn –
även i mycket svagt ljus.




 **MAX
COLOR
VISION**

Image: A smartphone screen displaying the eufy Security app's live view, showing a car parked in a driveway at night with clear visibility.

4.2 Motion Detection Settings

The eufyCam E40 features an advanced Passive Infrared (PIR) sensor for reliable motion detection. Customize detection sensitivity and activity zones within the app to minimize false alerts.

Anpassade Skyddszoner

Ställ in upp till två aktivitetszoner för att täcka de mest viktiga områdena och ta emot aviseringar* endast när något detekteras där.

*Push-meddelanden med förhandsvisningar av miniatyrer kräver att miniatyrbilder tillfälligt lagras i molnet.




Image: A screenshot from the eufy Security app demonstrating how to set custom activity zones to focus motion detection on specific areas.

4.3 Night Vision Modes

The eufyCam E40 utilizes MaxColor Vision for full-color night vision, providing clear, daylight-like views even in low-light conditions. The camera also offers infrared night vision for discreet monitoring.

Ljusstarkare och Klarare Nätter

Få kristallklara nattbilder med ett f/1.0-objektiv som fångar 200 %* mer ljus än ett f/2.0-objektiv. En AI-driven bildsignalprocessor (ISP) minskar brus med 15 % för skarpere och ljusare detaljer.

*Data baserad på interna tester. Faktiska resultat kan variera.



f/2.0 (Ingen AI-driven ISP)



f/1.0 (Med AI-driven ISP)

Image: A comparison showing the superior clarity and color of eufyCam E40's MaxColor Night Vision compared to standard night vision in low light.

4.4 Smart Home Integration

The eufyCam E40 system can be integrated with popular smart home platforms such as Apple HomeKit, Amazon Alexa, and Google Assistant for convenient voice control and automation.

4.5 Local Storage Management

The HomeBase 2 provides local storage for your recordings. You can expand the storage capacity up to 256 GB by inserting a USB flash drive (not included) into the HomeBase 2.

Hantera Dina eufy-Enheter

Hantera och kontrollera enkelt mer än 29 eufy-enheter samtidigt med HomeBase 2.



Image: An array of eufy security devices, including cameras and sensors, demonstrating compatibility and management through the HomeBase 2.

5. MAINTENANCE

5.1 Cleaning the Camera

Periodically clean the camera lens and solar panel with a soft, damp cloth to ensure optimal image quality and charging efficiency. Avoid using harsh chemicals or abrasive materials.

IP66 Vädertålig

Byggd för att tåla regn, damm och tuffa väderförhållanden.



Image: The eufyCam E40 camera mounted outdoors, with raindrops visible, highlighting its IP66 weatherproof design.

5.2 Solar Panel Efficiency

The integrated SolarPlus 2.0 technology ensures efficient charging. For best results, ensure the solar panel receives at least 2 hours of direct sunlight daily. If the camera is installed in a shaded area, consider adding an external solar panel for extended power coverage.

Solenergidriven, Bekymmersfri Säkerhet

Håll din familj och egendom trygg med
SolarPlus™ 2.0.

2 Timmars Soljus Dagligen
Håller den Laddad*

*Vid optimala ljusförhållanden kan den inbyggda solpanelen samla in och lagra 450 till 600 mAh per dag. Kameran förbrukar 150 till 200 mAh under en hel dags normal användning.



Lägg till ett externt solpanel för
att utöka energitäckningen.



Image: The eufyCam E40 camera shown with its integrated solar panel, illustrating how it charges from sunlight. Another image shows an optional external solar panel for enhanced charging.

5.3 Firmware Updates

Regularly check for and install firmware updates via the eufy Security app to ensure your system has the latest features, security enhancements, and bug fixes.

6. TROUBLESHOOTING

- **Camera not connecting to HomeBase:** Ensure HomeBase 2 is powered on and connected to the internet (solid blue LED). Try moving the camera closer to the HomeBase during pairing.
- **Poor video quality:** Check for obstructions on the camera lens. Ensure the camera is within Wi-Fi range of the HomeBase.
- **Battery not charging:** Verify the solar panel is clean and receiving sufficient direct sunlight. If in a shaded area, consider an external solar panel or manual charging.
- **False motion alerts:** Adjust motion detection sensitivity and configure activity zones in the eufy Security app to focus on relevant areas.
- **No local storage:** Ensure a compatible USB flash drive is correctly inserted into the HomeBase 2 if expanding storage. Check app settings for storage management.

7. SPECIFICATIONS

Model Name	eufyCam E40
Model Number	T8144
Recommended Use	Outdoor Security
Connectivity Technology	Wireless (Wi-Fi)
Special Feature	Local Recording
Compatible Devices	HomeBase 2
Power Source	Solar Powered
Mounting Type	Wall Mount
Color	White
Water Resistance Level	Waterproof (IP66)
Battery Power	44.3 Watt-hours
Video Recording Resolution	2K
Night Vision	Color Night Vision
Item Dimensions (LxWxH)	13.3 x 6.8 x 6.7 cm
GTIN / UPC	194644277482

2K QHD, Se Varje Detalj

4 Miljoner
Pixlar

f/1.0
objektiv

AI-driven
ISP



Image: An exploded view of the eufyCam E40 lens assembly, highlighting its 2K QHD resolution and f/1.0 aperture for detailed imaging.

8. WARRANTY AND SUPPORT

eufy security products typically come with a limited warranty. Please refer to the warranty card included in your package or visit the official eufy security website for detailed warranty information and terms. For technical support, troubleshooting assistance, or to access FAQs, please visit the eufy security support page or contact their customer service directly. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F42VDN2M>

More documents and user manuals: <https://manuals.plus/>