

[manuals.plus](#) /

› [Rfiver](#) /

› [Rfiver Swivel Floor TV Stand Instruction Manual for 32-60 inch TVs](#)

Rfiver Swivel Floor TV Stand B0F42XVT8C

Rfiver Swivel Floor TV Stand Instruction Manual

Model: Swivel Floor TV Stand B0F42XVT8C

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Rfiver Swivel Floor TV Stand. Please read this manual thoroughly before installation and use to ensure safe and correct operation. Keep this manual for future reference.



Image 1: Rfiver Swivel Floor TV Stand with a television mounted.

2. SAFETY INFORMATION

Always follow these safety precautions to prevent injury or damage to your product and property:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 88 lbs (40 kg). This stand is designed for TVs between 32 and 60 inches.
- **VESA Compatibility:** Ensure your TV's VESA mounting pattern is within the supported range of 100x100mm to 400x400mm.
- **Stable Surface:** Place the TV stand on a flat, level, and stable surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the TV stand during assembly and ensure the TV is securely mounted to prevent accidental falls.
- **Assembly:** Assemble the stand according to the instructions. Do not modify the product or use it for purposes other than its intended use.
- **Cable Management:** Route all cables neatly to prevent tripping hazards and to avoid damage to the cables.

3. PACKAGE CONTENTS

Before assembly, verify that all parts are present and undamaged. Refer to the included parts list and hardware pack in your product packaging. If any parts are missing or damaged, contact customer service immediately.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 15 minutes. No drilling is required. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Assemble the Base:** Attach the main support pole to the wooden base using the provided screws and tools. Ensure all connections are secure.
3. **Install TV Brackets:** Attach the vertical TV brackets to the back of your television using the appropriate screws and spacers from the hardware kit. Ensure the brackets are centered and securely fastened to your TV's VESA mounting holes.
4. **Mount TV to Stand:** Carefully lift the television and hook the TV brackets onto the mounting plate of the stand. Secure the TV in place with the safety screws or locking mechanisms provided.
5. **Adjust Height (Initial):** Before final placement, adjust the TV to your desired initial height setting. Refer to the 'Operating Instructions' section for details on height adjustment.
6. **Cable Management:** Use the integrated cable management clips or channels to route and conceal TV cables for a tidy appearance and to prevent hazards.

BASE FOOT SUPPORT DESIGN




Image 2: Illustration of the stable base foot support design, highlighting its stability compared to other designs.



Image 3: Close-up view of the base feet support, designed to prevent tilting.

5. OPERATING INSTRUCTIONS

5.1 Swivel Function

The Rriver Swivel Floor TV Stand allows for a 70-degree swivel range, 35 degrees left and 35 degrees right. This feature enables optimal viewing angles from various positions in your room.

- To swivel the TV, gently grasp the sides of the television and rotate it to the desired angle.
- Avoid forcing the swivel beyond its intended range to prevent damage.



Image 4: The TV stand offers a 70-degree swivel for flexible viewing.



Image 5: The swivel function allows for comfortable viewing from different seating arrangements.

5.2 Height Adjustment

The TV stand features 3 height settings, adjustable in 1.97-inch (50 mm) increments, providing a total of 5.9 inches of vertical adjustability. This allows you to position your TV at an ergonomic eye level.

- To adjust the height, carefully lift the TV mounting bracket to disengage it from its current position.
- Slide the bracket up or down to the desired height slot.
- Ensure the bracket is securely seated in the chosen slot before releasing the TV.

MULTI HEIGHT FOR EYE LEVEL COMFORT




Image 6: Visual representation of the 3-level height adjustment for optimal eye-level comfort.

WILL THIS STAND FIT MY TV?



Max Load
88 lbs



Max:400x400mm
Min:100x100mm



**Suitable for flat/
curved TV screens**

Image 7: Detailed diagram of the three adjustable height levels.

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV stand:

- **Cleaning:** Wipe the stand with a soft, dry cloth. For stubborn marks, use a slightly damp cloth and mild detergent, then dry thoroughly. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight and secure. Retighten if necessary.
- **Cable Management:** Ensure cables are still neatly managed and not pinched or damaged.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|-------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| TV stand feels unstable or wobbly. | Screws are loose; stand is on an uneven surface; TV weight exceeds capacity. | Check and tighten all assembly screws. Move the stand to a level surface. Verify TV weight is within 88 lbs limit. |
| TV does not fit the mounting plate. | Incorrect VESA pattern; TV size outside recommended range. | Confirm your TV's VESA pattern is between 100x100mm and 400x400mm. Ensure TV size is between 32-60 inches. |
| Difficulty swiveling the TV. | Obstruction; mechanism needs lubrication. | Check for any objects blocking the swivel path. Apply a small amount of silicone-based lubricant to the swivel mechanism if necessary. |

8. SPECIFICATIONS

Key specifications for the Rfiver Swivel Floor TV Stand:

- **Compatible TV Sizes:** 32 to 60 inches
- **Maximum Load Capacity:** 88 lbs (40 kg)
- **VESA Compatibility:** 100x100mm to 400x400mm (Horizontal x Vertical)
- **Swivel Range:** 70 degrees (35 degrees left, 35 degrees right)
- **Height Adjustment:** 3 levels, 1.97 inch (50 mm) increments, 5.9 inches total adjustability
- **Base Dimensions:** 16.7 x 12.7 x 1 inches (Wood Panel)
- **Material:** Alloy Steel, Wood
- **Product Weight:** Approximately 13.95 lbs
- **Color:** White

WIDE COMPATIBILITY




Image 8: Compatibility details for TV size, weight, and VESA mounting patterns.






Image 9: Detailed compatibility information for various TV types.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Rfiver customer service. Refer to the contact details provided with your product packaging or visit the official Rfiver website. Please have your model number (B0F42XVT8C) and purchase date available when contacting support.

Related Documents - Swivel Floor TV Stand B0F42XVT8C

| | |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>RFIVER TF3001U TV Stand Installation Manual</p> <p>Detailed installation guide for the RFIVER TF3001U TV Stand, including parts list, step-by-step assembly instructions, VESA compatibility chart, and safety guidelines. Learn how to safely mount your TV.</p> |
|  | <p>Rfiver Universal Swivel Tabletop TV Stand Assembly Manual</p> <p>Assembly manual for the Rfiver Universal Swivel Tabletop TV Stand, Model UT2001. Provides step-by-step instructions and parts list for safe and proper installation.</p> |
|  | <p>Rfiver TF2002 TV Stand Assembly Instructions and User Guide</p> <p>Comprehensive guide for assembling the Rfiver TF2002 TV stand. Includes parts list, step-by-step instructions, safety warnings, and cable management tips for your floor TV mount.</p> |
|  | <p>RFIVER UT5002 TV Stand Assembly Instructions and User Guide</p> <p>This document provides assembly instructions, parts list, and safety notices for the RFIVER UT5002 TV Stand. Learn how to safely assemble and install your TV stand for optimal viewing.</p> |
|  | <p>Perlegear PGFS09 Floor TV Stand Instruction Manual</p> <p>Comprehensive instruction manual for the Perlegear PGFS09 Floor TV Stand, detailing assembly, compatibility checks, and safety guidelines for mounting TVs from 32 to 70 inches.</p> |