

ZDZA ZA04

ZDZA ZA04 Electric Bike User Manual

Model: ZA04

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your ZDZA ZA04 Electric Bike. Please read this manual thoroughly before your first ride to ensure proper usage and to maximize your riding experience. Retain this manual for future reference.

2. SAFETY INFORMATION

Your safety is paramount. Always wear a helmet and appropriate safety gear when riding. Familiarize yourself with local traffic laws and regulations regarding electric bicycles. Perform a pre-ride inspection before each use.

2.1 General Safety Guidelines

- Always wear a certified helmet.
- Ensure all components are securely fastened before riding.
- Do not ride under the influence of alcohol or drugs.
- Be aware of your surroundings and traffic.
- Avoid riding in adverse weather conditions or on slippery surfaces.
- Maintain a safe distance from other vehicles and pedestrians.

2.2 Pre-Ride Checklist

- **Brakes:** Check for proper function and responsiveness.
- **Tires:** Ensure tires are inflated to the recommended pressure and are free from damage.
- **Battery:** Verify the battery is securely installed and sufficiently charged.
- **Lights & Reflectors:** Confirm all lights and reflectors are clean and functional.
- **Handlebars & Seat:** Check that they are properly adjusted and tightened.
- **Gears:** Test gear shifting for smooth operation.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all items listed below are present:

- 1x ZDZA ZA04 26" Electric Bike
- 1x Battery Charger
- 1x Tool Kit
- 1x User Manual (this document)

4. ASSEMBLY

The ZDZA ZA04 Electric Bike arrives approximately 90% assembled. The included tool kit and instructions will guide you through the final assembly steps. Typically, this involves attaching the front wheel, handlebars, pedals, and seat.

4.1 Initial Setup Steps

1. **Unpack:** Carefully remove the bike and all components from the packaging.
2. **Install Front Wheel:** Securely attach the front wheel, ensuring the brake rotor is correctly aligned with the caliper.
3. **Attach Handlebars:** Mount the handlebars to the stem, ensuring they are centered and tightened to the recommended torque.
4. **Install Pedals:** Note that pedals are typically left (L) and right (R) specific. Thread them carefully to avoid cross-threading.
5. **Adjust Seat:** Insert the seat post and adjust the seat height for a comfortable riding position, then tighten the quick-release lever or bolt.
6. **Charge Battery:** Fully charge the battery before your first ride. Refer to the 'Battery Information' section for details.
7. **Final Inspection:** Double-check all bolts, connections, and components for tightness and proper function.



Figure 4.1: The ZDZA ZA04 Electric Bike after assembly.

5. COMPONENTS OVERVIEW

Understanding the key components of your ZDZA ZA04 Electric Bike will enhance your riding experience and maintenance efforts.

5.1 Motor

The ZA04 is equipped with a **1000W peak power motor**, providing robust assistance and enabling a top speed of 22 mph. It is designed to handle inclines of up to 25% effortlessly.




Figure 5.1: Detailed view of the 1000W peak brushless motor.

5.2 Battery

The bike features a **375Wh rechargeable and removable lithium battery**. This battery provides a range of up to 40 miles in pedal-assist mode and is IPX6 waterproof, ensuring durability. It also includes a Battery Management System (BMS) for intelligent safety.



Figure 5.2: Illustration of the 375Wh removable and waterproof battery integrated into the frame.

5.3 Display

An **upgraded colorful LCD display** provides real-time riding data, including speed, battery level, mileage, and power assistance mode. It is designed for clear readability even in varying light conditions.



Figure 5.3: Overview of the colorful LCD display showing various ride metrics.

5.4 Tires

The ZA04 features **26-inch puncture-resistant tires**, designed to provide stability and comfort across various terrains, including snow, mountain, beach, and urban roads.



Figure 5.4: The 26-inch puncture-resistant tires suitable for diverse road conditions.

5.5 Suspension

Dual lockable front suspension forks absorb shocks and bumps, ensuring a smoother and more comfortable ride on uneven surfaces.



Figure 5.5: Illustration of the dual front suspension system for enhanced ride comfort.

5.6 Brakes

A **dual disc braking system** provides sensitive and fast stopping power, ensuring precise control and enhancing riding safety in various conditions.



Dual Disc Brake System

Sensitive dual disc brakes provide fast and stable braking power to ensure your riding safety in any road conditions.

Figure 5.6: Close-up view of the dual disc brake system.

5.7 Gears

The **7-speed gear system** allows for easy adjustment to different terrains and riding preferences, providing an efficient and comfortable cycling experience.



Figure 5.7: Illustration of the 7-speed gear system.

5.8 Lighting

A bright headlight and multiple reflectors are integrated to ensure visibility and safety during night riding.



Figure 5.8: The integrated headlight and reflectors for improved visibility.

5.9 Frame and Seat

The bike features a stable carbon steel triangular frame with a step-over design, supporting a maximum load capacity of 265 lbs. The ergonomic seat is adjustable for personalized comfort.




Figure 5.9: The ergonomic and adjustable seat for rider comfort.

6. OPERATING INSTRUCTIONS

Learn how to operate your ZDZA ZA04 Electric Bike effectively and safely.

6.1 Powering On/Off

To power on the bike, press and hold the power button on the LCD display until the screen illuminates. To power off, press and hold the same button until the display turns off.

6.2 Riding Modes

The ZA04 offers five distinct riding modes:

- **Pure Electric Mode:** Engages the motor fully without pedal input.
- **Pedal Assist Mode (PAS):** Provides motor assistance as you pedal. The level of assistance can typically be adjusted via the display.
- **Cruise Control Mode:** Maintains a set speed without continuous throttle or pedal input (refer to display manual for activation).
- **Normal Bike Mode:** The motor is off, and the bike operates like a traditional bicycle.
- **Push Assist Mode:** Provides low-speed motor assistance for walking the bike uphill or through difficult terrain.

6.3 Using the Display

The colorful LCD display allows you to monitor your ride and adjust settings. Use the control buttons near the display to:

- View current speed, average speed, and max speed.
- Check battery level.
- Monitor trip distance and total mileage (ODO).
- Select pedal assist levels.
- Turn the headlight on/off.

6.4 Shifting Gears

Use the trigger shifter on the handlebars to change between the 7 available gears. Shift gears smoothly to match your speed and terrain, reducing strain on the drivetrain.

6.5 Braking

Apply both front and rear brakes simultaneously for effective and controlled stopping. Avoid sudden, hard braking, especially at high speeds or on loose surfaces.

6.6 Charging the Battery

The battery can be charged either while installed on the bike or after removal. Connect the charger to a standard power outlet and then to the battery's charging port. The charging indicator on the charger will show the charging status. A full charge typically takes approximately 5 hours.



Figure 6.1: The two convenient methods for charging the removable battery.

7. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your electric bike.

7.1 General Cleaning

Clean your bike regularly with a damp cloth and mild soap. Avoid using high-pressure washers directly on electrical components or bearings.

7.2 Tire Pressure

Check tire pressure before each ride. Maintain the recommended pressure (usually indicated on the tire sidewall) for optimal performance and to prevent punctures.

7.3 Brake Inspection

Regularly inspect brake pads for wear and brake cables for tension. Replace worn pads promptly and adjust cable tension as needed to ensure effective braking.

7.4 Battery Care

- Store the battery in a cool, dry place when not in use.
- Avoid fully discharging the battery.
- Charge the battery at least once every two months if not used regularly.

7.5 Chain Lubrication

Keep the chain clean and lubricated to ensure smooth gear changes and prevent premature wear.

8. TROUBLESHOOTING

This section addresses common issues you might encounter with your ZDZA ZA04 Electric Bike.

8.1 Bike Not Powering On

- **Check Battery:** Ensure the battery is fully charged and securely installed.
- **Check Connections:** Verify all electrical connections are firm and free from damage.
- **Power Button:** Ensure the power button on the display is pressed correctly.

8.2 Motor Not Assisting

- **Check PAS Level:** Ensure a pedal assist level (PAS) is selected on the display.
- **Brake Levers:** Some e-bikes have safety cut-off switches on the brake levers. Ensure brake levers are not partially engaged.
- **Battery Level:** Confirm the battery has sufficient charge.

8.3 Brakes Squeaking

- **Clean Rotors/Pads:** Dirt or oil on rotors or pads can cause squeaking. Clean them with a brake-specific cleaner.
- **Pad Wear:** Check brake pads for wear and replace if necessary.

- **Bedding In:** New brakes may squeak until properly bedded in.

For issues not covered here, please contact customer support.

9. SPECIFICATIONS

Detailed technical specifications for the ZDZA ZA04 Electric Bike:

Feature	Specification
Brand	ZDZA
Model Name	ZA04
Bike Type	Commuting Bike, Electric Bike
Age Range (Description)	Adult
Number of Speeds	7
Color	Black
Wheel Size	26 Inches
Frame Material	Carbon Steel
Suspension Type	Dual Front
Special Features	Digital Display, Dual Disc Brake, Dual Suspension, Headlight, Lightweight
Item Weight	26.25 Kilograms (57.9 lbs)
Maximum Weight Recommendation	120 Kilograms (265 lbs)
Motor Power	1000W Peak
Battery	375Wh Removable Lithium Battery
Max Speed	22 Mph
Range	Up to 40 Miles (in PAS mode)
Charging Time	Approx. 5 Hours
Minimum User Height	63 Inches
Dimensions (L x W x H)	66.9 x 25.8 x 39.4 Inches



Figure 9.1: Key dimensions and weight specifications of the ZDZA ZA04 Electric Bike.

10. WARRANTY AND SUPPORT

The ZDZA ZA04 Electric Bike is covered by a **12-month manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

10.1 Warranty Exclusions

The warranty does not cover:

- Normal wear and tear.
- Damage caused by improper assembly or maintenance.
- Damage resulting from accidents, misuse, neglect, or unauthorized modifications.
- Consumable parts such as tires, brake pads, and chains.

10.2 Customer Support

If you have any questions, require assistance with assembly, operation, or encounter any issues with your ZDZA ZA04 Electric Bike, please contact our customer service team. We aim to respond within 24 hours to resolve your concerns.

Contact Information: Please refer to the contact details provided with your purchase documentation or visit the official ZDZA website for support.

© 2025 ZDZA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question