

[Manuals.plus](#) /

> [GVODE](#) /

> GVODE Masticating Juicer Attachment for KitchenAid Stand Mixer, Cold Press Slow Juicer with 4.9" Large Feed Chute for Whole Fruits & Vegetables, Includes 2*1L Measuring Cups for Kitchenaid Attachments

GVODE EUG2501

GVODE Masticating Juicer Attachment User Manual

Model: EUG2501

INTRODUCTION

Thank you for choosing the GVODE Masticating Juicer Attachment. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new juicer attachment. Designed to seamlessly integrate with your KitchenAid Stand Mixer, this cold press juicer extracts maximum juice yield while preserving vital nutrients from fruits and vegetables.

Please read this manual thoroughly before first use and keep it for future reference.

IMPORTANT SAFEGUARDS

When operating any electrical appliance, basic safety precautions should always be followed. This attachment is designed for household use only.

- **Read all instructions:** Familiarize yourself with the operation and safety guidelines before use.
- **Electrical Safety:** Ensure your KitchenAid Stand Mixer is unplugged before attaching or detaching the juicer.
- **Hands Clear:** Keep fingers out of the feed chute and away from moving parts when the machine is operating. Always use the provided food pusher.
- **No Foreign Objects:** Do not insert tools like spoons, forks, or other utensils into the feed chute.
- **Proper Assembly:** Ensure all parts are correctly assembled and locked into place before operating.
- **Cleaning:** Disassemble all non-motor parts for cleaning. Do not immerse the motor base of the KitchenAid mixer in water.
- **Hard Produce:** For very hard vegetables like carrots, cut them into smaller pieces (e.g., 2-3 inch chunks, no more than 1 inch thick) to prevent strain on the auger and potential damage.

- **Soft Fruits:** For very soft fruits like blueberries, it is recommended to process them with more fibrous fruits or vegetables to aid in extraction.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.

PRODUCT COMPONENTS

The GVODE Masticating Juicer Attachment comes with the following parts:

- **Masticating Juicer Attachment:** The main unit that connects to your KitchenAid Stand Mixer.
- **Feed Chute & Pusher:** For introducing fruits and vegetables into the juicer and safely pushing them down.
- **Juice Bowl & Deflector:** Collects the extracted juice.
- **Auger (Screw Rod):** The spiral component that crushes and presses produce.
- **Filter/Sieve:** Separates juice from pulp.
- **Pulp Outlet:** Where the dry pulp is expelled.
- **Juice Outlet with Silicone Nozzle:** For dispensing juice directly into cups.
- **2 x 1L Measuring Cups:** BPA-free cups for collecting juice and pulp.
- **Cleaning Brush:** A specialized brush with picks for thorough cleaning of the filter and other parts.



Image: The GVOKE Masticating Juicer Attachment connected to a KitchenAid Stand Mixer, alongside the two 1-liter measuring cups.

SETUP AND ASSEMBLY

Follow these steps to assemble your juicer attachment:

1. **Prepare Mixer:** Ensure your KitchenAid Stand Mixer is unplugged and the power hub cover is removed.
2. **Attach Base:** Insert the juicer attachment's drive shaft into the power hub of your KitchenAid mixer. Turn the locking knob clockwise until the attachment is securely fastened.
3. **Insert Auger:** Place the auger (screw rod) into the juicer bowl, aligning it properly.
4. **Place Filter:** Position the filter/sieve around the auger inside the juicer bowl.
5. **Attach Feed Chute:** Snap the feed chute assembly onto the juicer bowl, ensuring it clicks into place.
6. **Secure Top:** Rotate the top juice cup clockwise into the groove at the top of the base to lock it in place.
7. **Position Cups:** Place the two 1L measuring cups under the juice outlet and pulp outlet respectively.
8. **Attach Silicone Nozzle:** For precise juice dispensing, attach the yellow silicone nozzle to the juice outlet.

Installation Process



Image: A step-by-step visual guide demonstrating the assembly of the juicer attachment onto a KitchenAid mixer.



Image: The fully assembled GVODE Masticating Juicer Attachment connected to a red KitchenAid Stand Mixer, ready for juicing.

OPERATING INSTRUCTIONS

Before juicing, ensure your fruits and vegetables are washed. The 4.9-inch extra-wide chute allows for whole fruits and vegetables, reducing pre-cutting time.

1. **Prepare Produce:** Wash fruits and vegetables thoroughly. For harder produce like carrots or apples, it is recommended to cut them into smaller pieces to ease the juicing process and protect the auger.
2. **Set Mixer Speed:** Turn on your KitchenAid Stand Mixer and set the speed to 6-8 for optimal juicing performance.
3. **Feed Produce:** Slowly feed the fruits and vegetables into the feed chute. Use the food pusher to gently guide the produce down. *Never use your fingers or other utensils.*
4. **Collect Juice and Pulp:** The juicer will separate the juice and pulp into the designated 1L measuring cups. The cold-press technology ensures a high juice yield with minimal sediment.

5. **Anti-Drip Feature:** The silicone nozzle on the juice outlet allows you to pause juicing without drips by closing the valve.

4.9 INCH

Feed Chute and Safety Design



4.2 INCH



Ours



Large 4.9-inch bore with reversible top allows you to add fruit during the juicing process

Others



4.2-inch, no convenient flip design

Image: A visual comparison highlighting the large 4.9-inch feed chute of the GVODE juicer attachment compared to smaller, less convenient feed chutes on other models.

- ✓ Includes 2 x 1L Measuring Cups
- ✓ Sediment less than 0.5%
- ✓ Smooth juice extraction
- ✓ Maximizes juice nutrient retention

- ✗ No measuring cup included
- ✗ High sediment
- ✗ Loss of nutrients
- ✗ Poor juicing

Others



Image: Demonstrates the high-yield, low-sediment performance of the GVODE juicer, showing clear juice in one measuring cup and minimal pulp in the other.

Max 99% Juice Yield with Slow

with Slow Masticating Juicer



Efficient And
Time-saving



Retain The
Nutrients of Fruits
And Vegetables



Smooth Juicing



Image: An illustrative diagram explaining the masticating process, showing how the auger cuts, squeezes, extracts, and grinds produce for maximum juice yield.

CARE AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your juicer attachment.

1. **Disassembly:** Unplug the KitchenAid mixer. Disassemble all non-motor parts of the juicer attachment by reversing the assembly steps.
2. **Rinsing:** Rinse all disassembled parts under running water immediately after use to prevent pulp from drying and sticking.
3. **Cleaning Brush:** Use the included cleaning brush to remove any stubborn pulp or residue from the filter/sieve and other intricate parts. The specialized picks on the brush are designed to reach small crevices.
4. **Washing:** All non-motor parts are dishwasher safe (top rack recommended) or can be hand-washed with warm, soapy water.

- 5. **Drying:** Allow all parts to air dry completely before reassembling or storing.
- 6. **Storage:** Store the attachment and its components in a clean, dry place.

Easy To Clean

Disassemble the product and clean it with the included brush



Image: Illustrates the ease of cleaning the disassembled parts of the juicer attachment under running water, highlighting the cleaning brush.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer not operating.	Mixer not plugged in or turned on; attachment not properly secured.	Ensure KitchenAid mixer is plugged in and powered on. Check that the attachment is securely fastened to the power hub.

Problem	Possible Cause	Solution
Low juice yield or wet pulp.	Produce fed too quickly; auger or filter clogged; improper speed setting.	Feed produce slowly. Clean the auger and filter thoroughly. Ensure mixer speed is set to 6-8.
Pulp or juice backing up.	Clogged pulp or juice outlet; too much fibrous produce.	Stop the mixer, disassemble, and clear any blockages. For fibrous produce like celery, cut into shorter pieces.
Loud noise or grinding sound.	Hard produce causing strain; improper assembly.	Ensure hard produce is cut into smaller, manageable pieces. Verify all parts are correctly assembled and locked.

If you encounter any issues not listed here, please contact GVOKE customer support for assistance.

SPECIFICATIONS

Brand: GVOKE

Model Number: EUG2501

Color: White

Product Dimensions: 5.51"D x 3.93"W x 11.81"H

Item Weight: 4.36 pounds

Blade Material: Plastic (referring to auger material)

Special Feature: Whole Fruit Processing, Masticating

Included Components: Masticating Juicer Attachment, Product Manuals, Cleaning Brush, Capacity Cups (2x 1L)

Recommended Uses: Vegetables, Fruit

WARRANTY AND SUPPORT

This product includes a one-year guarantee. For warranty claims, technical support, or any inquiries, please contact GVOKE customer service through the retailer where the product was purchased or visit the official GVOKE website for contact information.

GVOKE Official Store: [Visit the GVOKE Store on Amazon](#)