

AMACOOOL D37

AMACOOOL D37 Portable Stroller Fan User Manual

Model: D37

1. INTRODUCTION

Thank you for choosing the AMACOOOL D37 Portable Stroller Fan. This fan is designed to provide a strong yet quiet breeze with its 5000mAh rechargeable battery, 3-speed settings, and 360° rotation capability. Its flexible tripod allows for versatile attachment to various surfaces, making it ideal for strollers, car seats, cribs, and more. Please read this manual carefully to ensure proper use and maintenance of your fan.

2. KEY FEATURES

- **Strong Wind & Whisper-Quiet:** Features a 5-inch head with upgraded aerodynamic blades, operating under 30dB for robust yet quiet airflow.
- **Outstanding Battery Life:** Built-in 5000mAh rechargeable battery provides up to 20 hours of runtime at low speed. Fully charges in 2-3 hours via USB-C.
- **360° Rotation:** The fan head adjusts vertically and horizontally for optimal airflow direction. The bendable tripod also aids in height and angle adjustment.
- **Easy and Safe to Use:** A single control button manages power and 3 wind speeds. Fine mesh cover protects small fingers from blades.
- **Upgraded Flexible & Stable Tripod:** Durable, high-grip legs securely wrap around various objects like strollers, cribs, car seats, bikes, and treadmills. Lightweight and portable at 0.68lb.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your AMACOOOL D37 Portable Stroller Fan:

LARGE AIR OUTLET & EASY TO USE




Figure 1: Fan Components and Dimensions

Fan Head: 5-inch diameter, houses blades and motor.

Control Button: Single button for power and speed adjustments.

Type-C Port: For charging the internal battery.

Power Indicator: LED light indicating battery status and operation.

Flexible Tripod: Bendable legs for versatile mounting and positioning.

4. SETUP

4.1 Attaching the Fan

The flexible tripod legs allow the fan to be securely attached to various objects. Bend and wrap the legs around handles, bars, or edges of strollers, car seats, cribs, or other surfaces. Ensure the fan is stable and securely fastened before use.




Figure 2: Flexible Tripod for Versatile Attachment

4.2 Charging the Fan

Before first use, fully charge the fan. Connect the provided USB-C cable to the fan's Type-C port and plug the other end into a compatible USB power source (e.g., portable charger, laptop, car adapter). The power indicator light will show charging status. A full charge typically takes 2-3 hours.



Figure 3: Rechargeable Battery and USB-C Charging

5. OPERATING INSTRUCTIONS

5.1 Power and Speed Control

Locate the single control button on the back of the fan. Press the button once to turn the fan on at low speed. Subsequent presses will cycle through medium speed, high speed, and then turn the fan off.

- **1st Press:** Low Speed
- **2nd Press:** Medium Speed
- **3rd Press:** High Speed
- **4th Press:** Power Off

5.2 LED Light Function

Some models of the AMACOOOL D37 fan may include an LED light feature. If present, a separate button or a long press of the main control button will activate the light. Cycle through different brightness settings or turn the light off as needed.

6. VERSATILE APPLICATIONS

The AMACOOOL D37 fan is designed for a wide range of uses:



Figure 4: Variety of Applications

- **Stroller:** Keep your baby cool during walks or outdoor activities.
- **Car Seat:** Provide airflow in the car, especially during warmer weather.
- **Crib:** Ensure comfortable sleeping conditions for infants.

- **Desk/Table:** Use as a personal fan in home offices or other indoor spaces.
- **Outdoor Activities:** Ideal for camping, beach trips, or sporting events.
- **Treadmill/Bike:** Attach to exercise equipment for personal cooling.

7. SAFETY GUIDELINES

To ensure safe operation and prevent injury, please observe the following:

- Keep fingers and other objects away from the fan blades. The fan features a narrow mesh cover to protect small fingers.
- Do not immerse the fan in water or expose it to excessive moisture.
- Do not attempt to disassemble or repair the fan yourself. Contact customer support for assistance.
- Keep the fan away from heat sources and open flames.
- Ensure the fan is securely attached when using the tripod legs to prevent it from falling.
- Supervise children when the fan is in use.



Figure 5: Safety and Design Features

8. MAINTENANCE

8.1 Care and Cleaning

To maintain optimal performance, clean your fan regularly:

- Turn off the fan and unplug it before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- For the fan blades, use a soft brush or compressed air to remove dust. Do not use water or harsh chemicals.
- Ensure the fan is completely dry before resuming use.

8.2 Battery Care

- Charge the fan fully before long periods of storage.
- Recharge the fan at least once every three months to prolong battery life.
- Avoid exposing the fan to extreme temperatures, which can degrade battery performance.

9. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following table:

Problem	Possible Cause	Solution
Fan does not turn on	Low battery; Power button not pressed correctly	Charge the fan fully; Press the power button firmly.
Weak airflow	Low speed setting; Obstruction in front/back of fan; Low battery	Increase speed setting; Clear any obstructions; Charge the fan.
Fan makes unusual noise	Obstruction hitting blades; Fan not on a stable surface	Turn off and check for obstructions; Place on a flat, stable surface or re-secure tripod.
LED light not working	Light function not activated; Low battery	Press the LED button (if applicable) or main control button to activate; Charge the fan.

10. SPECIFICATIONS

Feature	Detail
Brand	AMACOOOL
Model Name	D37
Color	Green
Power Source	Battery Powered
Battery Type	1 Lithium Polymer battery (included)
Number of Power Levels	3
Control Method	Touch
Noise Level	30 Decibels
Product Dimensions	3.27"D x 5.51"W x 8.26"H
Item Weight	14.9 ounces
Special Feature	Adjustable Tilt, Portable
Installation Type	Clip-on
Indoor/Outdoor Usage	Indoor, Outdoor

11. WARRANTY AND SUPPORT

11.1 Warranty Information

Your AMACOOOL D37 Portable Stroller Fan comes with a standard manufacturer's warranty. Please refer to the product packaging or the official AMACOOOL website for specific warranty terms and conditions.

11.2 Customer Support

For any questions, concerns, or technical support regarding your AMACOOOL D37 fan, please contact AMACOOOL customer service through the retailer where the product was purchased or visit the official AMACOOOL website for contact information.