

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [RAINPOT](#) /

› [RAINPOT Handheld Steam Cleaner CP89937-25US User Manual](#)

RAINPOT CP89937-25US

RAINPOT Handheld Steam Cleaner CP89937-25US User Manual

Model: CP89937-25US

1. INTRODUCTION

Thank you for purchasing the RAINPOT Handheld Steam Cleaner. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your device. Please read this manual thoroughly before first use and retain it for future reference.

This powerful 2500W steam cleaner generates high-temperature steam (up to 229°F/105°C) and 3 BAR pressure, designed for effective cleaning across various surfaces.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Do not leave the appliance unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not direct steam at people, animals, or electrical components. High temperature steam can cause burns.
- Always ensure the water tank cap is securely closed before operating.
- Use distilled or demineralized water to prevent mineral buildup and prolong the life of the appliance.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your RAINPOT Handheld Steam Cleaner.



Image: Overview of the RAINPOT Handheld Steam Cleaner, showing the main unit, handheld sprayer, extended sprayer rod, speed adjustment knob, 2.2-meter-long steam tube, and large capacity water tank. Also visible are various brush heads: big hair brush hood, small hair brush hood, and steel brush.

- **Main Unit:** Contains the heating element and water tank.
- **Handheld Sprayer:** For directing steam.
- **Extended Elbow Nozzle:** For reaching difficult areas.
- **Large Brush:** For general cleaning.
- **Small Brush:** For detailed cleaning.
- **Small Steel Brush:** For stubborn dirt and grime.
- **Speed Adjustment Knob:** To control steam output.
- **Water Tank:** Large capacity for extended use.

4. SETUP AND ASSEMBLY

1. **Unpack:** Carefully remove all components from the packaging.

2. Fill Water Tank:

Unscrew the water tank cap. Fill the large capacity glass water tank with clean, distilled, or demineralized water. Do not overfill. Securely close the cap.



Image: The RAINPOT Handheld Steam Cleaner main unit and various accessories, including the handheld sprayer, extended nozzle, and different brush heads. This image illustrates the complete set of components.

3. Attach Accessories:

Select the appropriate brush head or nozzle for your cleaning task. Attach it firmly to the handheld sprayer. For extended reach, connect the extended elbow nozzle.

4. Connect Power:

Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

1. **Power On:** Turn on the main power switch located on the unit. The indicator light will illuminate.
2. **Heating Time:** Allow approximately 10 seconds for the unit to heat up and generate steam.
3. **Adjust Steam Output:** Use the speed adjustment knob to select one of the six available steam gears. Start with a lower setting and increase as needed for stubborn stains.

4. **Begin Cleaning:** Direct the steam nozzle towards the surface to be cleaned. Keep the sprayer head close to the machine for optimal temperature and cleaning effect.

5. **Cleaning Applications:**

- **Kitchen:** Ideal for cleaning walls, stoves, range hoods, microwave ovens, and refrigerators.
- **Bathroom:** Effective on tiles, grout, and fixtures.
- **Automotive:** Clean car interiors and tires.
- **General Home:** Refresh surfaces, clean windows, and mirrors.




Image: A collage demonstrating the RAINPOT Handheld Steam Cleaner being used for various tasks, including cleaning car interiors, kitchen sinks, outdoor grills, and air conditioner filters. This highlights the versatility of the product.

6. **Continuous Use:** The large capacity water tank allows for approximately 1 hour of continuous operation on a single fill.

7. **Power Off:** After cleaning, turn off the main power switch and unplug the appliance.

6. CARE AND MAINTENANCE

1. **Empty Water Tank:** After each use, ensure the appliance has cooled down, then carefully empty any remaining

water from the tank.

2. **Clean Accessories:** Wash brush heads and nozzles with water and mild detergent. Allow them to dry completely before storing.
3. **Wipe Down Unit:** Wipe the exterior of the steam cleaner with a damp cloth. Do not use abrasive cleaners.
4. **Descaling (Optional):** If you notice reduced steam output or mineral buildup, descale the unit using a descaling solution suitable for steam appliances, following the solution's instructions.
5. **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty. Unit not heated sufficiently. Mineral buildup (scaling).	Refill water tank. Allow 10 seconds for heating. Descal the unit as per maintenance instructions.
Water leaking from nozzle.	Nozzle not securely attached. Overfilling the water tank.	Ensure nozzle is firmly attached. Do not overfill the water tank.
Appliance not turning on.	Not plugged in. Power outlet malfunction.	Check power connection. Test outlet with another appliance.

If the problem persists after attempting these solutions, please contact customer support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	CP89937-25US
Brand	RAINPOT
Wattage	2500W
Steam Temperature	Up to 229°F / 105°C
Steam Pressure	3 BAR
Heating Time	Approx. 10 seconds
Steam Output Levels	6 adjustable gears
Power Cord Length	2.5 meters
Spray Gun Length	2.2 meters
Included Accessories	Extended elbow nozzle, large brush, small brush, small steel brush

9. WARRANTY AND SUPPORT

RAINPOT products are manufactured to high-quality standards. For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official RAINPOT website. Please have your model number (CP89937-25US) and purchase date available when contacting support.

For additional assistance, you may contact the seller directly through your purchase platform.