

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [oneisall](#) /

› [oneisall Dog Clippers \(Model B0F4429CDX\) Instruction Manual](#)

oneisall B0F4429CDX

oneisall Dog Clippers (Model B0F4429CDX) Instruction Manual

For Small and Large Dogs, Cats, and Animals

1. INTRODUCTION

Thank you for choosing the oneisall Dog Clippers. This grooming kit is designed to provide a quiet and efficient grooming experience for your pets. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. SAFETY INFORMATION

- Keep the appliance dry. Do not immerse in water or use in wet conditions.
- Keep out of reach of children and pets when not in use.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support if needed.
- Ensure the clipper is fully charged before first use. Avoid overcharging to prevent battery damage.
- Always check the blades for any damage or debris before and after each use.
- Use only the provided charging cable.

3. WHAT'S INCLUDED

Your oneisall Dog Grooming Kit includes:

- oneisall Dog Grooming Clipper
- 6 Guide Guards (3mm, 6mm, 9mm, 12mm, 15mm, 18mm)
- Cleaning Brush
- Comb
- Scissor
- USB Charging Cable

EASY TO USE



ONE BUTTON
(on/off & 2-speed mode)



High Performance Battery
& Battery Power Monitor



Easy to Charge
Cordless & With Cord Use



Easy to Clean
Detachable Blade

Image showing the complete oneisall Dog Grooming Kit contents, including the clipper, various guide combs, cleaning brush, comb, scissors, and charging cable, neatly arranged in its packaging.

4. SETUP

4.1. Charging the Clipper

The clipper features a 2000mA high-capacity Li-ion battery.

- Connect the USB charging cable to the clipper and a suitable USB power adapter (not included).
- Charge for approximately 3 hours for a full charge. The intelligent LCD display will indicate the charging status.
- Avoid overcharging to prolong battery life.

LONG-LASTING BATTERY LIFE



BUILT-IN LI-ION BATTERY

⚡ 2.5 hours
charging time

⚡ 150 minutes
working time

Illustration demonstrating how to charge the oneisall Dog Clipper using the USB cable, highlighting the 2.5-hour charging time for 150 minutes of use.

4.2. Attaching and Removing Guide Guards

Select the desired guide guard (3mm, 6mm, 9mm, 12mm, 15mm, or 18mm) for your pet's coat length.

- To attach: Align the guide guard with the clipper blade and slide it on until it clicks securely into place.
- To remove: Gently push the guard away from the blade.

ADJUSTABLE BLADE & GUIDE COMBS

From 0.8mm to 2.0mm



Image displaying the oneisall Dog Clipper with its adjustable blade settings (0.8mm to 2.0mm) and the six included guide combs (3mm, 6mm, 9mm, 12mm, 15mm, 18mm) for various hair lengths.

5. OPERATING INSTRUCTIONS

5.1. Powering On/Off and Speed Adjustment

The clipper features a simple one-button operation for power and speed.

- To turn on: Press the ON/OFF button. The clipper will start at the default speed.
- To adjust speed: Press the ON/OFF button again to switch between the two speeds (5000 RPM and 5700 RPM).
- To turn off: Press the ON/OFF button until the clipper stops.

EASY TO USE



ONE BUTTON
(on/off & 2-speed mode)



High Performance Battery
& Battery Power Monitor



Easy to Charge
Cordless & With Cord Use



Easy to Clean
Detachable Blade

Image illustrating the easy-to-use features of the oneisall Dog Clipper, including the one-button operation for on/off and 2-speed mode, high-performance battery monitor, easy charging, and detachable blade for cleaning.

5.2. Adjusting Blade Length

The ceramic blade can be adjusted from 0.8mm to 2.0mm using the rotating dial on the clipper body. This allows for precise trimming without a guide comb or fine-tuning with one.

ADJUSTABLE BLADE & GUIDE COMBS

From 0.8mm to 2.0mm



Image displaying the oneisall Dog Clipper with its adjustable blade settings (0.8mm to 2.0mm) and the six included guide combs (3mm, 6mm, 9mm, 12mm, 15mm, 18mm) for various hair lengths.

5.3. Grooming Your Pet

- Ensure your pet's coat is clean, dry, and free of tangles before grooming. Use the included comb to brush out any knots.
- Start with a longer guide comb if you are unsure of the desired length.
- Hold the clipper firmly and move it in the direction of hair growth.
- The ultra-quiet 50db low noise design helps keep pets calm during grooming.



Image highlighting the quiet design of the oneisall Dog Clipper, showing a sleeping dog next to the clipper with a sound level meter indicating 50db, emphasizing its low noise operation for pet comfort.

6. MAINTENANCE

6.1. Cleaning the Blades

Regular cleaning ensures optimal performance and hygiene.

- Turn off the clipper.
- Detach the blade by pushing it forward.
- Use the included cleaning brush to remove any hair or debris from the blades and the clipper head.
- The removed blade part can be directly washed under water for thorough cleaning. Ensure it is completely dry before reattaching.
- Reattach the blade by aligning it and pushing it back until it clicks.

6.2. Oiling the Blades

Apply a few drops of clipper oil (not included in this kit, but recommended for maintenance) to the blades regularly to keep them sharp and running smoothly.

7. TROUBLESHOOTING

7.1. Clipper Not Turning On

- Check if the battery is charged. Recharge if necessary.
- Ensure the ON/OFF button is pressed correctly.

7.2. Poor Cutting Performance

- Clean the blades thoroughly to remove any trapped hair or debris.
- Ensure the blades are properly oiled.
- Check if the blade length adjustment is set correctly for the coat type.
- Ensure the guide comb is securely attached.

7.3. Clipper Overheating

- Turn off the clipper and allow it to cool down.
- Clean and oil the blades.
- Avoid continuous use for extended periods; take breaks if grooming a large pet.

8. SPECIFICATIONS

Feature	Detail
Model	B0F4429CDX
Brand	oneisall
Battery Type	2000mA High Capacity Li-ion Battery
Charging Time	Approx. 3 hours
Operating Time	Up to 220 minutes
Noise Level	Approx. 50db
Speed Settings	2 speeds (5000 RPM and 5700 RPM)
Blade Adjustment	0.8mm - 2.0mm
Guide Combs	3mm, 6mm, 9mm, 12mm, 15mm, 18mm (6 total)
Power Source	Rechargeable (Cordless use, can be used while charging)
Package Dimensions	9.06 x 7.8 x 2.2 inches
Weight	1.23 Pounds
Date First Available	April 1, 2025

9. WARRANTY AND SUPPORT

For warranty information or customer support, please contact oneisall directly.

Protection plans are available for purchase separately:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan covering eligible purchases)

Return Policy: 30-day refund/replacement policy.