Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YUYTE HZ-006

YUYTE HZ-006 Electric Makeup Brush Cleaner User Manual

Model: HZ-006 | Brand: YUYTE

1. Introduction

Thank you for choosing the YUYTE HZ-006 Electric Makeup Brush Cleaner. This device is designed to provide efficient and thorough cleaning and drying for your makeup brushes, ensuring hygiene and extending brush life. Featuring an advanced LCD display, smart touch controls, reverse power cleaning, and customizable drying times, the HZ-006 simplifies your brush maintenance routine.



Image 1.1: Overview of the YUYTE HZ-006 Electric Makeup Brush Cleaner, showcasing its LCD display, touch controls, and cleaning functions.

2. Important Safety Information

- Read all instructions before use.
- Keep the device away from water and moisture. Do not immerse the main unit in water.
- Use only the provided power cable.
- Keep out of reach of children.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if issues arise.
- Ensure the power supply matches the device's requirements.

3. Package Contents

Verify that all items are present in the package:

- 1 x YUYTE HZ-006 Electric Makeup Brush Cleaner (Main Unit)

- 1 x Power Cable
- 1 x User Manual (This document)

4. Product Overview

The YUYTE HZ-006 consists of a main unit housing the motor and controls, and a detachable cleaning cylinder. The main unit features an LCD touch control panel for easy operation.



Image 4.1: Angled view of the YUYTE HZ-006 Electric Makeup Brush Cleaner.

5. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Place the Cleaning Cylinder:** Ensure the transparent cleaning cylinder is securely placed onto the main unit. It should click into position.
3. **Connect Power:** Plug the power cable into the designated port on the device, then connect the other end to a suitable power outlet.



Image 5.1: The main unit and detachable cleaning cylinder, illustrating how they separate for setup and maintenance.

6. Operating Instructions

6.1 Cleaning Process

1. **Add Water and Cleaning Solution:** Fill the cleaning cylinder with an appropriate amount of water and a small quantity of makeup brush cleaning solution. Do not overfill.
2. **Insert Brushes:** Place your makeup brushes into the designated slots within the cleaning cylinder. Ensure brushes are securely held and bristles are submerged in the solution.
3. **Start Cleaning:** Touch the power button on the LCD control panel to begin the 5-minute quick cleaning cycle. The LCD display will show the cleaning progress.
4. **Reverse Power Cleaning:** The device features a reverse power cleaning function that automatically alternates rotation directions to ensure a deep and thorough clean. This function operates automatically during the cleaning cycle.
5. **Rinse (Optional):** After the cleaning cycle, you may remove the brushes and rinse them under clean water if desired, then return them to the cleaner for drying.



Image 6.1: Illustration of the forward and reverse cleaning function, ensuring comprehensive brush cleaning.

6.2 Drying Process

1. **Select Drying Time:** After cleaning, use the touch controls on the LCD panel to select your desired air drying time: 2 hours or 5 hours.
2. **Start Drying:** The device will begin the selected air drying cycle, gently drying your brushes while maintaining their shape and softness.
3. **Completion:** Once the drying cycle is complete, the device will automatically power off. Remove your clean and dry brushes.



Image 6.2: The LCD touch control panel, highlighting the 2-hour and 5-hour timed air drying function options.

7. Maintenance

Regular cleaning of the device ensures optimal performance and hygiene.

1. **Empty and Rinse:** After each use, empty any remaining water and cleaning solution from the cleaning cylinder. Rinse the cylinder thoroughly with clean water.
2. **Dismantle for Deep Cleaning:** The cleaning cylinder can be easily detached from the main unit for more thorough cleaning. Wash the cylinder with mild soap and water, then rinse and dry completely before reattaching.
3. **Wipe Main Unit:** Use a soft, damp cloth to wipe the exterior of the main unit. Do not use abrasive cleaners or immerse the main unit in water.
4. **Storage:** Store the device in a clean, dry place when not in use.



Image 7.1: The separated main unit and cleaning cylinder, demonstrating ease of dismantling for cleaning.

8. Troubleshooting

- **Device does not turn on:**
  - Ensure the power cable is securely connected to both the device and the power outlet.
  - Check if the power outlet is functional.
- **Brushes are not cleaning effectively:**
  - Ensure sufficient water and cleaning solution are used.
  - Do not overload the cleaner with too many brushes.
  - For heavily soiled brushes, a pre-soak or a second cleaning cycle may be necessary.
- **Brushes are not drying completely:**
  - Ensure the selected drying time (2H or 5H) is appropriate for the brush type and density.

- Avoid placing excessively wet brushes directly into the drying cycle without a prior cleaning cycle.

9. Specifications

Feature	Detail
Product Model	HZ-006
Color	Pink + White
Material	ABS, PC, TPE
Gear Switch	Touch Button
Power Cable Length	1m
Rated Power	6W
Package Dimensions	7.09 x 7.09 x 4.72 inches
Item Weight	1.51 Pounds



Image 9.1: Detailed dimensions of the YUYTE HZ-006 Electric Makeup Brush Cleaner.

10. Warranty and Support

This product is manufactured by YUYTE. For information regarding warranty coverage, please refer to the retailer's return policy at the point of purchase. Typically, products are eligible for return or replacement within 30 days of purchase.

For technical support or inquiries not covered in this manual, please contact the seller or manufacturer directly through their official channels. Please have your product model (HZ-006) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F442XYBZ

More documents and user manuals: **https://manuals.plus/**