

[manuals.plus](#) /

› [Milex](#) /

› [Milex Mighty Scrub 7-in-1 Cordless Cleaning Brush Instruction Manual](#)

Milex Mighty Scrub 7-in-1 (MMS101)

Milex Mighty Scrub 7-in-1 Cordless Cleaning Brush

MODEL: MMS101

Brand: Milex

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Milex Mighty Scrub 7-in-1. Retain this manual for future reference.

- **Electrical Safety:** Use only the provided Type-C charging cable and a compatible 5V 1A adapter. Do not attempt to modify the charging system.
- **Water Exposure:** The device has an IPX6 waterproof rating, meaning it can withstand strong jets of water. However, **avoid immersing the power buttons in water** to prevent damage. Do not submerge the entire unit.
- **Children and Pets:** Keep the device out of reach of children and pets. This is not a toy.
- **Storage:** Store the device in a dry, cool place when not in use.
- **Maintenance:** Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel for any repairs.
- **Brush Head Safety:** Ensure brush heads are securely attached before operation. Do not apply excessive force that could damage surfaces or the device.



45-80mins
Working Time



2.5-Hours
Type-C Quick
Charge



NOTICE: Avoid immersing the power buttons in the water



With an **IPX6 waterproof rating**, this product is designed to withstand water exposure and maintain its performance, even in demanding cleaning tasks involving wet surfaces


Image: The Milex Mighty Scrub 7-in-1 highlighting its IPX6 waterproof rating, 45-80 minutes working time, and 2.5-hour Type-C quick charge. A crucial safety note advises against immersing the power buttons in water.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Milex Mighty Scrub 7-in-1 Main Unit
- 1 x Dome Brush
- 1 x Flat Brush
- 1 x Pointed Brush
- 1 x Scouring Pad
- 1 x Sponge Attachment
- 1 x Velcro Base
- 1 x Wool Cloth
- 1 x Type-C Charging Cable (Adapter not included)

7 Replaceable Brush Heads



Velcro Base



Flat Brush



Pointed Brush



Wool Cloth



Dome Brush



Sponge Attachment



Scouring Pad



The Milex Mighty Scrub 7-in-1 tackles a variety of cleaning tasks with ease, adapting effortlessly to different surfaces with **seven interchangeable heads**

Image: A visual representation of the seven interchangeable brush heads included with the Milex Mighty Scrub 7-in-1: Flat Brush, Velcro Base, Pointed Brush, Dome Brush, Wool Cloth, Sponge Attachment, and Scouring Pad.

3. SETUP

3.1 Charging the Device

1. Locate the Type-C charging port on the main unit.
2. Connect the provided Type-C charging cable to the device.
3. Plug the other end of the cable into a compatible 5V 1A USB power adapter (not included) or a USB port.
4. The battery indicator lights will illuminate during charging. A full charge takes approximately 2.5 hours.
5. Once fully charged, the device will provide 45 to 80 minutes of working time, depending on the intensity of use.

3.2 Assembling the Handle

The Milex Mighty Scrub features an adjustable handle for various cleaning tasks.

1. To extend the handle, twist the locking collar counter-clockwise to loosen, pull the handle to the desired length

(up to 130cm), and then twist clockwise to secure.

2. To shorten the handle, twist the locking collar counter-clockwise, push the handle inwards (to 105cm or 28cm for handheld use), and twist clockwise to secure.

3.3 Attaching Brush Heads

1. Ensure the device is turned off before attaching or detaching brush heads.
2. Align the desired brush head with the rotating base of the main unit.
3. Push firmly until it clicks into place.
4. To remove, pull the brush head away from the base.



Image: The Milex Mighty Scrub 7-in-1 cordless cleaning brush fully assembled with its handle extended, ready for use.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

Press the power button located on the handle to turn the device on. Press it again to turn off.

4.2 Using the Different Brush Heads

Select the appropriate brush head for your cleaning task:

- **Flat Brush:** Ideal for large flat surfaces like floors, walls, and shower doors.
- **Dome Brush:** Suitable for curved surfaces such as bathtubs, sinks, and toilet bowls.
- **Pointed Brush:** Designed for corners, grout lines, and tight spaces.
- **Scouring Pad:** For tough stains and grime on durable surfaces.
- **Sponge Attachment:** Gentle cleaning and polishing of delicate surfaces.
- **Velcro Base with Wool Cloth:** For polishing and buffing tasks.

The Milex Mighty Scrub features a 360-degree spinning action for effective cleaning. Apply light pressure and let the brush do the work.



Image: A person using the Milex Mighty Scrub 7-in-1 to clean a kitchen floor, demonstrating its effectiveness on hard surfaces.



360°

The Milex Mighty Scrub 7-in-1 has a **360° spinning action**, delivering powerful scrubbing from every angle. Its high-speed rotation effortlessly reaches every corner

Image: A close-up view of the Milex Mighty Scrub's brush head in action, illustrating its 360-degree spinning capability for thorough cleaning.

5. MAINTENANCE

5.1 Cleaning the Main Unit

After each use, wipe the main unit with a damp cloth. Do not use abrasive cleaners or immerse the unit in water, especially near the power buttons.

5.2 Cleaning Brush Heads

Remove the brush head from the device. Rinse the brush head under running water to remove dirt and debris. For stubborn grime, use a mild soap. Allow brush heads to air dry completely before storing or reattaching.

5.3 Storage

Store the Milex Mighty Scrub 7-in-1 and its accessories in a clean, dry place, away from direct sunlight and extreme

temperatures.

6. TROUBLESHOOTING

- Device not turning on:** Ensure the device is fully charged. Check the battery indicator lights.
- Brush head not spinning:** Verify that the brush head is securely attached to the main unit. Check for any obstructions.
- Reduced performance:** The battery might be low; recharge the device. Ensure the brush head is clean and not worn out.
- Charging issues:** Ensure the Type-C cable is properly connected to both the device and the power source. Try a different compatible 5V 1A adapter.

If problems persist, please contact Milex customer support.

7. SPECIFICATIONS

Feature	Specification
Model	MMS101
Handle Material	Stainless Steel
Body Material	ABS
Battery	2500mAh, 3.7V
Charging Type	Type-C
Charging Time	Approximately 2.5 hours
Working Time	45 - 80 minutes
Waterproof Level	IPX6
Item Weight	1.5 kg
Extended Length	130 cm
Shortened Length	105 cm
Handheld Length	28 cm

7-in-1 Versatility



ABS

Body Material

**2500mAh,
3.7V**

Battery



Charging Type: C



STAINLESS STEEL

Handle Material

IPX6

Waterproof Level

**45 - 80
mins**

Working Time

Image: Key specifications of the Milex Mighty Scrub 7-in-1, including body and handle materials (ABS, Stainless Steel), battery (2500mAh, 3.7V), charging type (Type-C), waterproof level (IPX6), working time (45-80 mins), and adjustable lengths (130cm, 105cm, 28cm).





8. WARRANTY AND SUPPORT

Specific warranty information for the Milex Mighty Scrub 7-in-1 is not provided in this manual. Please refer to the product packaging or your point of purchase for warranty details.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Milex customer service through their official website or the retailer from whom you purchased the product.

Manufacturer: Milex

Related Documents - Mighty Scrub 7-in-1 (MMS101)

	<p>Milex Extended Warranty Information and Product Eligibility</p> <p>Details on Milex products eligible for extended warranties, including warranty periods, registration requirements, exclusions, and care instructions. Covers models manufactured from 2024-2025.</p>
	<p>Milex Cordless Stick Vac User Manual MYOKR-8880DC</p> <p>Comprehensive user manual for the Milex Cordless Stick Vac (Model: MYOKR-8880DC), detailing important safeguards, assembly, cleaning procedures, troubleshooting tips, and warranty information.</p>
	<p>Milex Nutri1200 Nutritional Blender Instruction Manual</p> <p>Comprehensive instruction manual for the Milex Nutri1200 Nutritional Blender, covering setup, safe operation, maintenance, and troubleshooting for optimal use.</p>
	<p>Milex Power Airfryer XXXL User Manual and Cooking Guide</p> <p>Comprehensive guide to the Milex Power Airfryer XXXL (Model MPA001), including features, safety precautions, operating instructions, cooking times, recipes, troubleshooting, and warranty information.</p>
	<p>Milex Bread Master MBM001 Instruction Manual</p> <p>Comprehensive instruction manual for the Milex Bread Master MBM001, covering operation, safety, troubleshooting, ingredients, and recipes for homemade bread. Features include multiple programs, delay timer, and fruit/nut dispenser.</p>
	<p>Milex INSTACHOP User Manual: Features, Usage, and Maintenance</p> <p>Comprehensive user manual for the Milex INSTACHOP food processor. Learn about its features, installation, usage methods, maintenance, troubleshooting, and safety guidelines for optimal performance.</p>