Motorola Edge 60 Fusion

Motorola Edge 60 Fusion 5G Smartphone User Manual

Model: Edge 60 Fusion (PB7G0009IN, PB7G0012IN)

Introduction

Welcome to your new Motorola Edge 60 Fusion 5G smartphone. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read this guide thoroughly to ensure optimal use and longevity of your smartphone.

Package Contents

The following items are typically included with your Motorola Edge 60 Fusion 5G:

- Motorola Edge 60 Fusion 5G Smartphone
- USB Type-C Cable
- 68W Fast Charger
- SIM Ejector Tool
- Quick Start Guide (This Manual)
- Safety and Regulatory Information

Device Overview

Familiarize yourself with the physical features of your Motorola Edge 60 Fusion 5G.



Image showing the Motorola Edge 60 Fusion 5G smartphone from both the front and back. The front displays the pOLED screen, while the back highlights the camera module and the device's sleek design.

Front View

- **6.67" 120Hz pOLED Display:** High-resolution, smooth display for vibrant visuals.
- **Front Camera:** For selfies and video calls.
- **Earpiece:** For audio during calls.

Rear View

- **50MP OIS Camera System:** Advanced camera for high-quality photos and videos with optical image stabilization.
- **Motorola Logo:** Brand identification.

Side and Bottom Views

- **Power Button:** To turn the device on/off or lock/unlock the screen.
- **Volume Buttons:** To adjust media and call volume.
- **USB Type-C Port:** For charging and data transfer.
- **SIM Card Tray:** For inserting Nano-SIM cards.

- **Speaker:** For audio output.
- **Microphone:** For voice input.

Initial Setup

1. Insert SIM Card

Locate the SIM card tray on the side of your device. Use the provided SIM ejector tool to open the tray. Insert your Nano-SIM card(s) into the tray with the gold contacts facing down. Ensure the tray is fully reinserted into the device to prevent dust and water ingress.

2. Power On

Press and hold the Power button located on the side of the device until the Motorola logo appears on the screen.

3. Initial Configuration

Follow the on-screen prompts to select your preferred language, connect to a Wi-Fi network, and sign in with your Google account. This process will guide you through essential settings and data transfer options.

4. Charge the Battery

For optimal performance and to ensure sufficient power for initial setup, fully charge your device using the provided 68W fast charger and USB Type-C cable before extensive use.

Operating Your Motorola Edge 60 Fusion 5G

Basic Navigation

- **Touch Gestures:** Interact with the screen using taps, swipes, and pinch-to-zoom gestures.
- **Home Screen:** Your central hub for accessing applications, widgets, and notifications. Customize it to your preference.
- **Notifications:** Swipe down from the top of the screen to view incoming notifications and access quick settings for Wi-Fi, Bluetooth, and more.

Camera Usage

Your device features a versatile 50MP OIS camera system for capturing high-quality photos and videos.



A close-up image of the Motorola Edge 60 Fusion 5G display, highlighting its key features including the 1.5K True Quad-Curved Display, Sony-LYT 700C Camera, and MIL-STD 810H military-grade durability with IP68 water resistance.

1. Open the **Camera** application from your home screen or app drawer.
2. Select your desired mode (e.g., Photo, Video, Portrait, Night Vision) from the available options.
3. Tap the shutter button to capture images or to start/stop video recording.

Connectivity

- **Wi-Fi:** To connect to wireless networks, go to **Settings > Network & internet > Wi-Fi** and select an available network.
- **Bluetooth:** To pair with other Bluetooth devices (e.g., headphones, speakers), go to **Settings > Connected devices > Bluetooth**.
- **5G Network:** Ensure your SIM card supports 5G and your mobile plan includes 5G data for access to high-speed cellular connectivity.

Device Maintenance

Cleaning Your Device

Use a soft, lint-free cloth to gently clean the screen and body of your smartphone. Avoid using abrasive materials, harsh chemicals, or aerosol sprays, as these can damage the device's finish and coatings.

Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance enhancements. You can typically find this option under **Settings > System > System updates**.

Battery Care

To prolong the lifespan and maintain the performance of your 5500 mAh battery, avoid exposing the device to extreme temperatures (very hot or very cold). The device supports 68W fast charging; use the provided

charger for optimal charging speed.

Troubleshooting Common Issues

Device Not Powering On

- Ensure the battery is sufficiently charged. Connect the charger and wait a few minutes before attempting to power on again.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

Poor Network Connectivity

- Verify that your SIM card is properly inserted into the tray.
- Restart your device to refresh network connections.
- Check your mobile data settings and ensure they are configured correctly with your service provider.

Apps Crashing or Freezing

- Close the problematic app and reopen it.
- Clear the app's cache by going to **Settings > Apps > [App Name] > Storage & cache > Clear cache**
- Ensure the app is updated to its latest version from the Google Play Store.

Technical Specifications

Feature	Detail
Model	Edge 60 Fusion (PB7G0009IN, PB7G0012IN)
Display	6.67" 120Hz pOLED
Processor	Dimensity 7030
Operating System	Android 14
Rear Camera	50MP OIS
RAM	8GB
Internal Storage	256GB
Battery Capacity	5500 mAh
Charging	68W Fast Charging
Connectivity	5G, Wi-Fi, Bluetooth, USB Type-C, GPS
Dimensions	16.12 x 7.31 x 0.82 cm
Weight	430 g
Durability	Corning Gorilla Glass 7i, IP68 Water Resistance

Important Safety Information

To ensure safe operation and prevent damage to your device, please observe the following safety guidelines:

- Do not expose the device to extreme temperatures (below -20°C or above 60°C) or direct sunlight for prolonged periods.
- Use only approved chargers, batteries, and accessories. Use of unapproved accessories may void your warranty and pose safety risks.
- Avoid disassembling, modifying, or attempting to repair the device yourself. This can lead to damage, electric shock, or fire.
- Dispose of the device and its battery responsibly according to local environmental regulations. Do not dispose of batteries in household waste.
- Maintain a safe distance from medical devices such as pacemakers when using the phone to avoid potential interference.
- Avoid using the device while driving or operating heavy machinery.

Warranty and Support

Your Motorola Edge 60 Fusion 5G is covered by a limited warranty. For detailed warranty terms, conditions, and duration, please refer to the warranty card included in your product package or visit the official Motorola support website for your region.
For further assistance, technical support, or service inquiries, please contact Motorola customer service through their official channels. Have your device's model number and serial number ready when contacting support.

© 2025 Motorola. All rights reserved.