



Manuals.plus /

› Energizer /

› Energizer UB2000 True Wireless Bluetooth Earbuds User Manual

Energizer UB2000

Energizer UB2000 True Wireless Bluetooth Earbuds User Manual

Model: UB2000

1. INTRODUCTION

Thank you for choosing the Energizer UB2000 True Wireless Bluetooth Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Energizer UB2000 True Wireless Earbuds
- Charging Case
- USB-C Charging Cable
- Ear Cushions (various sizes)
- Gel Tips
- User Manual (this document)

3. PRODUCT OVERVIEW

The Energizer UB2000 earbuds offer a seamless audio experience with advanced features. Below is an illustration of the main components:

1800mAh

Up to 40hrs

Emergency Power Reserve

+30%

Before 20%

After 50%

Provides up to 30-35% extra battery life (e.g., charges a smartphone from 20% to 50%).

*Based on device compatibility

Image: Energizer UB2000 True Wireless Earbuds and their charging case. The earbuds are shown outside the case, which features LED indicators and a USB-C port.

The charging case also functions as an emergency power reserve for your smartphone, providing additional battery life on the go.



Image: The Energizer UB2000 charging case connected via USB-C to a smartphone, illustrating its emergency power reserve capability. The image highlights 1800mAh capacity and up to 40 hours of usage.

4. SETUP

4.1 Charging the Earbuds and Case

1. **Initial Charge:** Before first use, fully charge the earbuds and charging case. Place the earbuds into the charging case.
2. **Charge Case:** Connect the provided USB-C cable to the charging port on the case and to a USB power source (e.g., wall adapter, computer USB port).
3. **LED Indicators:** The LED indicators on the charging case will illuminate to show the charging status. A full charge is indicated when all LEDs are solid.
4. **Charging Time:** A full charge typically takes approximately 2 hours.

4.2 Pairing with Your Device

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. The LED on one earbud will flash, indicating it's ready to pair.
2. **Activate Bluetooth:** On your smartphone, tablet, or laptop, enable Bluetooth.
3. **Select Device:** In your device's Bluetooth settings, search for "Energizer UB2000" and select it to connect.

4. **Confirmation:** Once successfully paired, the earbud LED will stop flashing, and you may hear an audible confirmation.
5. **Reconnect:** The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.



Stable Bluetooth Connectivity

Experience seamless audio with advanced Bluetooth technology.



IOS



Android



Windows



Allowed on Planes

Image: Energizer UB2000 earbuds and charging case with a tablet in the background, illustrating stable Bluetooth 5.3 connectivity across iOS, Android, and Windows devices, and suitability for use on planes.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Open the charging case, or press and hold the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or press and hold the touch control area on both earbuds for 5 seconds.

5.2 Touch Controls

The earbuds feature touch-sensitive controls for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold on either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.

5.3 Emergency Power Reserve

The charging case can provide emergency power to other USB-C compatible devices:

1. Connect your smartphone or other device to the USB-C output port on the charging case using a compatible USB-C to USB-C cable (not included, unless your device uses USB-C to USB-C).
2. The charging case will begin to charge your connected device.
3. This feature is designed for emergency situations and provides approximately 30-35% extra battery life for a typical smartphone.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

6.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.



IPX4 Water Resistant



Sweatproof and splashproof for everyday and workout use.

Image: Three individuals engaged in different activities (yoga, walking in rain, running) while wearing Energizer UB2000 earbuds, highlighting their IPX4 water resistance for sweatproof and splashproof use.

7. TROUBLESHOOTING

If you encounter issues with your Energizer UB2000 earbuds, refer to the following common solutions:

- **Earbuds not pairing:**

- Ensure both earbuds are charged.
- Place earbuds back in the case, close the lid, then open it again to re-enter pairing mode.
- Turn off and on Bluetooth on your device.
- Forget "Energizer UB2000" from your device's Bluetooth list and try pairing again.

- **No sound from one earbud:**

- Ensure both earbuds are charged.

- Try placing both earbuds back in the case, closing the lid, and then taking them out again.
- Reconnect the earbuds to your device.

- **Earbuds not charging:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Check if the power source is active.
- Clean the charging contacts on both the earbuds and inside the case with a dry cotton swab.

- **Poor sound quality:**

- Ensure the earbuds are properly seated in your ears. Try different sized ear tips for a better seal.
- Move closer to your connected device to avoid interference.
- Clean any debris from the earbud speakers.

8. SPECIFICATIONS

Feature	Detail
Model Name	UB2000
Connectivity Technology	Bluetooth, USB-C
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Audio Driver Type	Dynamic Driver
Audio Driver Size	6 Millimeters
Frequency Response	20 KHz
Sensitivity	42 dB
Impedance	32 Ohms
Battery Life	40 Hours (with charging case)
Charging Time	2 Hours
Control Type	Touch Control
Water Resistance Level	IPX4 (Water Resistant)
Material	Plastic
Item Weight	0.16 Kilograms (5.6 ounces)
Product Dimensions	2.07 x 2.07 x 1.02 inches (case)
Special Features	Bluetooth 5.3, Touch Control, Emergency Power Reserve

For a visual overview of product specifications, please watch the video below:

Your browser does not support the video tag.

Video: An official product video detailing the specifications and features of the Energizer UB2000 True Wireless Earbuds, including Bluetooth 5.3, IPX4 water resistance, and usage time.

9. SAFETY INFORMATION

- Do not disassemble, repair, or modify the product.
- Keep the product away from water, moisture, and extreme temperatures.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Keep out of reach of children and pets.
- Dispose of the product responsibly according to local regulations.

10. WARRANTY AND SUPPORT

Energizer products are designed for reliability and performance. For warranty information, please refer to the warranty card included in your package or visit the official Energizer website.

For technical support, troubleshooting assistance, or any inquiries regarding your Energizer UB2000 earbuds, please contact Energizer customer service through their official channels.