

Poedagar 8051-4

Poedagar Men's Automatic Mechanical Watch

Model: 8051-4

INTRODUCTION

Thank you for choosing the Poedagar Automatic Mechanical Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.

PRODUCT FEATURES

- **Automatic Mechanical Movement:** Powers with the movement of your wrist, requiring no battery.
- **Stainless Steel Construction:** High-quality stainless steel case and band for durability and a refined appearance.
- **Multifunctional Dial:** Features Roman numerals, date, day, and month displays.
- **3ATM Water Resistance:** Suitable for daily life, such as splashes or rain, but not for swimming or diving.
- **Adjustable Band:** Includes a free stainless steel band adjustment tool for a customized fit.

INNOVATIVE MULTIFUNCTIONAL CHRONOGRAPH SKELETON MECHANICAL WATCH



MONTH
DISPLAY



WEEK
DISPLAY



DAY
DISPLAY



SKELETON
TOURBILLON

Image: The watch dial showcasing its month, week, and day displays, along with the visible mechanical skeleton tourbillon.

SETUP INSTRUCTIONS

1. Initial Winding

As an automatic mechanical watch, it requires initial winding if it has stopped. To wind the watch, gently whirl the crown (the knob on the side) clockwise for 15 to 20 complete revolutions. Do not pull the crown out during this process. This will provide sufficient power to start the movement.

2. Adjusting Time and Date

1. **Time Adjustment:** Pull the crown out to the outermost position. Rotate the crown to set the hour and minute hands to the correct time. Push the crown back in to its normal position.
2. **Date/Day/Month Adjustment:** Pull the crown out to the middle position. Rotate the crown to adjust the date, day, and month displays. Some models may have additional push-buttons for specific adjustments. Refer to the watch face for specific indicators. Push the crown back in to its normal position once set.



**Butterflu
watch**

◀ **Easy to wear and open**

Image: A detailed view of the watch's crown and adjustment buttons, used for setting time and calendar functions.

3. Adjusting Band Length

Your watch comes with a stainless steel band adjustment tool. Use this tool to remove or add links to the band for a comfortable fit around your wrist. Instructions for using the tool are typically included with the tool itself. Ensure the clasp closes securely after adjustment.

OPERATING YOUR WATCH

Automatic Movement


The watch is powered by an automatic mechanical movement. This means it winds itself through the natural motion of your wrist while you wear it. If the watch is not worn for an extended period, it may stop. In such cases, manually wind it as described in the "Initial Winding" section to restart it.

Water Resistance (3ATM)

This watch is rated for 3ATM (30 meters) water resistance. This means it is suitable for daily use and can withstand splashes, rain, or brief immersion in water. However, it is **not** suitable for bathing, showering, swimming, diving, or any activities involving prolonged water exposure or high-pressure water. Avoid operating the crown or push-buttons when the watch is wet.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and smudges. For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Magnets:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, certain electronic devices) as magnetism can affect the accuracy of the mechanical movement.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures, both hot and cold, as this can impact its performance and materials.
- **Impact:** Protect the watch from strong impacts or drops, which can damage the delicate internal mechanisms.
- **Storage:** When not wearing the watch, store it in a cool, dry place, preferably in its original box or a watch case to protect it from dust and scratches.



ALLOY CASE

04

Alloy case with three-dimensional engraved dial
rich in details

Image: The transparent case back revealing the intricate mechanical movement of the watch.

TROUBLESHOOTING GUIDE

- **Watch has stopped:** If the watch has stopped, it likely needs to be wound. Manually wind the watch by rotating the crown clockwise 15-20 times. Ensure you are wearing the watch regularly for the automatic movement to function.

- **Watch is running inaccurately:** Ensure the watch has been sufficiently wound. Keep the watch away from strong magnetic fields. If the issue persists, professional servicing may be required.
- **Date/Day/Month not changing:** Manually adjust the calendar functions using the crown in its middle position. Ensure adjustments are not made between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	Poedagar
Model Number	8051-4
Movement	Automatic Mechanical
Case Material	Stainless Steel
Case Shape	Round
Case Thickness	13mm
Dial Diameter	40mm
Display Type	Analog
Band Material Type	Stainless Steel
Band Width	20mm
Band Length	24cm
Clasp Type	Push Button Hidden Clasp
Water Resistance Depth	3Bar (30M Life Waterproof)
Weight	150g

OPEN THE PARAMETER FILE



Brand: Poedagar
Length: 24.5 cm
Strap width: 1.8CM
Thickness: 1.3 cm
Strap: stainless steel
Dial diameter: 4cm
Weight: 150G
Case material: alloy
Movement: Mechanical
Waterproof: 30M life
waterproof

Note: This data is manually measured, there is a reasonable error, everything is subject to the actual product

Image: A visual representation of the watch alongside its detailed technical specifications.

WARRANTY INFORMATION

The Poedagar Automatic Mechanical Watch Model 8051-4 comes with a **Lifetime Warranty**. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for any warranty claims. For specific terms and conditions, please refer to the official Poedagar website or contact customer support.

CUSTOMER SUPPORT

For further assistance, questions, or support regarding your Poedagar watch, please visit the official Poedagar store or contact their customer service department.

[Visit the Poedagar Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F47L3KDG>

More documents and user manuals: <https://manuals.plus/>