Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

K&F CONCEPT KF13.182

K&F CONCEPT Waterproof Camera Rain Cover

Model: KF13.182

Brand: K&F CONCEPT

1. Introduction

Thank you for choosing the K&F CONCEPT Waterproof Camera Rain Cover. This manual provides essential information for the proper setup, operation, and maintenance of your new camera rain cover. Designed to protect your valuable camera and lens from adverse weather conditions such as rain, snow, and salty air, this cover ensures you can continue capturing moments outdoors without worry.



Image 1.1: The K&F CONCEPT Waterproof Camera Rain Cover in use, protecting a camera and lens from rain.

2. Product Features

- **Waterproof Protection:** Constructed from high-quality water-repellent nylon material with a waterproof zipper, providing reliable protection against rain, snow, and extreme weather.
- **Clear Viewing Window:** Features a highly transparent TPU window for an unobstructed view of your camera's screen and viewfinder. A special anti-fog coating prevents condensation, even with temperature fluctuations, and the surface is scratch and oil-resistant.
- **Secure Attachment:** An adjustable internal hook-and-loop fastener adapts to various lens sizes. Elastic straps and a non-slip leather tab at the lens base ensure a snug fit. Compatible with tripod mounts.
- **Easy Access:** Drawstring closures on both side sleeves allow for free hand movement, enabling easy operation of the camera controls.
- **Compact and Portable:** Made from lightweight, foldable nylon, it occupies minimal space, making it ideal for hiking, action photography, and demanding outdoor use.

Detalles de calidad



Cremallera impermeable bidireccional de alta calidad



Diseño de tira antideslizante



Correas de sujeción de velcro internas

Image 2.1: Detailed view of the high-quality waterproof zipper, non-slip strap, and internal hook-and-loop fasteners.

Adecuado para todo tipo de clima



Lluvia



Nieve



Arena



Exterior húmedo

Image 2.2: The rain cover is suitable for diverse weather conditions including rain, snow, sand, and general wet outdoor environments.

3. Compatibility

This rain cover is designed to accommodate a wide range of DSLR and SLR cameras, as well as drones, with attached lenses. Please verify your camera and lens dimensions against the maximum compatible size to ensure a proper fit.

- **Maximum Camera + Lens Dimensions:** 11.3 x 8.8 x 15.2 cm (Width x Height x Depth) / 4.45 x 3.46 x 5.98 inches.
- **Compatible Devices:** DSLR cameras, SLR models, and drones.

Note: Always measure your camera and attached lens before purchase to confirm compatibility.




Image 3.1: Product dimensions and maximum compatible camera size for the rain cover.

4. Setup and Installation

1. **Prepare Your Camera:** Ensure your camera and lens are clean and dry before placing them inside the cover.

2. **Position the Cover:** Slide the rain cover over your camera and lens, starting from the front of the lens.
3. **Secure the Lens:** Use the internal adjustable hook-and-loop fastener and elastic straps to secure the cover tightly around your lens barrel. The non-slip leather tab at the base of the lens port helps maintain a firm grip.
4. **Adjust for Viewfinder/Screen:** Position the transparent TPU window over your camera's screen and viewfinder for clear visibility. Ensure the viewfinder opening is aligned if you plan to use it.
5. **Hand Access:** Adjust the drawstring closures on the side sleeves to comfortably fit your hands, allowing easy access to camera controls.
6. **Tripod Compatibility:** If using a tripod, the cover is designed to allow tripod mounting without obstruction.




Image 4.1: Securing the lens port with the elastic strap and hook-and-loop fastener to prevent water ingress and ensure a snug fit.

5. Operating Instructions

Once installed, the K&F CONCEPT Waterproof Camera Rain Cover allows for continued camera operation in challenging weather conditions.

- **Viewing and Control:** Utilize the highly transparent TPU window to monitor your camera's LCD screen and viewfinder. The anti-fog coating helps maintain clarity. Insert your hands through the side sleeves to access all necessary camera buttons and dials.
- **Photography in Rain/Snow:** The waterproof design ensures your camera remains dry. Focus on your photography without concern for moisture damage.
- **Tripod Use:** The cover is designed to be used while your camera is mounted on a tripod, providing stability and protection simultaneously.



Image 5.1: Clear viewing window allows full visibility of the camera screen and viewfinder for operation.




Image 5.2: Drawstring sleeves provide easy and secure hand access for operating the camera.

6. Maintenance and Care

To ensure the longevity and effectiveness of your K&F CONCEPT Waterproof Camera Rain Cover, follow these care instructions:

- **Cleaning:** After use, especially in dirty or salty conditions, wipe the cover with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Allow the cover to air dry completely before folding and storing. Do not machine wash or tumble dry.
- **Storage:** Store the cover in a cool, dry place away from direct sunlight when not in use. Its foldable design allows for compact storage.
- **Inspection:** Periodically inspect the cover for any signs of wear, tears, or damage to the waterproof material or zippers.

7. Troubleshooting

- **Condensation on Viewing Window:** The TPU window features an anti-fog coating. If condensation still occurs in extreme temperature differences, ensure the cover is properly sealed around the lens and camera body to minimize air exchange. Allow the camera to acclimate to the ambient temperature before use if possible.
- **Difficulty Accessing Controls:** Ensure the drawstring sleeves are adjusted correctly for your hand size. Practice operating your camera with the cover on in a dry environment before using it in adverse conditions.
- **Cover Feels Loose:** Re-check the adjustable hook-and-loop fastener and elastic straps around the lens. Ensure they are tightened securely to achieve a snug fit for your specific lens diameter.

8. Specifications

Model Number	KF13.182
Material	Nylon (Water-repellent), High Transparent TPU
Color	Black
Flat Dimensions (L x W)	64 x 48 cm (25.8 x 18.9 inches)
Max. Compatible Device Size (W x H x D)	11.3 x 8.8 x 15.2 cm (4.45 x 3.46 x 5.98 inches)
Weight	Approx. 250 g
Water Resistance Level	Water Repellent

9. What's in the Box

- 1 x K&F CONCEPT Waterproof Camera Rain Cover



Image 9.1: Contents of the package, including the rain cover and packaging box.

10. Warranty and Support

K&F CONCEPT products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official K&F CONCEPT website. For technical support, product inquiries, or

assistance, please contact K&F CONCEPT customer service through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F48271FG

More documents and user manuals: **https://manuals.plus/**