

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [kensen](#) /
- › [Kensen Body Hair Trimmer User Manual](#)

**kensen 06-KTMQ32-06A**

# Kensen Body Hair Trimmer User Manual

Model: 06-KTMQ32-06A

## INTRODUCTION

---

This manual provides detailed instructions for the safe and effective use of your kensen Body Hair Trimmer. Please read this manual thoroughly before first use and retain it for future reference. This device is designed for personal grooming, offering versatile trimming and shaving capabilities for various body areas.



Image: The kensen Body Hair Trimmer, its packaging, and included accessories such as different trimmer heads and comb attachments.

## SAFETY GUIDELINES

To ensure safe operation and prevent injury or damage to the device, please adhere to the following safety precautions:

- **Water and Charging:** Avoid contact with water while the device is charging. Ensure the charging port is dry before connecting the Type-C data cable.
- **Skin Irritation:** Use caution to prevent cuts or skin irritation. Always ensure the blade is clean and properly attached. If irritation occurs, discontinue use.
- **Cleaning:** Clean the device regularly to prevent bacterial growth and maintain hygiene. Refer to the

"Cleaning and Maintenance" section for detailed instructions.

- **Storage:** Store the trimmer in a dry place, away from direct sunlight and extreme temperatures.
- **Children:** Keep the device out of reach of children.
- **Intended Use:** This device is intended for personal grooming only. Do not use it for purposes other than those described in this manual.

*Note: Statements regarding dietary supplements have not been evaluated by the FDA and are not directly related to the trimmer's function.*

## PACKAGE CONTENTS

Verify that all items listed below are included in your package:



Image: A visual representation of the complete Kensen Body Hair Trimmer kit, including the main unit, various heads, combs, charging cable, and user manual.

1. 1 x Shaped Body Shaver (Main Unit)
2. 1 x T-shaped Head Accessory Comb
3. 1 x I-shaped Shaving Head
4. 1 x I-shaped Head Accessory Comb
5. 1 x Type-C Data Cable
6. 1 x User Manual

## PRODUCT OVERVIEW & FEATURES

The kensen Body Hair Trimmer is engineered for comprehensive personal grooming with advanced features for comfort and efficiency.

### Dual-Sided Blades for Efficient Trimming

Equipped with high-quality stainless steel double-edged blades, this trimmer allows for effortless shaving in any direction, optimizing grooming time.

# Bi-directional Trimming For Efficient Shaving



Image: A detailed view of the trimmer's bi-directional blades, illustrating their ability to cut hair when moved in either direction.

## **Nut-Safe Blade for Maximum Comfort**

The trimmer features a specialized blade design with a 30-degree rotating body, engineered to minimize nicks, cuts, and pulls, providing a comfortable and safe grooming experience, particularly for sensitive areas.

# Skin Protection Blade

Multi-protection,  
Will not cut the skin,  
Gentle and non-irritating.



Image: A magnified view of the skin protection blade, highlighting the protective mesh designed to prevent direct contact with the skin.

# Skin Protection Blade

Skin-Safe Design, No Cuts or Nicks

OTHERS ❌



OURS ✅



Image: A visual comparison demonstrating the Kensen trimmer's skin-safe design, contrasting it with a conventional trimmer that may cause irritation.

## 2-in-1 Electric Trimmer with Multiple Heads

This versatile grooming kit includes two interchangeable trimmer heads and two adjustable comb attachments, allowing seamless switching to cater to various grooming needs across the face, arms, chest, legs, and other body areas.

# For Your Full Body Hair Grooming Needs



Image: An illustration of the trimmer's modular design, showcasing how different heads can be attached for specific grooming tasks on various body regions.

## Powerful Motor with Low Noise Technology

Equipped with a robust 6800RPM ultra-quiet motor, the trimmer ensures efficient, low-vibration performance, effectively managing various hair types for a smooth grooming process.

## IPX6 Waterproof Design

The IPX6 waterproof rating allows for both wet and dry use, making it suitable for use in the shower. This feature simplifies cleaning and offers flexibility in your grooming routine.

# IPX6 Waterproof

Shave Anywhere,  
Anytime




Image: A man demonstrating the trimmer's waterproof capability by using it in the shower, alongside an inset image of the device being rinsed under running water.

## **Long Battery Life & USB-C Charging**

The integrated 600mAh large-capacity battery provides up to 100 minutes of runtime on a full charge. The device charges via a convenient USB-C port, making it ideal for travel.

# Long Battery Life

Single Charge =  
100-120 Minutes of use




Image: An illustration of the trimmer's USB-C charging port and its LED screen displaying battery life, emphasizing its long operational time per charge.

## GETTING STARTED (SETUP)

1. **Initial Charge:** Before first use, fully charge the trimmer. Connect the Type-C data cable to the trimmer's charging port and plug the other end into a compatible USB power adapter (not included). The LED screen will indicate charging status.
2. **Attaching Trimmer Heads:** To attach a trimmer head, align the head with the main unit and gently push until it clicks into place. To remove, hold the main unit firmly and pull the head away.
3. **Attaching Comb Attachments:** Slide the desired comb attachment onto the trimmer head until it

securely locks. Ensure it is firmly in place before use.

## OPERATING INSTRUCTIONS

Follow these steps for optimal grooming results:

### General Use

- **Power On/Off:** Press the power button to turn the trimmer on or off.
- **Dry Use:** For dry shaving, ensure skin is clean and dry.
- **Wet Use:** For wet shaving, you may use shaving foam or gel. The trimmer is IPX6 waterproof and can be used in the shower.

### Trimming Different Body Regions

The kensen trimmer is suitable for various body areas, including facial beard, armpit hair, chest hair, back hair, pubic hair, and leg hair.




Image: A composite image demonstrating the trimmer's versatility across various body regions, including facial hair, armpit, chest, back, pubic area, and legs.

- **For Longer Hair:** Use the T-shaped head accessory comb for initial trimming of longer hair.
- **For Shorter Hair/Close Shave:** Use the I-shaped shaving head for a closer shave or to trim shorter hair.
- **Sensitive Areas:** For sensitive areas, ensure the Nut-Safe blade is used. Stretch the skin taut and move the trimmer slowly against the direction of hair growth.

### Adjusting Hair Length

The trimmer offers adjustable comb attachments for precise length control.

# DIY Beard Shapes In 20 Lengths




Image: A detailed view of the adjustable comb attachment, showing the dial for selecting various trimming lengths in millimeters.

- **T-shaped Head Accessory Comb:** Can be adjusted for lengths of 3mm, 6mm, and 9mm.
- **I-shaped Head Accessory Comb:** Allows for length adjustments from 1mm to 10mm.
- Rotate the dial on the comb attachment to select your desired hair length.

## CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your trimmer.

1. **After Each Use:** Turn off the trimmer. Remove the trimmer head. Rinse the blades and comb

attachments under running water.

2. **Drying:** Shake off excess water and allow all parts to air dry completely before reattaching or storing. Do not use cloths or abrasive materials on the blades.
3. **Main Unit:** Wipe the main unit with a damp cloth. Do not submerge the main unit in water unless specifically designed for full immersion (this model is IPX6, meaning it can withstand powerful water jets, but avoid prolonged submersion of the charging port area).
4. **Lubrication:** Periodically apply a small drop of clipper oil (not included) to the blades to maintain smooth operation.
5. **Storage:** Store the trimmer and its accessories in a clean, dry place, preferably in its original packaging or a protective pouch.

## TROUBLESHOOTING

If you encounter any issues with your kensen Body Hair Trimmer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully using the provided USB-C cable.
Trimmer pulls hair or cuts poorly.	Blades are dull or clogged with hair.	Clean the blades thoroughly. If blades are dull, consider replacement (contact customer support).
Excessive vibration or noise.	Hair caught in the motor or blade assembly.	Turn off and disassemble the trimmer head. Remove any trapped hair. Reassemble securely.
Charging indicator not working.	Cable or power adapter issue.	Try a different USB-C cable or power adapter. Ensure the charging port is clean and dry.

If the problem persists after attempting these solutions, please contact kensen customer support for further assistance.

## TECHNICAL SPECIFICATIONS

Specification	Detail
Model Number	06-KTMQ32-06A
Power Source	Battery Powered
Battery Type	Rechargeable (Internal 600mAh)
Battery Capacity	600mAh (approx. 100-120 minutes runtime)
Motor Speed	6800 RPM
Waterproof Rating	IPX6
Special Feature	Cordless, Travel Lock Function
Dimensions (Package)	7.72 x 5.16 x 1.77 inches

Specification	Detail
Weight (Package)	9.7 ounces
Manufacturer	kensen

## WARRANTY AND SUPPORT

kensen is committed to providing high-quality products and excellent customer service.

- **Warranty:** Your kensen Body Hair Trimmer is covered by a **12-month replacement warranty**.
- **Lifetime Service:** kensen offers lifetime service for this product.
- **Customer Support:** For any inquiries, issues, or warranty claims, please contact kensen customer support. Our after-sales service team aims to provide a response within **12 hours**.
- **Contact Information:** Please refer to the contact details provided on the product packaging or the official kensen website for the most up-to-date support information.



Images: Visuals indicating the 12-month replacement warranty, lifetime service, and 12-hour quick reply customer support.

© 2025 kensen. All rights reserved.

For more information, visit the [kensen Store](#).