

Feihe SR-16P

Feihe 15.6-inch Portable TV User Manual

Model: SR-16P | Brand: Feihe

INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Feihe 15.6-inch Portable TV (Model SR-16P). Please read this manual thoroughly before using the product to ensure proper function and to maximize your viewing experience. Keep this manual for future reference.

WHAT'S IN THE BOX

Carefully unpack the box and ensure all items listed below are present and in good condition. If any items are missing or damaged, please contact customer support.

- Portable TV (1 unit)
- Remote Control (1 unit)
- AC Adapter (1 unit)
- Car Charger Adapter (1 unit)
- AV Cable (3-in-1 male, 1 unit)
- Antenna (1 unit)
- User Manual (1 unit)



Figure 1: Contents of the Feihe 15.6-inch Portable TV package.

PRODUCT OVERVIEW

The Feihe 15.6-inch Portable TV is designed for versatile entertainment. It features a high-definition display and multiple connectivity options.

Controls and Ports

Familiarize yourself with the TV's controls and connection ports:

- **Top/Side Controls:** OK, VOL+, VOL-, CH+, CH-, MENU, SOURCE buttons for basic operation.
- **Rear/Side Ports:**
 - **TV Antenna Jack:** For connecting the included antenna or an external antenna.
 - **USB Port:** For connecting USB devices (e.g., USB drives for media playback, or for antenna power).
 - **HDMI Input:** For connecting external high-definition devices like TV sticks, gaming consoles, or laptops.
 - **AV Input:** For connecting older devices using the included 3-in-1 AV cable.
 - **DC IN:** Power input for the AC adapter or car charger adapter.
 - **Headphone Jack:** For private listening.




Figure 2: Feihe 15.6-inch Portable TV controls and ports.

SETUP

1. Power Connection

The TV can be powered using either the AC adapter for home use or the car charger adapter for portable use.

- **AC Adapter:** Connect the AC adapter to the DC IN port on the TV and plug the other end into a standard wall outlet.
- **Car Charger Adapter:** Connect the car charger adapter to the DC IN port on the TV and plug the other end into your vehicle's 12V power socket.

Note: This TV does not have a built-in battery and requires an external power source to operate.



Figure 3: Power supply options for the Feihe Portable TV.

2. Antenna Connection

To receive local free-to-air channels, connect the included antenna to the TV Antenna Jack. If the antenna requires power, connect its USB cable to the TV's USB port simultaneously.

Important: TV signal coverage varies by location. For stronger signals or more channels, a stronger outdoor antenna may be required.



Figure 4: Connecting the antenna and ensuring USB power for the antenna.

3. Remote Control

Insert two AAA batteries (not included) into the remote control. Ensure the remote control is aligned with the

TV's infrared receiver for optimal operation. The optimal distance for operation is within 9.8 feet (3 meters).

4. TV Placement

The TV features a built-in steel stand for easy placement on any flat surface. The stand is collapsible and adjustable, allowing you to set the viewing angle as desired. For wall mounting, ensure appropriate mounting hardware (not included) is used and the TV is securely fastened.

WHY CHOOSE OUR SMALL PORTABLE TV	OUR (HD Screen)	OTHERS (General Image)
Screen Size	15.6 inch	✗
Resolution	1080p HD	✗
Features	Portable & Handheld Lightweight Design	✗
Compatibility	Fire Stick, Roku, Apple tv, Chromecast, PC, Gaming Consoles, DVD Player	✗

Figure 5: Using the collapsible kickstand for flexible TV placement.

OPERATING INSTRUCTIONS

1. Turning On/Off

Press the **POWER** button on the remote control or the TV's side panel to turn the TV on or off.

2. Initial Setup and Channel Scan

Upon first use, the TV may guide you through an initial setup process. Follow the on-screen prompts to select your language and perform an automatic channel scan. The built-in digital tuner supports ATSC digital TV and NTSC analog TV.

- Press **MENU** on the remote.
- Navigate to the 'Channel' or 'Setup' menu.
- Select 'Auto Scan' or 'Auto Tuning' to search for available channels.

3. Connecting External Devices

The TV offers HDMI, USB, and AV ports for connecting various devices.

- **HDMI:** Connect a TV stick, gaming console, DVD player, or laptop to the HDMI port using an HDMI cable. Press the **SOURCE** button on the remote or TV to select the HDMI input.
- **USB:** Insert a USB flash drive into the USB port to play compatible media files (photos, music, videos). Press the **SOURCE** button to select the USB input.
- **AV:** Use the included 3-in-1 AV cable to connect older devices like VCRs or some DVD players. Connect the yellow, white, and red plugs to the corresponding output jacks on your device, and the single plug to the TV's AV input. Press the **SOURCE** button to select the AV input.

4. Adjusting Settings

Use the **MENU** button on the remote to access various settings:

- **Picture Settings:** Adjust brightness, contrast, color, and aspect ratio (16:9).
- **Sound Settings:** Adjust volume, bass, treble, and select sound modes. The TV has built-in speakers for clear audio.
- **Time Settings:** Set the current time and configure sleep timers.
- **System Settings:** Access language options, factory reset, and software information.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your TV.

- **Cleaning:** Use a soft, dry cloth to clean the screen and exterior. For stubborn marks, lightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Ventilation:** Ensure the TV's ventilation openings are not blocked to prevent overheating.
- **Storage:** When not in use for extended periods, store the TV in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Power:** Disconnect the power adapter from the wall outlet during thunderstorms or when leaving the TV unattended for long periods.

TROUBLESHOOTING

If you encounter issues with your Feihe Portable TV, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power adapter not connected; outlet not working.	Ensure power adapter is securely connected to TV and a working power outlet. Check if the power outlet has power.
No signal / Poor picture quality (Antenna)	Antenna not connected; weak signal; channel scan not performed.	Ensure antenna is properly connected. Perform a channel scan. Adjust antenna position. Consider a stronger outdoor antenna if local signal is weak. Ensure antenna USB power is connected if required.
No picture (HDMI/AV)	Incorrect input source selected; cable not connected properly.	Press SOURCE to select the correct input (HDMI or AV). Ensure the HDMI/AV cable is securely connected to both the TV and the external device.
No sound	Volume too low or muted; external device sound settings.	Increase volume. Check if TV is muted. If using an external device, check its volume and audio output settings.
Remote control not working	Dead batteries; obstruction; incorrect alignment.	Replace batteries. Ensure no obstructions between remote and TV. Point remote directly at the TV's IR receiver.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Below are the technical specifications for the Feihe 15.6-inch Portable TV (Model SR-16P):

- **Model Number:** SR-16P
- **Screen Size:** 15.6 Inches
- **Display Technology:** LCD
- **Resolution:** 1080p
- **Refresh Rate:** 60 Hz
- **Aspect Ratio:** 16:9
- **Connectivity:** HDMI, USB, AV
- **Tuner:** Built-in ATSC Digital TV / NTSC Analog TV
- **Special Features:** Built-In Speaker, Flat, Portable, Sleep Timer
- **Power Input:** 12V DC (via AC adapter or car charger adapter)
- **Voltage:** 240 Volts (AC)
- **Wattage:** 12 watts
- **Product Dimensions:** 1.4"D x 14.7"W x 9.3"H (3.56 cm D x 37.34 cm W x 23.62 cm H)
- **Item Weight:** 4.05 pounds (1.84 kg)

WARRANTY AND SUPPORT

Feihe products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or contact Feihe customer support.

Customer Support

If you require assistance, have questions, or need to report an issue, please contact Feihe customer support through the retailer where you purchased the product or visit the official Feihe website for contact details.