

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Edvivi](#) /
- › [Edvivi Outdoor Wall Sconce EW682S-BK Instruction Manual](#)

Edvivi EW682S-BK

Edvivi Outdoor Wall Sconce EW682S-BK Instruction Manual

Model: EW682S-BK

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Edvivi Outdoor Wall Sconce, Model EW682S-BK. This fixture is designed to illuminate outdoor spaces such as porches, patios, garages, and entryways. It features a matte black finish, clear glass panels, and an integrated dusk-to-dawn sensor for automatic operation. Please read this manual thoroughly before installation and retain it for future reference.



Image 1.1: The Edvivi Outdoor Wall Sconce (Model EW682S-BK) installed on an exterior brick wall.

2. SAFETY INFORMATION

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installing or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This fixture is intended for outdoor use and is waterproof. However, ensure all connections are properly sealed during installation to maintain water resistance.
- Do not install this fixture on a wet surface.
- Use only E26 medium base bulbs, maximum 60 watts. Do not exceed the recommended wattage.
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture when in operation.

3. PACKAGE CONTENTS

Carefully unpack your fixture and check that all parts are included.

- 1 x Edvivi Outdoor Wall Sconce (Model EW682S-BK)
- 1 x Mounting Hardware Kit (includes mounting bracket, screws, wire nuts)
- 1 x Instruction Manual

Note: An E26 medium base bulb (max 60W) is **not included** and must be purchased separately.

4. SPECIFICATIONS

| | |
|-------------------------------|--|
| Model Number | EW682S-BK |
| Brand | Edvivi |
| Dimensions (L x W x H) | 5" x 6" x 16" |
| Material | Metal, Glass |
| Finish | Matte Black |
| Shade Color | Clear |
| Bulb Base | E26 Medium |
| Max Wattage | 60 Watts |
| Voltage | 120 Volts |
| Special Features | Dusk-to-Dawn Sensor, Waterproof, Anti-Rust |
| Indoor/Outdoor Usage | Outdoor |
| Certification | ETL Listed |



Image 4.1: Product dimensions and bulb type information.

5. INSTALLATION INSTRUCTIONS

Important: Professional installation is recommended. Ensure power is disconnected at the circuit breaker before beginning installation.

Tools Required (Not Included):

- Screwdriver (Phillips and/or Flathead)
- Wire Strippers

- Electrical Tape
- Safety Glasses
- Ladder (if necessary)

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's location and turn it OFF. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** If replacing an existing fixture, carefully remove it. Ensure the junction box is securely mounted and accessible.
3. **Attach Mounting Bracket:** Secure the provided mounting bracket to the junction box using the screws from the hardware kit. Ensure the bracket is level and firmly attached.
4. **Make Electrical Connections:**
 - Connect the **black** wire from the fixture to the **black** (hot) wire from the junction box using a wire nut.
 - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box using a wire nut.
 - Connect the **ground** wire (bare copper or green) from the fixture to the **ground** wire from the junction box and to the mounting bracket using a wire nut or ground screw.
 - Ensure all wire nuts are securely tightened and connections are insulated with electrical tape if desired.
5. **Mount the Fixture:** Carefully align the fixture with the mounting bracket and secure it using the provided screws. Ensure the fixture is flush against the wall and stable.
6. **Install Bulb:** Insert one E26 medium base bulb (max 60W, not included) into the socket. Do not overtighten.
7. **Restore Power:** Turn the power back ON at the circuit breaker.



Image 5.1: Close-up of the E26 medium base bulb socket.

6. OPERATING INSTRUCTIONS

The Edvivi Outdoor Wall Sconce features a built-in dusk-to-dawn sensor for automatic operation.

- **Automatic On/Off:** The integrated sensor detects ambient light levels. The fixture will automatically turn ON when it gets dark (dusk) and turn OFF when it becomes light (dawn).
- **Sensor Placement:** Ensure the sensor is not obstructed by objects, eaves, or other light sources (e.g., other bright lights, streetlights) that could interfere with its operation.
- **First Use:** After installation and restoring power, the light may take a few moments to calibrate or may turn on briefly before turning off if it is daytime.

Dusk to Dawn Sensor



Image 6.1: Illustration of the dusk-to-dawn sensor functionality.

7. MAINTENANCE

- **Cleaning:** To clean the fixture, ensure power is off. Wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or glass.
- **Bulb Replacement:**

- a. Turn off power at the circuit breaker.
- b. Allow the old bulb to cool completely before touching.
- c. Carefully unscrew the old bulb from the E26 socket.
- d. Screw in a new E26 medium base bulb (max 60W).
- e. Restore power at the circuit breaker.

- **Inspection:** Periodically inspect the fixture for any signs of damage, loose connections, or wear. Address any issues promptly.

8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------------|---|---|
| Light does not turn on. | <ul style="list-style-type: none"> ◦ Power is off at the circuit breaker. ◦ Bulb is faulty or not installed correctly. ◦ Loose wiring connection. ◦ Sensor is detecting too much light. | <ul style="list-style-type: none"> ◦ Check circuit breaker and turn on power. ◦ Replace bulb or ensure it is screwed in properly. ◦ Turn off power, check wiring connections, and re-secure. ◦ Ensure sensor is not obstructed or exposed to other light sources. |
| Light stays on during the day. | <ul style="list-style-type: none"> ◦ Sensor is obstructed or dirty. ◦ Sensor is faulty. | <ul style="list-style-type: none"> ◦ Clean the sensor. Remove any obstructions. ◦ Contact customer support if the issue persists after cleaning and checking for obstructions. |
| Light flickers. | <ul style="list-style-type: none"> ◦ Loose bulb or wiring connection. ◦ Faulty bulb. | <ul style="list-style-type: none"> ◦ Turn off power, check bulb and wiring connections. ◦ Replace bulb. |

9. WARRANTY AND SUPPORT

This Edvivi product is covered by a **1-year manufacturer's limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, accident, misuse, abuse, or unauthorized modifications.

For warranty claims or technical support, please contact Edvivi customer service through the retailer where the product was purchased or visit the official Edvivi website. Please have your model number (EW682S-BK) and proof of purchase available.

Edvivi Lighting

[Visit the Edvivi Store on Amazon](#)

