

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [kaitol](#) /

> kaitol 6QT Air Fryer & Multi-Cooker Combo Instruction Manual

kaitol 12QT

kaitol 6QT Air Fryer & Multi-Cooker Combo Instruction Manual

Model: 12QT

1. INTRODUCTION

Welcome to the kaitol family! This manual provides essential information for the safe and efficient operation of your new 6QT Air Fryer & Multi-Cooker Combo. Please read all instructions carefully before use and retain this manual for future reference. This versatile appliance combines 12 cooking functions into one compact unit, designed to simplify your cooking experience.

2. PRODUCT OVERVIEW

The kaitol 6QT Air Fryer & Multi-Cooker Combo is a 12-in-1 kitchen appliance that allows you to air fry, grill, boil, steam, sauté, bake, stew, and cook rice, noodles, congee, and hot pot. It features a detachable air frying basket and a deep cooking pot, offering flexibility for various culinary tasks.

Key Features

- **12-in-1 Versatile Cooking Functions:** Air fry, grill, boil, steam, sauté, bake, stew, rice cooker, noodles, congee, and hot pot.
- **Switch Between Air Frying & Boiling:** Equipped with a detachable air frying basket and a deep cooking pot.
- **Large 6L Capacity:** Ideal for families or gatherings.
- **Intuitive Touch Panel:** Features 12 smart presets for one-touch cooking.
- **Easy to Clean:** Non-stick, detachable parts are dishwasher-safe.
- **Safety Features:** Overheat protection and cool-touch handles.

REPLACE 6 APPLIANCES IN 1

Unlock more cooking possibility

One Pot=



Air Fryer



Deep Fryer



Rice & Grain Cooker



Hot Pot/Soup Maker



Stir-Fry & Sauté Pan



Bakes Cakes



Figure 1: The kaito 6QT Air Fryer & Multi-Cooker Combo showcasing its air frying and hot pot modes.




Figure 2: Examples of meals prepared with the multi-cooker, highlighting its versatility.

3. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The appliance features overheat protection; it will automatically shut off if the temperature exceeds 464°F.
- The cooking process will automatically pause if the lid is removed during operation.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off",

then remove plug from wall outlet.

- Do not use appliance for other than intended use.

4. INITIAL SETUP

Unpacking and Assembly

- Carefully remove all packaging materials and place the appliance on a flat, stable surface.
- Wash the glass pot, air fry basket, and other accessories with hot water, dish soap, or a soft cloth. Rinse thoroughly and dry.
- Ensure all parts are completely dry before assembly and use.



Figure 3: All included components for the kaito 6QT Air Fryer & Multi-Cooker Combo.

Assembling for Different Modes

The appliance can be configured for either air frying or multi-cooking (hot pot, rice cooker, steamer) by interchanging the main cooking vessels.

Your browser does not support the video tag.

Video 1: Demonstrates how to switch the appliance between air fryer and hot pot modes by changing the cooking vessel.

5. OPERATING YOUR APPLIANCE

Control Panel Overview

The appliance features an intuitive touch control panel with a digital display. The panel includes various preset icons for different food types and cooking functions, along with time and temperature adjustment buttons.



Figure 4: Detailed view of the digital touch control panel with preset icons and adjustment buttons.

Selecting Cooking Modes and Presets

- After connecting the power, the display screen will light up.
- Press the 'Function Select' button to cycle through the 12 available presets (e.g., Fries, Cake, Meat, Chicken Wings, Grilled Fish, Hot Pot, Boil Congee).
- Each preset has a default time and temperature setting.

Adjusting Time and Temperature

- After selecting a preset, you can manually adjust the cooking time using the '+' and '-' buttons.
- To adjust the temperature, press the 'Time/Temp' button and then use the '+' and '-' buttons to change the temperature.
- Press the 'Start/Stop' button to begin or pause the cooking process.

6. COOKING GUIDE

The kaitol 6QT Air Fryer & Multi-Cooker Combo offers a wide range of cooking possibilities. Here are some general guidelines:

Air Frying

- Use the air fry basket for crispy results with minimal oil.
- Ideal for chicken wings, potato wedges, fries, and other frozen snacks.
- The air fry function uses 400°F rapid air circulation.
- For best results, shake the basket halfway through cooking for even crisping.

Multi-Cooking Functions

- Use the deep cooking pot for boiling soups, noodles, and congee.
- The ceramic pot evenly heats for perfect rice, congee, or shabu-shabu hot pot.
- Explore presets for baking cakes, stewing, and sautéing.



Figure 5: A selection of dishes that can be prepared using the appliance's various functions.

7. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your kaitol appliance. Always unplug the unit and allow it to cool completely before cleaning.

Cleaning Instructions

- **Removable Parts:** The non-stick deep pot, air fry basket, and other detachable accessories are dishwasher-safe for convenient cleaning.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- For stubborn residue, soak the removable parts in warm, soapy water before scrubbing gently with a non-abrasive sponge.



Figure 6: The non-stick pot is easy to clean by hand or in a dishwasher.

EVERYTHING INCLUDED



Figure 7: Detachable components are dishwasher-safe for hassle-free cleaning.

8. TROUBLESHOOTING

If you encounter any issues with your kaitol appliance, please refer to the following common problems and solutions:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the lid is properly seated; the appliance has an auto-pause safety feature that prevents operation if the lid is not correctly in place.
- **Food not cooking evenly:** Ensure the food is spread in a single layer in the basket/pot. For air frying, shake the basket halfway through cooking. Adjust cooking time or temperature as needed.
- **Appliance stops unexpectedly:** Check if the lid was removed during operation (auto-pause feature). If the appliance overheats, it will automatically shut off as a safety measure. Allow it to cool down before restarting.
- **Smoke or unusual odor:** Ensure the appliance is clean and free of food debris or grease buildup. If cooking high-fat foods, a small amount of smoke is normal.

9. PRODUCT SPECIFICATIONS

Specification	Value
---------------	-------

Brand	kaitol
Model Name	12QT
Capacity	6 Quarts
Output Wattage	1800 Watts
Voltage	110 Volts
Control Method	Touch
Material	Non-stick
Product Dimensions	15.16"D x 12.4"W x 5"H
Item Weight	7 Pounds
Min Temperature Setting	100 Degrees Fahrenheit
Max Temperature Setting	400 Degrees Fahrenheit
Is Dishwasher Safe	Yes (detachable parts)

10. WARRANTY AND CUSTOMER SUPPORT

kaitol products are designed for durability and reliability. For warranty information or customer support, please refer to the contact details provided at the time of purchase or visit the official kaitol website. Our customer service team is available to assist you with any questions or concerns regarding your appliance.