

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [boAt](#) /

› [boAt Stone 110 Bluetooth Speaker User Manual](#)

**boAt Stone 110**

# boAt Stone 110 Bluetooth Speaker User Manual

Model: Stone 110 | Brand: boAt

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your boAt Stone 110 Bluetooth Speaker. Please read this manual thoroughly before operating the device and retain it for future reference.



Image: The boAt Stone 110 Bluetooth Speaker in Groovy Grey, showcasing its compact design and front grille.

## PACKAGE CONTENTS

Ensure all items are present in the package:

- boAt Stone 110 Bluetooth Speaker
- Charging Cable
- User Manual

## PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Image: A collage illustrating the boAt Stone 110's main features: 3W Signature Sound, up to 15 hours of playtime, TWS for 2X power, and IPX4 sweat & splash resistance.

## Controls and Ports

- **Power Button:** Press and hold to turn the speaker on or off.
- **Volume Up (+):** Increase volume.
- **Volume Down (-):** Decrease volume.
- **Play/Pause/Call Button:** Play/pause music, answer/end calls.
- **Mode Button:** Switch between Bluetooth and AUX modes.
- **Microphone:** For hands-free calling and voice assistant.
- **USB Charging Port:** For charging the speaker.
- **AUX Port:** For wired audio connection.

## SETUP

### 1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's USB charging port and the other end to a USB power adapter (not included) or a computer's USB port.

- The LED indicator will show charging status.
- A full charge provides up to 15 hours of playtime.



Image: A person holding the compact boAt Stone 110 speaker, illustrating its portability and ease of handling.

## 2. Power On/Off

Press and hold the Power button for a few seconds until you hear an audible prompt and the LED indicator lights up.

- To power off, press and hold the Power button again.

## 3. Bluetooth Pairing

1. Turn on the boAt Stone 110 speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED.
2. Enable Bluetooth on your smartphone, tablet, or other device.
3. Search for "boAt Stone 110" in the list of available Bluetooth devices.
4. Select "boAt Stone 110" to connect. Once connected, the LED indicator will stop flashing and remain solid.
5. You can now play audio wirelessly through the speaker.

## 4. AUX Connection

For devices without Bluetooth, use the AUX port:

1. Connect one end of a 3.5mm audio cable (not included) to the speaker's AUX port.
2. Connect the other end to the audio output jack of your device.
3. The speaker will automatically switch to AUX mode, or you may need to press the Mode button.

## 5. True Wireless Stereo (TWS) Pairing

Pair two boAt Stone 110 speakers for a stereo audio experience:



Image: Two boAt Stone 110 speakers positioned to illustrate their TWS pairing capability, providing enhanced audio output.

1. Ensure both boAt Stone 110 speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the Play/Pause button for a few seconds until you hear a TWS pairing prompt.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a confirmation tone.
4. Now, connect your device to the primary speaker via Bluetooth as described in step 3. Audio will play in stereo through both speakers.

## OPERATING INSTRUCTIONS

### Music Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

### Hands-Free Calling




Image: An illustration detailing the speaker's multi-compatibility with Bluetooth v5.4 and AUX, its built-in microphone for hands-free calls, and support for voice assistants like Siri and Google Assistant.

- **Answer Call:** Press the Play/Pause button once when a call comes in.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.

### Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant) through the speaker:

- **Activate:** Double-press the Play/Pause button.

## MAINTENANCE

### Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port cover is securely closed to maintain IPX4 resistance.



Image: The boAt Stone 110 speaker with water droplets on its surface, illustrating its IPX4 rating for sweat and splash resistance.

### Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to maintain its lifespan.

## TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Speaker does not turn on.	Ensure the speaker is charged. Connect it to a power source and try again.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (flashing LED). Make sure Bluetooth is enabled on your device. Move the speaker closer to your device. Forget "boAt Stone 110" from your device's Bluetooth list and try pairing again.
No sound.	Check the volume levels on both the speaker and your connected device. Ensure the speaker is correctly paired or connected via AUX. Try playing a different audio source.
TWS pairing fails.	Ensure both speakers are powered on and not connected to any other device. Place speakers close to each other. Repeat the TWS pairing steps carefully.

## SPECIFICATIONS

Feature	Detail
Model Name	Stone 110
Brand	boAt
Speaker Type	Bluetooth Speaker
Connectivity Technology	Bluetooth v5.4, AUX
Speaker Output Power	3 Watts
Audio Driver Type	Dynamic Driver
Audio Output Mode	Stereo (with TWS pairing)
Battery Life	Up to 15 Hours
Battery Type	Lithium Ion (1 x 12V included)
Water Resistance	IPX4 (Sweat & Splash Resistant)
Built-in Microphone	Yes (for Hands-free Calling)
Voice Assistant Support	Yes
Product Dimensions	13D x 5W x 9H Centimeters
Item Weight	200 Grams
Country of Origin	India

## SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not attempt to disassemble or repair the speaker yourself. This will void the warranty.
- Keep the speaker away from water sources, despite its splash resistance. Do not submerge it.
- Use only the provided charging cable or a certified equivalent.
- Dispose of the product responsibly according to local regulations.

## WARRANTY AND SUPPORT

The boAt Stone 110 Bluetooth Speaker comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, warranty claims, or any other inquiries, please visit the official boAt website or contact their customer service department. Contact details can typically be found on the product packaging or the official brand website.

You can also visit the [boAt Store on Amazon](#) for more information.