

MOVE SPEED Z70Pro

MOVE SPEED 2025 Upgrade Power Bank 70,000mAh 100W & 35W PD Fast Charger with Type C Retractable Cable

Brand: MOVE SPEED | Model: Z70Pro

1. INTRODUCTION

Thank you for choosing the MOVE SPEED Z70Pro Power Bank. This device is designed to provide reliable and high-speed portable charging for a wide range of electronic devices, including smartphones, tablets, and laptops. With its massive 70,000mAh capacity, 100W Power Delivery (PD) output, and integrated 35W fast charger with a retractable Type-C cable, it offers unparalleled convenience and power for your daily needs and outdoor adventures.

Please read this manual carefully before using the product to ensure safe and optimal performance. Keep this manual for future reference.

2. SAFETY INFORMATION

- Do not expose the power bank to extreme temperatures (above 60°C/140°F or below -10°C/14°F), direct sunlight, or fire.
- Do not immerse the power bank in water or expose it to rain or moisture.
- Do not disassemble, repair, or modify the device yourself. Refer all servicing to qualified personnel.
- Keep the power bank away from children.
- Use only the provided or certified charging cables and adapters.
- Avoid dropping or subjecting the power bank to strong impacts.
- If the power bank swells, emits an odor, or becomes excessively hot, discontinue use immediately and contact customer support.
- Dispose of the power bank according to local regulations. Do not dispose of it with household waste.

3. PACKAGE CONTENTS

Please check the package for the following items:

- MOVE SPEED Z70Pro Power Bank (70,000mAh)
- 35W PD Fast Charger with Retractable Type-C Cable

- USB-C to USB-C Charging Cable
- User Manual



Figure 3.1: Package Contents Overview. The image displays the MOVE SPEED Z70Pro Power Bank, a white 35W wall charger with a retractable Type-C cable, and two separate USB-C to USB-C charging cables.

4. PRODUCT FEATURES

- **70,000mAh High Capacity:** Provides extensive power, capable of fully charging an iPhone 14 approximately 16 times or a MacBook Pro 14" multiple times. Ideal for extended travel and outdoor use.
- **100W Super Fast Charging (PD3.0 & QC3.0):** Equipped with a powerful 100W Power Delivery output, allowing rapid charging of laptops and other high-power devices. Charges a MacBook Pro 14" to 50% in just 35 minutes.
- **Integrated 35W Super-Fast Charger:** Features a built-in 35W wall charger with a retractable Type-C cable for convenient and fast recharging of the power bank itself or other devices. Charges an iPhone 16 Pro Max to 65% in 30 minutes.

- **Multi-Device Charging:** Supports simultaneous charging of multiple devices.
- **Emergency LED Light:** Includes an integrated LED light with four modes (High, Medium, Low, SOS) for illumination in various situations.
- **Smart Display:** Digital display shows remaining battery percentage and charging status.



Figure 4.1: Key Features of the Z70Pro Power Bank. The image shows the power bank with its side LED light illuminated, placed on a wooden table in an outdoor camping scene, emphasizing its large capacity and fast charging capabilities.

5. SETUP

5.1 Initial Charging of the Power Bank

Before first use, it is recommended to fully charge your MOVE SPEED Z70Pro Power Bank.

1. Locate the integrated 35W PD Fast Charger on the side of the power bank.
2. Extend the retractable Type-C cable from the charger.

3. Plug the 35W charger directly into a standard wall outlet.
4. The digital display on the power bank will show the charging progress. A full charge from empty takes approximately 5 hours.



Figure 5.1: Extending the Retractable Cable. This image illustrates how the integrated Type-C cable extends from the 35W wall charger for convenient use.

65% in 30 Mins, Always Ready

Next-gen dual-core GaN tech, 35W low-temp fast charging.



Figure 5.2: 35W GaN Charger Technology. This image highlights the compact design and advanced GaN technology of the integrated 35W charger.

6. OPERATING INSTRUCTIONS

6.1 Charging Your Devices

The MOVE SPEED Z70Pro Power Bank offers multiple output ports for charging various devices simultaneously.

1. **Using the 100W PD Output:** For laptops, tablets, and other high-power devices, use a compatible USB-C to USB-C cable (one is included) and connect it to the 100W PD output port on the power bank and your device. This port supports up to 100W fast charging.
2. **Using the 35W Output (Retractable Cable):** For smartphones and other devices compatible with Type-C, simply extend the integrated retractable Type-C cable from the 35W charger and plug it into your device. This port supports up to 35W fast charging.

3. **Using Other USB Ports:** The power bank also features additional USB-A and USB-C ports for charging other devices. Connect your device's charging cable to the appropriate port.
4. The digital display will indicate when a device is connected and charging.



High Speed 100W Power Delivery

Rapidly recharge your Phone, MacBook, or Samsung to 70% in just 20 minutes.

30% → 20min → 70%

100w

The image shows a black rectangular power bank with a digital display and various ports. A hand is holding a gold iPhone connected to the power bank. The power bank has a large '100w' text and a diagram showing a battery icon increasing from 30% to 70% in 20 minutes.

Figure 6.1: High-Speed 100W Power Delivery. This image illustrates the rapid charging capability of the 100W output, showing a phone charging from 30% to 70% in 20 minutes.

Multi-Protocol Fast Charging Certified

Powers Phones, Tablets, and Computers
Supports Multiple Fast charging Protocols for iPhone and Android Phones



Figure 6.2: Multi-Protocol Fast Charging. This image demonstrates the versatility of the charger, capable of powering phones, tablets, and computers with various fast charging protocols.

6.2 Using the Emergency LED Light

The Z70Pro Power Bank includes a built-in LED light for emergency situations or general illumination.

1. To turn on the LED light, locate the power button (or dedicated light button, if present) on the power bank and press it briefly.
2. Subsequent brief presses will cycle through the light modes: High, Medium, Low, and SOS (Morse code for distress).
3. To turn off the LED light, continue pressing the button until the light turns off, or press and hold the button for a few seconds.



Figure 6.3: Emergency Light with 4 Modes. This image displays the power bank's LED light functioning in an outdoor setting, illustrating its different brightness levels and SOS signal.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, charge the power bank to about 50-70% capacity every 3 months to prolong battery life.
- **Cable Care:** Ensure the retractable cable is fully retracted when not in use to prevent damage. Avoid bending or twisting cables excessively.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Charger not properly connected; faulty cable/adapter; power bank battery depleted.	Ensure charger is securely plugged into outlet and power bank. Try a different cable or adapter. Allow power bank to charge for a few minutes.
Device not charging from power bank	Power bank battery depleted; incompatible cable; device not properly connected; device requires more power than available.	Recharge the power bank. Ensure the cable is securely connected to both the power bank and the device. Use a compatible cable. Check if your device's power requirements exceed the power bank's output.
Slow charging	Using a non-fast charging port/cable; device not supporting fast charging protocol; multiple devices charging simultaneously.	Ensure you are using the 100W PD or 35W output ports with compatible cables. Verify your device supports the fast charging protocols (PD, QC). Charging multiple devices may reduce individual charging speeds.
LED light not working	Power bank battery low; incorrect operation.	Recharge the power bank. Refer to section 6.2 for correct operation of the LED light.

9. SPECIFICATIONS

Feature	Detail
Model	Z70Pro
Capacity	70,000mAh / 259Wh
Input (for Power Bank Charging)	35W (via integrated charger)
Output 1 (USB-C PD)	Up to 100W Power Delivery
Output 2 (Integrated Type-C Cable)	Up to 35W Fast Charging
Other Display Features	Wireless (as per product specifications, though not explicitly detailed in features)
ASIN	B0F48NPMKJ
Date First Available	April 9, 2025

Neat Desk, Instantly!



Figure 9.1: Compact Size of the 35W Charger. This image highlights the small footprint of the integrated 35W charger, allowing it to fit easily on power strips.




10. WARRANTY AND SUPPORT

MOVE SPEED products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or any product-related inquiries, please contact MOVE SPEED customer service through the retailer where you purchased the product or visit the official MOVE SPEED website.

Please have your product model (Z70Pro) and ASIN (B0F48NPMKJ) ready when contacting support.

For more information, you may visit the [MOVE SPEED Store on Amazon](#).

Related Documents - Z70Pro

	<p>MOVE SPEED S80 80,000mAh 130W Portable Power Station User Guide</p> <p>Comprehensive user guide for the MOVE SPEED S80 portable power station. Learn how to use its 80,000mAh capacity, 130W output, digital display, USB-C ports, and solar charging capabilities for camping, laptops, and emergency backup.</p>
	<p>MOVE SPEED MoveSpeedDrivePro USB Flash Drive User Manual</p> <p>User manual for the MOVE SPEED MoveSpeedDrivePro USB flash drive. This guide covers PC software download and installation, setting up AES256 and fingerprint encryption, data backup procedures, and restoring factory settings. Features USB3.2, Type C, and 520MB/s speeds.</p>
	<p>Move Speed Drive User Guide: Backup, Encryption, and Fingerprint Features</p> <p>A comprehensive guide to the Move Speed Drive, detailing how to use its software for data backup, phone backup, restore operations, and security features like password and fingerprint encryption.</p>
	<p>MOVESPEED M25 Energy Planet 130W 25000mAh Portable Power Bank User Manual</p> <p>User manual for the MOVESPEED M25 Energy Planet portable power bank, detailing its 130W fast charging, 25000mAh capacity, USB-C PD3.0 capabilities, and smart LED display for charging laptops, smartphones, and other devices.</p>
	<p>MOVESPEED YSPBQ10 Power Bank User's Guide</p> <p>Comprehensive user guide for the MOVESPEED YSPBQ10 Power Bank, detailing technical specifications, charging instructions, power display, safety cautions, environmental claims, and warranty information for optimal use and maintenance.</p>
	<p>MOVESPEED USB Solid State Drive User Guide and Warranty Information</p> <p>Comprehensive user guide for MOVESPEED USB 3.2 Solid State Drives. Learn about plug-and-play setup, high-speed connectivity, safe data handling, warranty policies, and environmental compliance.</p>