

[Manuals.plus](#) /

› [Dpofirs](#) /

› Dpofirs USB Volume Control Knob for PC (Model: Dpofirs283d6fstgc) User Manual

Dpofirs Dpofirs283d6fstgc

Dpofirs USB Volume Control Knob for PC User Manual

Model: Dpofirs283d6fstgc

1. INTRODUCTION

This manual provides detailed instructions for the Dpofirs USB Volume Control Knob. This device offers convenient and precise control over your computer's audio output, featuring a 360-degree rotatable knob and a one-key mute function. It is designed for plug-and-play operation across various operating systems.



Image: The Dpofirs USB Volume Control Knob, showcasing its design and connectivity.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x Dpofirs USB Volume Control Knob
- 1 x Storage Bag



Image: The USB Volume Control Knob with its braided USB cable and a brown storage bag.

3. SETUP

The Dpofirs USB Volume Control Knob is designed for simple plug-and-play functionality, requiring no driver installation.

1. Connect the USB cable from the volume control knob to an available USB port on your computer or compatible device.
2. The device will be automatically recognized by your operating system.
3. A blue LED indicator light on the knob will illuminate, indicating it is powered on and ready for use.

Note: Some mobile devices like smartphones and tablets may require a USB adapter (not included) for connection.

Plug and Play, No Drivers Needed




Image: The USB Volume Control Knob connected to a computer, demonstrating its plug-and-play nature without the need for drivers.

4. OPERATING INSTRUCTIONS

The USB Volume Control Knob provides intuitive control over your audio.

4.1. Volume Adjustment

- **Rotate the knob clockwise:** Increases the system volume.
- **Rotate the knob counter-clockwise:** Decreases the system volume.



Quickly Adjust the Volume

Image: A user's hand operating the USB Volume Control Knob on a desk next to a keyboard, demonstrating quick volume adjustment.

Aluminum Alloy Shell



Image: A visual representation of the knob's 360-degree rotation capability for volume control.

4.2. Mute/Pause Function

- **Press the knob once:** Toggles mute/unmute for audio playback. This also functions as a play/pause button for media.
- **Press and hold the knob for 8 seconds:** This action is used to reset or change the key function, though specific alternative functions are not detailed.

4.3. Track Navigation

- **Press and hold the knob while rotating:** Skips to the previous or next track in media playback.

ONE KEY MUTE FUNCTION

Just press the knob, it will stop at once and back to music when you press it again. Rotate the knob to quickly adjust the computer volume.



Image: A graphic detailing the functions: rotating for volume, pressing for mute/pause, and pressing while rotating for track navigation.

How to Use



Image: A simplified diagram showing the three main operations: rotate to adjust volume, press to mute/unmute or play/pause, and press and rotate for previous/next song.

5. FEATURES

- **360-Degree Rotatable Knob:** Allows for precise and smooth volume adjustments.
- **One-Key Mute/Pause:** Instant control over audio playback.
- **Durable Construction:** Made from aluminum alloy, providing a sturdy and anti-scratch shell.
- **Non-Slip Base:** Equipped with a wide silicone base to ensure stability on any surface during use.
- **Blue LED Indicator:** Provides visual feedback on the device's operational status.
- **Plug and Play:** No drivers required for most compatible operating systems.



Image: A breakdown of key features: metal shell for durability, USB plug and play functionality, and a non-slip mat for stability.

6. COMPATIBILITY

The Dpofirs USB Volume Control Knob is compatible with a wide range of devices and operating systems:

- **Operating Systems:** Windows 7, 8, 10, 11, Vista; macOS; Android.
- **Applications:** PC, Laptop, Speakers, Sound Systems, Mobile Phones, Tablets.

7. MAINTENANCE

To ensure the longevity and optimal performance of your USB Volume Control Knob, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the knob. Avoid using abrasive cleaners or solvents, which may damage the finish.
- **Storage:** When not in use, store the knob in the provided storage bag to protect it from dust and scratches.
- **Handling:** Avoid dropping the device or subjecting it to strong impacts.

8. TROUBLESHOOTING

If you encounter issues with your USB Volume Control Knob, please refer to the following common solutions:

- **Device not recognized:**
 - Ensure the USB cable is securely connected to both the knob and the computer/device.
 - Try connecting the knob to a different USB port.
 - Restart your computer/device.
 - For smartphones/tablets, ensure you are using a compatible USB adapter.
- **No audio control:**
 - Verify that the blue LED indicator light is on.
 - Check your computer's audio settings to ensure the correct output device is selected.

- Ensure the system volume is not at its minimum or muted by other software.

- **Knob feels loose or unresponsive:**

- Ensure the knob is clean and free of debris.
- If the issue persists, contact customer support.

9. SPECIFICATIONS

Attribute	Value
Item Type	USB Volume Control Knob
Material	Aluminum Alloy
Color	Black
Cable Length	Approx. 183cm / 72in
Interface	USB
Compatibility	Windows 7/8/10/11/Vista, macOS, Android
Product Dimensions	5.12 x 3.94 x 1.57 inches (approx. 13 x 10 x 4 cm)
Item Weight	4.4 ounces (approx. 125 grams)
Model Number	Dpofirs283d6fstgc

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's return policy or contact Dpofirs customer service directly through their official channels. Keep your purchase receipt for warranty claims. For further assistance, visit the [Dpofirs Store on Amazon](#).