Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- BlackSmith /
- > BlackSmith 6 Large Gun Safe User Manual

BlackSmith 6 Large Gun Safe

BlackSmith 6 Large Gun Safe User Manual

Model: 6 Large Gun Safe for Rifles and Pistols

IMPORTANT SAFETY INFORMATION

Please read this manual thoroughly before operating your BlackSmith Gun Safe. Failure to follow these instructions may result in injury, damage to the safe, or unauthorized access.

- · Always store firearms unloaded and secured within the safe.
- Keep the safe's keys and access codes in a secure location, away from the safe and out of reach of children and unauthorized individuals.
- · Never share your access code with unauthorized persons.
- Ensure the safe is properly mounted to prevent tipping or unauthorized removal.
- Do not store flammable materials or explosives inside the safe.

PACKAGE CONTENTS

Verify that all items are present in the package:

- BlackSmith 6 Large Gun Safe
- Emergency Keys (2)
- Mounting Hardware (Bolts, Washers)
- User Manual (This Document)
- Removable 3-Slot Rifle Racks (2)
- Pistol Pockets (2)
- Gun Magazine Organizers (2)

PRODUCT OVERVIEW

The BlackSmith 6 Large Gun Safe is designed for secure storage of rifles, pistols, and ammunition. It features

a robust 16-gauge alloy steel construction, a sophisticated 10-digit keypad, and an interactive LCD display for enhanced security and user convenience.



Image Description: A comprehensive view of the BlackSmith 6 Large Gun Safe. The left side shows the safe's exterior, highlighting the 10-digit electronic keypad with an LCD display and a traditional key lock. The right side displays the safe's interior, revealing organized storage for multiple rifles, two pistol pockets, and two gun magazine organizers. At the top of the interior, a separate, smaller lockbox is visible for additional secure storage of valuables. Insets show close-ups of the keypad displaying 'OPEN', the interior of the top lockbox, and the automatic LED lighting strip inside the main compartment.

Key Components:

- 10-Digit Security Keypad: For primary access with customizable codes.
- Interactive LCD Display: Provides status updates and prompts.
- Emergency Key Lock: Provides backup access in case of battery failure or forgotten code.
- **Separate Lockbox:** An internal, independently lockable compartment for small valuables.
- Removable Rifle Racks: Two 3-slot racks to securely hold rifles.
- **Pistol Pockets & Magazine Organizers:** Integrated storage on the door for handguns and ammunition magazines.
- Automatic LED Lighting: Illuminates the interior when the door is opened.
- Type-C Port: For emergency power supply if batteries are depleted.

SETUP

1. Unpacking

- 1. Carefully remove the safe from its packaging.
- 2. Inspect the safe for any signs of damage. If damaged, contact customer support immediately.
- 3. Retain packaging materials for future transport or returns.

2. Battery Installation

The keypad requires 4 AA batteries (not included) for operation.

- 1. Locate the battery compartment on the back of the keypad.
- 2. Open the compartment cover.
- 3. Insert 4 new AA alkaline batteries, ensuring correct polarity (+/-).
- 4. Close the battery compartment cover securely.

3. Initial Access (Using Emergency Keys)

For first-time access or if batteries are dead, use the emergency key:

- 1. Locate the emergency keyhole, usually hidden behind a small cover on the keypad.
- 2. Insert one of the provided emergency keys and turn it clockwise.
- 3. While holding the key turned, rotate the handle to open the safe door.

4. Setting/Changing Passcode

It is highly recommended to set your personal passcode immediately after initial access.

- 1. With the safe door open, press the internal reset button (usually a small red button located on the inside of the door or near the hinge). The LCD display will show 'SET'.
- 2. Enter your desired 6-10 digit passcode on the keypad.
- 3. Press the '#' key to confirm. The LCD will display 'DONE'.
- 4. Test the new passcode with the door open to ensure it works correctly before closing the safe.

5. Wall Mounting

The safe features pre-drilled holes for secure wall mounting.

- 1. Choose a suitable location for mounting, preferably a solid wall stud or concrete wall.
- 2. Mark the drilling points through the pre-drilled holes at the back of the safe.
- 3. Drill pilot holes using an appropriate drill bit for your wall type.
- 4. Align the safe with the drilled holes and secure it using the provided mounting hardware. Ensure all bolts are tightened securely.

6. Interior Configuration

Customize the interior to suit your storage needs:

- Install the two removable 3-slot rifle racks into the designated slots.
- Utilize the two pistol pockets and two gun magazine organizers located on the inside of the door for handguns and ammunition.
- The separate lockbox at the top can be used for smaller, high-value items.

OPERATION

1. Opening the Safe (Keypad)

- 1. Enter your 6-10 digit passcode on the keypad.
- 2. Press the '#' key. The LCD will display 'OPEN'.
- 3. Within 5 seconds, rotate the handle clockwise to open the door.

2. Opening the Safe (Emergency Key)

Follow the steps outlined in 'Setup - Initial Access (Using Emergency Keys)' if keypad access is not possible.

3. Using the Separate Lockbox

The internal lockbox has its own key lock. Use the smaller key provided to open and close this compartment.

4. Automatic LED Lighting

The interior LED light will automatically illuminate when the safe door is opened, providing visibility in low-light conditions.

5. Alarm System and Mute Mode

- Alarm Trigger: The alarm will activate after 3 consecutive failed password attempts or if the safe experiences strong vibration.
- Alarm Deactivation: Enter the correct passcode or use the emergency key to stop the alarm.
- **Mute Mode:** To operate the keypad silently, press the '*' key before entering your passcode. The keypad tones will be muted for that operation.

6. Emergency Power (Type-C Port)

If the internal batteries are depleted, connect a Type-C USB cable to the port on the keypad and a power source (e.g., power bank) to temporarily power the keypad for access.

MAINTENANCE

- **Cleaning:** Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners. The interior carpeted surfaces can be vacuumed gently.
- Battery Replacement: Replace batteries annually or when the low battery indicator appears on the LCD display. Always use new, high-quality AA alkaline batteries.
- Lock Mechanism: Do not lubricate the lock mechanism. If it becomes stiff, contact customer support.
- Mounting Check: Periodically check the mounting bolts to ensure they remain tight and secure.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|---|---|
| Keypad not responding / LCD blank | Dead batteries; Incorrect battery installation. | Replace batteries; Check battery polarity; Use emergency key or Type-C emergency power. |

| Problem | Possible Cause | Solution |
|-----------------------------------|---|---|
| Safe won't open with correct code | Code not confirmed with '#'; Handle not turned within 5 seconds; Lock mechanism jammed. | Ensure '#' is pressed after code; Turn handle promptly; Use emergency key; Contact support if jammed. |
| Alarm sounds unexpectedly | Vibration detected; Multiple incorrect code entries. | Enter correct code to disarm; Avoid strong impacts to the safe. |
| Door does not close properly | Obstruction; Misalignment. | Check for items blocking the door; Ensure safe is on a level surface or properly mounted. |

SPECIFICATIONS

| Feature | Detail |
|---------------------------------------|--|
| Brand | BlackSmith |
| Model | 6 Large Gun Safe |
| Exterior Dimensions (H x W x D) | 57" x 13.8" x 11.8" (144.78 cm x 35.05 cm x 29.97 cm) |
| Material | 16-Gauge Alloy Steel |
| Color | Black |
| Locking Mechanism | Electronic Keypad (10-digit), Emergency Key |
| Special Features | Durable construction, Interactive LCD display, Automatic LED lighting, Alarm system, Mute mode, Type-C emergency power port, Separate lockbox, Removable rifle racks, Pistol pockets, Magazine organizers. |
| Mounting Type | Wall Mount (pre-drilled holes) |

WARRANTY INFORMATION

BlackSmith products are manufactured to high-quality standards. This product comes with a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the warranty card included with your product or visit the official BlackSmith website.

CUSTOMER SUPPORT

If you have any questions, require assistance, or encounter issues with your BlackSmith Gun Safe, please do not hesitate to contact our customer support team.

• Website: Visit the BlackSmith official website for FAQs and support resources.

- Email: Refer to your product packaging or warranty card for customer service email.
- **Phone:** Refer to your product packaging or warranty card for customer service phone number.

When contacting support, please have your product model and purchase information ready.

© 2024 BlackSmith. All rights reserved.


Related Documents - 6 Large Gun Safe

| | Blacksmith Rifle Safe User Manual - 6 Long Gun Capacity User manual for the Blacksmith Rifle Safe, featuring a 6-gun capacity, digital keypad, and separate lockbox. Includes safety instructions, product overview, specifications, operating instructions, troubleshooting, and warranty information. |
|---|--|
| USER MANUAL WAS A MANUAL WAS A MANUAL AND | Blacksmith GR1201 Series 12 Long Gun Wall-mounted Rifle Racks User Manual Detailed user manual for the Blacksmith GR1201 Series 12 Long Gun Wall-mounted Rifle Racks. This guide provides step-by-step instructions for installation on various wall types, including wooden panel, gypsum, and brick walls, along with safety usage tips. |
| | Blacksmith SKUK32269-SE0103 Gun Safe User Manual User manual for the Blacksmith SKUK32269-SE0103 gun safe, detailing features, operating instructions, installation, troubleshooting, and warranty information. |
| | Blacksmith Gun Safe Basic-SE0104/SE0106 User Manual and Operating Instructions Comprehensive user manual for Blacksmith Basic-SE0104 and Basic-SE0106 gun safes, covering installation, operation, security features, troubleshooting, and safety guidelines. |



Blacksmith SF0201 Bedside Pistol Safe User Manual

Comprehensive user guide for the Blacksmith SF0201 bedside pistol safe, detailing setup, fingerprint access, security features, and maintenance for optimal security.



Blacksmith Indoor Gun Racks UWR-MB10 User Manual

Comprehensive user manual for the Blacksmith UWR-MB10 Indoor Gun Rack. Provides detailed information on parts, installation, maintenance, precautions, and frequently asked questions for safe and effective firearm storage.