

[Manuals.plus](#) /

› [Eurolux](#) /

› Eurolux Electric Citrus Juicer Stainless Steel Instruction Manual

Eurolux ELCJ-4800

Eurolux Electric Citrus Juicer Stainless Steel Instruction Manual

Model: ELCJ-4800

INTRODUCTION

Thank you for choosing the Eurolux Electric Citrus Juicer. This premium hands-free, one-touch juicer is designed for efficient and quiet operation, making fresh juice from oranges, lemons, and limes a simple task. Please read this manual thoroughly before use to ensure safe and optimal performance of your appliance.



Image: The Eurolux Electric Citrus Juicer in action, extracting juice from an orange into a glass.

PRODUCT FEATURES

- **Quiet & Powerful Performance:** Equipped with a 300W motor running at 110 RPM for high-efficiency citrus extraction with minimal noise.

- **One-Touch Operation:** Simple single-button design for effortless juicing.
- **Compact & Stylish Design:** Sleek stainless steel body with a space-saving footprint (approx. 8.66"D x 7.48"W x 12.48"H) that complements modern kitchens.
- **Easy to Clean Design:** All detachable parts are rinse-friendly for hassle-free cleanup. The main unit can be wiped down with a damp cloth.
- **Safe & Durable Build:** Features secure part locking, rest interval protection, and BPA-free components. A stable base prevents movement during operation.
- **Universal Cone:** Designed to extract juice from small limes to large grapefruits effortlessly.
- **Anti-Drip Spout:** Prevents mess and waste, ensuring clean countertops.

COMPONENTS OVERVIEW

Familiarize yourself with the parts of your Eurolux Citrus Juicer:

1. **Motor Base:** The main power unit.
2. **Juice Tray:** Collects the extracted juice.
3. **Filter Cone:** Sits inside the juice tray to separate pulp and seeds from the juice.
4. **Reamer:** The rotating part that extracts juice from the fruit.
5. **Cover:** Secures the fruit during juicing and helps apply pressure.
6. **Juice Spout:** Dispenses the juice. Features an anti-drip stopper.



Image: All detachable components of the juicer laid out for easy identification.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash all detachable parts (juice tray, filter cone, reamer, cover) with warm, soapy water before first use. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.

3. **Assemble Juice Tray:** Place the juice tray onto the motor base. Twist it clockwise until it locks securely into place (you may hear a click).
4. **Insert Filter Cone:** Place the filter cone into the juice tray, ensuring it sits properly over the reamer.
5. **Attach Cover:** Place the cover on top of the filter cone and juice tray assembly.
6. **Position:** Place the assembled juicer on a stable, flat, and dry surface.
7. **Plug In:** Connect the power cord to a standard 110V AC electrical outlet. The power button will illuminate.

OPERATING INSTRUCTIONS

1. **Prepare Fruit:** Cut your citrus fruit (oranges, lemons, limes, grapefruits) in half.
2. **Place Fruit:** Place one half of the cut fruit onto the reamer, cut-side down.
3. **Close Cover:** Lower the cover over the fruit.
4. **Start Juicing:** Press the power button. The motor will activate, and the reamer will begin to rotate, extracting juice. Apply gentle downward pressure on the cover to ensure maximum juice extraction. The reamer will auto-reverse to ensure thorough juicing.
5. **Collect Juice:** Ensure the anti-drip juice spout is open (downward position) and a glass or container is placed underneath to collect the fresh juice.
6. **Repeat:** Continue with remaining fruit halves until desired amount of juice is obtained.
7. **Stop Juicing:** Release pressure from the cover and press the power button to turn off the juicer.
8. **Close Spout:** Lift the anti-drip juice spout to prevent any remaining drips.



Image: Freshly squeezed juice flowing from the juicer's spout into a glass.

CLEANING & MAINTENANCE

Regular cleaning ensures the longevity and hygiene of your juicer.

1. **Unplug:** Always unplug the juicer from the power outlet before cleaning.

- 2. **Disassemble:** Remove the cover, filter cone, and juice tray from the motor base.
- 3. **Rinse Detachable Parts:** Rinse the cover, filter cone, and juice tray under warm running water immediately after use to prevent pulp from drying. Use a soft brush if necessary to remove any stubborn pulp. These parts are rinse-friendly.
- 4. **Clean Motor Base:** Wipe the motor base with a soft, damp cloth. **Do not immerse the motor base in water or any other liquid.**
- 5. **Dry:** Ensure all parts are completely dry before reassembling or storing.
- 6. **Storage:** Store the juicer in a clean, dry place.

Note: While some parts may be labeled as "Dishwasher Safe" in general product descriptions, for optimal care and longevity, hand-washing detachable parts is recommended. The main unit is NOT dishwasher safe.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; power outlet issue; improper assembly.	Ensure unit is securely plugged into a working outlet. Check if juice tray is correctly locked onto the motor base.
Motor stops during juicing.	Overheating due to continuous use; excessive pressure on fruit.	Allow unit to cool down for 15-20 minutes. Reduce pressure applied to the fruit.
Low juice yield.	Insufficient pressure; fruit not ripe; reamer not properly engaged.	Apply consistent, gentle pressure. Use ripe fruit. Ensure filter cone and reamer are correctly assembled.
Juice leaks from base.	Juice tray not properly locked; spout not closed.	Ensure juice tray is securely twisted and locked onto the motor base. Check that the anti-drip spout is in the closed (upward) position when not dispensing.

SPECIFICATIONS

Brand: Eurolux

Model Name: ELCJ-4800

Color: Stainless Steel

Product Dimensions: Approx. 8.66" (D) x 7.48" (W) x 12.48" (H)

Maximum Power: 300 Watts

Power Source: Corded Electric

Voltage: 110 Volts (AC)

Blade Material: Stainless Steel

Item Weight: 4.38 pounds

UPC: 042796148009

Country of Origin: China

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Eurolux customer service directly. Contact details can typically be found on the official Eurolux website or on the product packaging.

Website: [Visit the Eurolux Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The plastic base that transfers juice to the spout is facing the wrong way on my Eurolux ELCJ-4800 juicer. How do I detach the base?

To detach the plastic juice tray (the base that transfers juice to the spout) from your Eurolux ELCJ-4800, follow these steps based on the manual's assembly and disassembly instructions: Unplug the Unit: Always ensure the...

[Read full answer](#)

I cannot get the juice holder to separate from the base unit on my Eurolux ELCJ-4800 juicer. Does it take a tool to do this?

No, you should not need any tools like pliers to separate the juice tray (juice holder) from the motor base. Using tools could damage the plastic components or the locking mechanism. According to the Eurolux...

[Read full answer](#)