

[Manuals.plus](#) /

› [BoxWave](#) /

› BoxWave Wall Charger Direct (15W) User Manual

BoxWave Wall Charger Direct (15W)

BoxWave Wall Charger Direct (15W) Instruction Manual

Model: Wall Charger Direct (15W)

INTRODUCTION

This manual provides essential information for the safe and efficient use of your BoxWave Wall Charger Direct (15W). This USB Type-C specific power adapter is designed to provide rapid charging for compatible devices, such as the Marbero Power Station M60, with its built-in 6-foot cable.

SETUP

Follow these steps to set up your BoxWave Wall Charger Direct:

1. **Unpack the Charger:** Carefully remove the Wall Charger Direct from its packaging. Inspect the charger and cable for any visible damage.
2. **Identify the USB Type-C Connector:** The charger features a built-in USB Type-C cable. Ensure your device has a compatible USB Type-C charging port.
3. **Connect to Power Outlet:** Plug the AC prongs of the Wall Charger Direct into a standard wall power outlet (100-240V, 50/60Hz).
4. **Connect to Device:** Insert the USB Type-C connector firmly into the charging port of your Marbero Power Station M60 or other compatible device.



Image: The BoxWave Wall Charger Direct (left) with its built-in USB-C cable, shown alongside a Marbero Power Station M60 (right), illustrating the intended use.

OPERATING INSTRUCTIONS

The BoxWave Wall Charger Direct is designed for simple and efficient operation:

- **Automatic Charging:** Once connected to a power outlet and your device, the charger will automatically begin delivering 15W of power to your device.
- **Rapid Charge Capability:** This charger is engineered for rapid charging, allowing your device to charge quickly and efficiently.
- **Built-in 6ft Cable:** The integrated 6-foot cable provides ample length for flexible placement of your device while charging, reducing the need for extension cords.



15W Fast Charging



Image: A smartphone connected to the BoxWave Wall Charger Direct, illustrating the 15W fast charging capability.

Free to Move

Wall Charger Direct features a generous 6ft length, allowing for freedom to use your devices anywhere without worry.



Image: The BoxWave Wall Charger Direct plugged into a wall, demonstrating the extended reach of its 6-foot built-in cable for flexible device placement.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your charger:

- **Cleaning:** Disconnect the charger from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the charger in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable.
- **Cable Care:** The charger features reinforced strain relief at the connector to prevent kinking and tearing. Avoid sharp bends or excessive pulling on the cable.
- **Inspection:** Periodically inspect the charger and cable for any signs of wear, cuts, or damage. If damage is observed, discontinue use immediately.



Reinforced Strain Relief

Rubberized connector supports keep Wall Charger Direct from kinking and tearing.



Image: A detailed view of the USB-C connector, showcasing the reinforced strain relief designed to prevent cable damage.

TROUBLESHOOTING

If you encounter issues with your BoxWave Wall Charger Direct, refer to the following common solutions:

Problem	Possible Cause	Solution
Device not charging.	Charger not properly plugged into outlet; device not properly connected; faulty outlet; device issue.	Ensure charger is fully inserted into a working wall outlet. Verify the USB Type-C connector is securely plugged into your device. Try a different outlet. Test the charger with another compatible device if possible.
Slow charging.	Device drawing less power; background apps on device; cable damage.	Ensure your device is capable of 15W charging. Close unnecessary background applications on your device. Inspect the cable for damage.

Problem	Possible Cause	Solution
Charger feels warm.	Normal operation during charging; excessive load.	It is normal for chargers to become slightly warm during operation. If the charger becomes excessively hot or emits smoke/odor, immediately unplug it and discontinue use.

SPECIFICATIONS

- **Model:** Wall Charger Direct (15W)
- **Input:** 100-240V ~ 50/60Hz, 0.55A Max
- **Output:** 5V === 3000mA (15W)
- **Connector Type:** USB Type-C (built-in cable)
- **Cable Length:** 6 feet (approx. 1.8 meters)
- **Material:** Polycarbonate
- **Item Weight:** 3.3 ounces (approx. 93.5 grams)
- **Manufacturer:** BoxWave
- **Country of Origin:** China

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation included with your purchase or visit the official BoxWave website. Limited third-party technical support for your device (up to 3 inquiries via messaging) may be available, as noted in the product description. Please note that BoxWave is not affiliated with or endorsed by Marbero.