

viquee S25U

viquee S25 Ultra Cell Phone User Manual

Model: S25U

Brand: viquee

1. INTRODUCTION

Welcome to the user manual for your new viquee S25 Ultra Cell Phone. This smartphone is designed to provide a comprehensive mobile experience with advanced features and robust performance. It operates on Android 15.0 and supports 5G connectivity, ensuring fast and reliable communication.

Key features include a large 6.9-inch display, 8GB of RAM and 256GB of internal storage, a powerful 8000mAh battery for extended use, and a versatile camera system with 72MP front and 108MP rear cameras. The device also comes with a built-in tool pen for enhanced productivity and creativity, along with advanced security features like face recognition and screen fingerprint unlock.



Figure 1.1: The vivo S25 Ultra Cell Phone in Rose Gold, showcasing its sleek design, multi-camera setup on the rear, and the vibrant

2. GETTING STARTED: SETUP

2.1. Package Contents

Before you begin, please ensure all items are present in your package:

- viquee S25 Ultra Cell Phone
- USB Cable
- Built-in Tool Pen
- Quick Start Guide (not included in this manual)

2.2. Inserting SIM Cards and Charging

1. Locate the SIM card tray on the side of your phone.
2. Use the provided SIM ejector tool (if included) to open the tray.
3. Carefully place your Nano-SIM cards (up to two) into the designated slots. Ensure the gold contacts face downwards.
4. Gently push the tray back into the phone until it clicks into place.
5. Connect the USB cable to the phone's charging port and the other end to a power adapter. Plug the adapter into a wall outlet to fully charge the device before first use.

8000mAh Battery

Equipped with an 8000mAh high-capacity battery and our own power-saving technology




Figure 2.1: The viqee S25 Ultra Cell Phone showing its charging status, indicating the large 8000mAh battery capacity.

2.3. Powering On and Initial Setup

- Press and hold the Power button (usually on the right side) until the viqee logo appears.
- Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
- You will also be guided through setting up security features such as face recognition and fingerprint unlock during this process.

3. OPERATING YOUR S25 ULTRA

3.1. Navigation and Display

The S25 Ultra features a large 6.9-inch FHD Super-V Display with a resolution of 1440*3040 pixels, offering an immersive visual experience. Navigate using touch gestures: tap, swipe, pinch-to-zoom.



Figure 3.1: The phone's large 6.9-inch display, ideal for media consumption and detailed viewing.

3.2. Using the Built-in Tool Pen

The integrated tool pen allows for precise interaction with your device. Simply pull out the pen from its slot to activate pen-specific features. Use it for note-taking, drawing, precise navigation, or quick selections.



Figure 3.2: Demonstrating the use of the built-in tool pen for drawing and precise input.

3.3. Camera Functions

Your S25 Ultra is equipped with a 72MP front camera and a 108MP rear camera, enhanced with a 200MP sensor and Adaptive Pixel Technology for optimized performance in various lighting conditions. Open the Camera app to capture photos and videos. Explore different modes like Portrait, Night, and Pro for enhanced photography.

3.4. Storage and Performance

With 8GB of RAM and 256GB of internal storage, the S25 Ultra provides ample space for apps, photos, and media, ensuring smooth multitasking and fast loading times. The device is powered by a Mediatek Dimensity 1100 CPU model, providing efficient performance.

8+256GB Flash memory

8GB of memory and 256GB storage space, ensuring smooth loading of screens, common game process resident in the background, quickly switch to other applications in seconds and are not afraid of being killed even if hung up for a long time.



Figure 3.3: Illustration of the phone's 8GB RAM and 256GB internal storage, ensuring smooth operation.

3.5. Security Features

The S25 Ultra offers advanced security options to protect your data:

- **Face Recognition:** Unlock your phone quickly and securely using your face. The zero-light face recognition works even in dark environments.
- **Fingerprint Unlock:** Use the in-screen fingerprint sensor for convenient and secure access.

Zero photosensitive Face recognition

Zero-light face recognition that hides infrared light, does not require glare in dark environments, and is still easy to read your "face"




Figure 3.4: The phone's face recognition feature, capable of operating in low light conditions.

Screen fingerprint unlock

Quick fingerprint allows you to quickly unlock the screen with just one hand, making it easy and quick to open your phone screen.



Figure 3.5: The convenient and secure screen fingerprint unlock functionality.

4. MAINTENANCE AND CARE

4.1. Battery Management

The 8000mAh battery provides long-lasting power. To maximize battery life:

- Avoid extreme temperatures.
- Use the provided USB cable for charging.
- Close unused apps running in the background.
- Adjust screen brightness to a comfortable level.

4.2. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials that could damage the finish.

4.3. Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. You can usually find this option in the phone's Settings menu under "System" or "About phone."

5. TROUBLESHOOTING COMMON ISSUES

If you encounter problems with your S25 Ultra, refer to the following common solutions:

Problem	Possible Solution
Phone does not power on	Ensure the battery is charged. Connect to a charger for at least 30 minutes. Try holding the Power button for 10-15 seconds.
Network connectivity issues (no signal, slow data)	Check if SIM cards are properly inserted. Restart the phone. Verify mobile data is enabled. Contact your carrier to confirm service.
Apps crashing or phone freezing	Close background apps. Clear app cache. Restart the phone. If persistent, consider a factory reset (back up data first).
Fingerprint or Face Recognition not working	Ensure your finger/face is clean and properly positioned. Re-register your fingerprint/face in settings.
Battery drains quickly	Reduce screen brightness. Disable unused features like Bluetooth/GPS. Limit background app activity. Check battery usage in settings.

6. PRODUCT SPECIFICATIONS

Below are the detailed technical specifications for the viqee S25 Ultra Cell Phone:

Feature	Detail
Model Name	S25U
Brand	viqee
Operating System	Android 15
CPU Model	Mediatek Dimensity 1100
RAM Memory Installed Size	8 GB
Memory Storage Capacity	256 GB

Feature	Detail
Screen Size	6.9 Inches
Standing Screen Display Size	6.9 Inches
Battery Capacity	8000 mAh (8000 Amp Hours)
Cellular Technology	5G
Wireless Carrier	Unlocked
Connectivity Technologies	5G, Wi-Fi, Bluetooth
GPS	True
Color	Rose Gold
Form Factor	Slate
Item Weight	14.7 ounces
Package Dimensions	7.17 x 3.78 x 1.73 inches
What's in the box	USB Cable
Manufacturer	viquee
Date First Available	April 10, 2025

Six selling points



Figure 6.1: Overview of the S25 Ultra's main features and specifications.

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the manufacturer, viquee, directly. Keep your proof of purchase for any warranty claims.

For further assistance, you may also visit the official viquee store on Amazon: [viquee Amazon Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question