Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave FST00213-T-AB1

Bellemave Triple Bunk Bed Instruction Manual

Model: FST00213-T-AB1

1. Introduction

Thank you for purchasing the Bellemave Triple Bunk Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed. Please read all instructions carefully before assembly and retain this manual for future reference.

This triple bunk bed is designed to maximize space, accommodating three twin-sized mattresses. Its versatile design allows it to be configured as a triple bunk bed or separated into three individual twin beds.



Image 1.1: Assembled Bellemave Triple Bunk Bed in a room setting.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always follow assembly instructions carefully to prevent instability or collapse.
- Be careful with sharp metal edges during assembly and use.
- Do not exceed the weight capacity of**250 pounds (113 kg)** for the upper bed.
- Do not exceed the weight capacity of**350 pounds (159 kg)** for each lower bed.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten as necessary.
- The top bunk is not suitable for children under 6 years of age.
- Always use the recommended mattress size to prevent entrapment or falls.
- Do not allow horseplay on or under the bed.

- Always use the ladder for entering and exiting the top bunk.
- Prohibit more than one person on the top bunk.
- Keep all assembly tools and small parts out of reach of children.

3. Package Contents

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.
The package includes:

- Metal Bed Frames (for three twin beds)
- Guardrails (for upper bunk)
- Metal Slats (for all three beds)
- Ladder
- Assembly Hardware (screws, bolts, nuts, washers, Allen wrench)
- Instruction Manual



Image 3.1: The triple bunk bed can be separated into three individual twin beds.

4. Assembly Instructions (Setup)

Assembly requires at least two adults. Clear a large area for assembly and keep all parts organized. Do not fully tighten bolts until instructed.

Step 1: Prepare the Components

Unpack all components and identify them using the parts list (not provided in this manual, refer to your included physical parts list). Ensure you have all necessary hardware.

Step 2: Assemble the Lower Beds

Begin by assembling the two individual twin beds that will form the lower bunks. Attach the side rails to the headboards and footboards using the provided bolts and Allen wrench. Insert the metal slats into the designated slots on the side rails. Do not fully tighten all bolts yet.

Image 4.1: Detail of the lower bunk bed frame and slat support.

Step 3: Assemble the Top Bunk

Assemble the top bunk frame, including the side rails, headboard, footboard, and guardrails. Ensure the guardrails are securely attached to prevent falls. Insert the metal slats. Do not fully tighten all bolts yet.

Image 4.2: Detail of the top bunk bed frame with integrated guardrails.

Step 4: Stack the Beds and Attach Ladder

Carefully lift the assembled top bunk and place it onto the designated support points of the lower bed frames. Ensure proper alignment. Secure the top bunk to the lower structures using the provided hardware. Attach the ladder to the top bunk, ensuring it is firmly secured and stable.

Step 5: Final Tightening

Once all components are assembled and aligned, systematically tighten all bolts and screws. Do not overtighten, but ensure all connections are snug and secure. Check for any wobbling or instability.

5. Usage Guidelines (Operating)

Triple Bunk Bed Configuration

- Ensure mattresses are twin size and fit snugly within the bed frames.
- Always use the ladder to access the top bunk.
- Do not jump on the beds.
- Regularly inspect all connections for tightness and re-tighten as needed.

Individual Bed Configuration

The triple bunk bed can be separated into three individual twin beds. To do this, carefully disassemble the top bunk from the lower frames and remove the ladder. Ensure all parts are stored safely if you plan to reconfigure it as a bunk bed later.

6. Care and Maintenance

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Inspection:** Periodically inspect all bolts, screws, and connections to ensure they remain tight. Re-tighten any loose hardware to maintain stability and safety.
- **Moving the Bed:** When moving the bed, lift it rather than dragging it to prevent damage to the frame or floor.

7. Troubleshooting

Bed is Wobbly After Assembly

- Ensure all bolts and screws are fully tightened.
- Check that all components are correctly aligned according to the assembly instructions.
- Verify that the bed is placed on a flat, even surface.

Missing Parts or Damaged Components

- Do not proceed with assembly.
- Contact Bellemave customer support immediately for replacement parts.

Difficulty Assembling

- Review the assembly instructions carefully, paying close attention to diagrams.
- Ensure you are using the correct hardware for each step.
- Having a second person assist can significantly ease the assembly process.

8. Specifications

Feature	Detail
Model Number	FST00213-T-AB1
Brand	Bellemave
Material	Metal
Overall Dimensions (L x W x H)	92.13" x 77.56" x 64.37" (approx. 234cm x 197cm x 163cm)
Mattress Size Compatibility	Twin (for all three beds)
Top Bunk Weight Capacity	250 lbs (113 kg)
Lower Bunk Weight Capacity (each)	350 lbs (159 kg)
Box Spring Required	No
Assembly Required	Yes



Image 8.1: Detailed dimensions of the Bellemave Triple Bunk Bed.

9. Warranty Information

Bellemave products are manufactured with quality and care. For specific warranty details regarding your Triple Bunk Bed, please refer to the warranty card included with your purchase or contact Bellemave customer support.

10. Customer Support

If you have any questions, require assistance with assembly, or need replacement parts, please contact Bellemave customer support. Refer to your purchase documentation for contact details or visit the official Bellemave website.

© 2023 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4CZ1DZS

More documents and user manuals: **https://manuals.plus/**