

## Lefton BF2204

# Lefton Rotatable Bathroom Faucet BF2204 User Manual

Model: BF2204-6 | Brand: Lefton

## 1. INTRODUCTION

Thank you for choosing the Lefton Rotatable Bathroom Faucet BF2204. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new faucet. Please read this manual thoroughly before installation and keep it for future reference.

### ⚠ IMPORTANT NOTICE ⚠:

- Please confirm the size before purchasing to ensure it fits your sink, countertop, or vanity.
- Some water inside the faucet is normal as all products are water-tested before shipment to ensure quality. Rest assured, all items are 100% brand new and never used.

## 2. PRODUCT OVERVIEW

The Lefton BF2204 is a rotatable bathroom faucet designed for deck mounting, featuring a single handle for water control and a brushed gold finish. It includes a pop-up stopper and a 10-inch cover plate for versatile installation.

### Included Components:

- 1 x Lefton Rotatable Bathroom Faucet BF2204
- 1 x Pop-up Stopper
- 1 x 10" Cover Plate
- Instruction Manual (this document)



Image 2.1: The Lefton Rotatable Bathroom Faucet BF2204, including the main faucet body, the pop-up drain stopper, and the 10-inch cover plate, all in a brushed gold finish.

3. SPECIFICATIONS

Feature	Specification
Brand	Lefton
Model Name	BF2204-FCP01-D01-6F
Item Model Number	BF2204-6
Recommended Uses	Bathroom
Mounting Type	Deck Mount
Finish Type	Electroplate
Material	Brass, Stainless Steel
Color	Brushed Gold

Feature	Specification
Number of Handles	1
Special Feature	360 Swivel Spout
Style	w/ 10" Cover & Pop-up Stopper
Maximum Flow Rate	1.19 Gallons Per Minute
Product Dimensions	1"D x 1"W x 1"H (Approximate)



Image 3.1: Detailed dimensions of the faucet, including spout reach, height, and base measurements. Note the mounting hole diameter requirements (Min: 1.38"/35mm, Max: 1.5"/38mm) and maximum deck thickness (1.9"/48mm).



Image 3.2: Detailed dimensions of the pop-up stopper, showing its overall height, cap diameter, and thread size (G1 1/4").




Image 3.3: Detailed dimensions of the 10-inch cover plate, indicating its length (9 7/8" / 25cm), width (2 3/8" / 6cm), and hole diameter (1 3/8" / 3.5cm).

## 4. INSTALLATION GUIDE

### 4.1 Before You Begin

- Ensure all necessary components are present as listed in Section 2.
- Turn off the main water supply to the installation area.
- Clear the workspace under the sink.

### 4.2 Tools Required (Not Included)

- Adjustable Wrench
- Phillips Head Screwdriver
- Plumber's Putty or Silicone Sealant
- Basin Wrench (optional, for tight spaces)
- Safety Glasses

### 4.3 Installation Steps

1. **Prepare the Sink/Countertop:** Ensure the mounting hole on your sink or countertop meets the required dimensions (Min: 1.38"/35mm, Max: 1.5"/38mm). If using the 10" cover plate, place it over the mounting holes.
2. **Install the Faucet:** Insert the faucet body through the mounting hole (and cover plate, if used). From underneath the sink, secure the faucet using the provided washer and mounting nut. Tighten firmly but do not overtighten.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines (23.6" length) to the corresponding inlets on the faucet body. Connect the other ends of the supply lines to your hot and cold water shut-off valves. Ensure all connections are hand-tight, then use a wrench for a final quarter-turn.

- 4. **Install the Pop-up Stopper:** Disassemble the pop-up stopper. Apply plumber's putty or silicone sealant around the flange of the stopper and insert it into the drain hole from the top of the sink. From underneath, secure the stopper body with the provided washer and nut. Connect the lift rod (if applicable) to the faucet's lift mechanism.
- 5. **Check for Leaks:** Once all connections are secure, slowly turn on the main water supply. Check all connections for any signs of leaks. If leaks are detected, tighten the connections slightly until the leak stops.
- 6. **Flush the Faucet:** Remove the aerator from the faucet spout. Turn on both hot and cold water for a few minutes to flush out any debris from the lines. Turn off the water, reattach the aerator, and test the faucet's operation.

## 5. OPERATING INSTRUCTIONS

### 5.1 Faucet Operation

- **Water Flow Control:** The single handle controls both water flow and temperature. Lift the handle to increase water flow.
- **Temperature Control:** Move the handle left for hot water and right for cold water. Adjust the handle position to achieve the desired water temperature.

### 5.2 Pop-up Stopper Operation

- To close the drain and fill the sink, press down on the top of the pop-up stopper.
- To open the drain and allow water to flow, press down on the top of the pop-up stopper again.

### 5.3 Rotatable Spout Feature

- The faucet features a 360-degree swivel spout, allowing you to rotate the spout to direct water flow as needed for convenience.

## 6. CARE AND MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your Lefton faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, harsh chemicals, or polishes containing alcohol, ammonia, or bleach, as these can damage the finish.
- **Aerator Maintenance:** Periodically unscrew the aerator from the spout and clean any mineral deposits or debris that may accumulate, which can affect water flow.
- **Temperature Extremes:** Protect the faucet from freezing temperatures, which can cause damage to internal components.

## 7. TROUBLESHOOTING

If you encounter any issues with your faucet, please refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valve; kinked supply line.	Clean or replace aerator; fully open shut-off valves; straighten supply lines.
Leaking at Base	Loose mounting nut; improper sealant application.	Tighten mounting nut; reapply plumber's putty or silicone sealant.


Problem	Possible Cause	Solution
Leaking from Spout	Worn cartridge.	Contact customer support for a replacement cartridge.
Water Temperature Issues	Incorrect supply line connection; water heater issues.	Verify hot/cold supply line connections; check water heater settings.
Pop-up Stopper Not Sealing	Improper installation; debris in drain.	Reinstall stopper ensuring proper alignment and sealant; clear drain of debris.

## 8. WARRANTY INFORMATION

Lefton products are manufactured to high-quality standards. This product is subject to a 30-day return policy from the date of purchase. For specific warranty details beyond the return period, please refer to the warranty card included with your product or contact Lefton customer support.

## 9. CUSTOMER SUPPORT

If you have any questions, require assistance, or need to order replacement parts, please contact Lefton customer support:



If you get any questions, please:

**EMAIL US:**  
customer@leftonhome.com (24/7 Service)

**CALL US:**  
1 (601) 564 0548  
(English Only, Mon. - Fri. 9:00 am - 6:00 pm PST)






Image 9.1: A customer service representative ready to assist with inquiries.

**Email Us:** [customer@leftonhome.com](mailto:customer@leftonhome.com) (24/7 Service)

**Call Us:** 1 (601) 564 0548 (English Only, Mon. - Fri. 9:00 am - 6:00 pm PST)

For more information and products, visit the official Lefton Store: [Lefton Sanitary Store](#)

### Related Documents

<div>LEFTON</div> <div>Installation Manual</div> <div>BF2204</div> <div></div>	<div><a href="#">Lefton BF2204 Installation Manual</a></div> <div>Installation guide for the Lefton BF2204 faucet, detailing step-by-step assembly and connection procedures.</div>
<div>LEFTON</div> <div>Installation Manual</div> <div>BF2204</div> <div></div>	<div><a href="#">Lefton BF2204 Faucet Installation Manual</a></div> <div>Installation manual for the Lefton BF2204 faucet, providing step-by-step instructions for assembly and connection.</div>
<div>BF2501</div> <div>LEFTON</div> <div></div> <div></div>	<div><a href="#">Lefton BF2501 Single-Hole Pull-Out Bathroom Faucet with Temperature Display Specification Sheet</a></div> <div>Detailed specifications for the Lefton BF2501 bathroom faucet, a single-hole, liftable, pull-out design with a digital temperature display. Features include brass construction, ABS sprayer, lead-free waterway, 1.5 GPM flow rate, and multiple finish options. Includes dimensions, accessories, and warranty information.</div>
<div>LEFTON</div> <div>Installation Manual</div> <div>BF2204</div> <div></div>	<div><a href="#">Lefton BF2204 Faucet Installation Manual</a></div> <div>Comprehensive installation manual for the Lefton BF2204 faucet, detailing each step with clear instructions and diagrams for a smooth setup process.</div>





[\[pdf\]](#) User Manual Installation Guide Guide

Installation Guide 2024 Latest Smart Modern Rotatable Bathroom Faucet BF2204 Lefton Home Manual 1 v 1723804743 cdn shopify s files 0641 0462 8483 |||

Single Lever Bathroom Basin Faucet **BF2204** www.leftonhome.com I customer leftonhome.com I August25,2022 2 3 FaucetBody WaterproofRubberRing ThreadedMetalPipe Rubber Gasket MatelGasket Mounting Nut Mounting Screws Hot ColdWaterPipes 4 Removemountinghardware Shutoffthewatersupply.Remove theold...

lang:en score:45 filesize: 12.2 M page\_count: 11 document date: 2024-08-16



[\[pdf\]](#) User Manual

User Manual Lefton Home Installation BF2204 v 1678863535 cdn shopify s files 1 0641 0462 8483 |||

Single Lever Bathroom Basin Faucet **BF2204** www.leftonhome.com I customer leftonhome.com I August25,2022 2 3 FaucetBody WaterproofRubberRing ThreadedMetalPipe Rubber Gasket MatelGasket Mounting Nut Mounting Screws Hot ColdWaterPipes 4 Removemountinghardware Shutoffthewatersupply.Remove theold...

lang:en score:35 filesize: 14.16 M page\_count: 14 document date: 2023-03-13



[\[pdf\]](#) User Manual

222883 4632702 BF2204 D01 0F Faucet Installation Manual Lefton Rotatable Bathroom Bf2204 With Pop up Sink Drain Stopper Without Overflow Ifto1046 LeftonLefton 1F 2F 3F 6F Lefton222883 bf2204 d01 0f faucet installation manualsecure img1 ag wfcnd dm document c2d0de73 4330 46e1 a2d8 e3f72eee9e94 manual |||

Single Lever Bathroom Basin Faucet **BF2204** www.leftonhome.com I customer leftonhome.com I August25,2022 2 3 FaucetBody WaterproofRubberRing ThreadedMetalPipe Rubber Gasket MatelGasket Mounting Nut Mounting Screws Hot ColdWaterPipes 4 5 Removemountinghardware Shutoffthewatersupply.Remove the...

lang:en score:34 filesize: 4.06 M page\_count: 14 document date: 2023-03-20

Single Lever Bathroom  
Basin Faucet

BF2204

www.leftonhome.com | customer@leftonhome.com | August 25, 2022

LEFTON

Installation Manual  
BF2204



[pdf] User Manual

Installation Manual Lefton Rotatable Bathroom Faucet with Temperature Display Batteries Free 3 Water Modes Chrome BF2204 1 C1W58SGpaBL m media amazon images I |||

Single Lever Bathroom Basin Faucet **BF2204** www.leftonhome.com I customer leftonhome.com I August25,2022 2 3 FaucetBody WaterproofRubberRing ThreadedMetalPipe Rubber Gasket MatelGasket Mounting Nut Mounting Screws Hot ColdWaterPipes 4 5 Removemountinghardware Shutoffthewatersupply.Remove the... lang:en score:33 filesize: 4.06 M page\_count: 14 document date: 2023-03-20

[Lefton BF2204 Faucet Installation Manual](#)

Comprehensive installation manual for the Lefton BF2204 faucet, detailing each step with clear instructions and diagrams for a smooth setup process.

lang:en score:25 filesize: 465.47 K page\_count: 6 document date: 2025-06-30

**BF2204**  
Single Lever Bathroom Basin Faucet

**Feature Description:**  
Overall Height: 15.12" (383 mm)  
Spout Height: 12.12" (308 mm)  
Handle Height: 1.12" (28 mm)

**Features:**  
Single-lever  
Lead-Free Brass Body  
15° Fixed Spout  
Flow Rate: 1.2 gpm (0.45 L/min) @ 60 psi  
Ceramic Disc Cartridge  
90° Rotation  
Battery-Free Temperature Display

**Accessories Included:**  
Mounting Hardware  
Hot & Cold Water Pipes  
Rubber Gasket  
Drain Gasket

**Available Finishes:**  
Chrome  
Black  
Brushed Nickel  
Matte White

**Warranty:**  
See website for details: www.leftonhome.com  
Lefton Customer Service  
Please email to: customer@leftonhome.com

**LEFTON**  
#LEFTONISBEST

Technical drawing showing side and top views of the faucet with dimensions in inches and millimeters.

[Lefton BF2204 Single Lever Bathroom Basin Faucet - Specification Sheet](#)

Detailed specification sheet for the Lefton BF2204 Single Lever Bathroom Basin Faucet, including dimensions, features, available finishes, and warranty information.

lang:fr score:25 filesize: 1.92 M page\_count: 1 document date: 2023-03-13

LEFTON

Installation Manual  
BF2204



[Lefton BF2204 Faucet Installation Manual](#)

Installation manual for the Lefton BF2204 faucet, providing step-by-step instructions for assembly and connection.

lang:fr score:24 filesize: 464.23 K page\_count: 6 document date: 2025-07-14

LEFTON

Installation Manual  
BF2204



[Lefton BF2204 Installation Manual](#)

Installation guide for the Lefton BF2204 faucet, detailing step-by-step assembly and connection procedures.

lang:fr score:23 filesize: 464.23 K page\_count: 6 document date: 2025-07-14



CEC TEST REPORT

Report No.: SJ52309238G-CEC-R1  
Product: Bathroom Faucet  
Model No.: BF2204-1, BF2204-2, BF2204-3, BF2204-4, BF2204-5  
Applicant: HONG KONG LEFTON TECHNOLOGY CO LIMITED  
Address: UNIT 1507C, 15/F, EASTCORE, 398 KWUN TONG ROAD, KWUN TONG HONG KONG 99077  
Issued by: Shenzhen SJ5 Testing Technology Services Co., Ltd  
Room 435, No.6095-2, Bao'an Road, Qiaotou Community,  
Lab Location: Fuhai Subdistrict, Bao'an District, Shenzhen, Guangdong, China  
Tel: +86-755-2778 4461 Fax: +86-755-2778 4461

CEC

This test report consists of 12 pages including images. It may be distributed externally for legal use with the agreement of the applicant. It should not be reproduced except in full, without the written approval of our laboratory. The client should not use the data or product information in this report for any other purpose. The test report shall be valid only when all the signatures of testing engineers, reviewer and supervisor are present. Results should be issued to the client within 10 days when the report is requested. It will not be taken into consideration beyond two years.

[\[pdf\]](#) Test Report

View CEC Test Report HereWater Efficient Products Enjoy 20% Off Lefton HomeBF2204 TEST REPORTcdn shopify s files 1 0641 0462 8483 BF2204 REPORT v 1737341251 |||

...

lang:fr score:13 filesize: 2.88 M page\_count: 12 document date: 2023-05-18