Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Z ZONAMA B0F4D48XVX

Z ZONAMA Golf Trunk Organizer User Manual

Model: B0F4D48XVX

Introduction

This manual provides detailed instructions for the assembly, use, and maintenance of your Z ZONAMA Golf Trunk Organizer. Please read this manual thoroughly before using the product to ensure proper function and longevity.

Product Overview

The Z ZONAMA Golf Trunk Organizer is designed to keep your golf accessories neatly organized and easily accessible. It features a multi-layered design with adjustable compartments and durable, waterproof fabric.

Key Features:

- **Adequate Storage Space:** The organizer has 3 layers. The bottom layer includes two independent compartments for up to two pairs of shoes (under size 11), with 2 air holes for ventilation. The middle layer features 5 adjustable compartments for golf shirts, hats, gloves, towels, etc. The upper cover has 3 compartments for golf balls, tees, pens, and other small items.
- **Enhanced Sturdy Structure:** Equipped with a thick movable support panel at the bottom and hard PVC bottom plates in the side pockets, preventing collapse and maintaining shape even when fully loaded.
- **Waterproof and Tear-resistant Fabric:** Constructed from waterproof and tear-resistant honeycomb structure fabric for durability. The bottom fabric is also waterproof and stain-resistant, allowing for placement on wet surfaces without damage and easy cleaning.

Components:

- 1x Golf Trunk Organizer
- Movable support panels
- Adjustable dividers

Setup and Installation

Follow these steps to set up your Z ZONAMA Golf Trunk Organizer:

1. Unfold the organizer from its compact state.

2. Insert the thick movable support panel into the bottom of the main compartment to provide a sturdy base.
3. Place the hard PVC bottom plates into the designated pockets on both sides of the bottom layer. This reinforces the structure and prevents the upper layers from collapsing.
4. Attach the adjustable dividers within the middle layer using the Velcro fasteners to create compartments of your desired size.
5. Ensure all zippers are functioning smoothly and the structure is stable before loading items.

Your browser does not support the video tag.

Video: Demonstrates the installation process of the Z ZONAMA Golf Trunk Organizer, showing how to unfold, insert support panels, and arrange dividers.



Image: The Z ZONAMA Golf Trunk Organizer fully assembled, showcasing its internal structure with adjustable dividers and multiple compartments.

Operating Instructions

The Z ZONAMA Golf Trunk Organizer is designed for intuitive use. Utilize the various compartments to store your golf gear efficiently.

Storage Layers:

- **Bottom Layer:** Use the two independent compartments for golf shoes. The integrated air holes help ventilate the shoes, reducing odor.
- **Middle Layer:** Adjust the 5 dividers to create custom-sized sections for larger items like shirts, hats, gloves, and towels.
- **Upper Cover:** The 3 mesh pockets on the inside of the lid are ideal for small accessories such as golf balls, tees, pencils, and scorecards.



Image: A visual representation of the organizer's three layers, detailing suggested items for each compartment to maximize storage efficiency.



Image: The adjustable partition system, illustrating the flexibility to configure the internal space according to your storage needs.

Maintenance

To ensure the longevity and cleanliness of your Z ZONAMA Golf Trunk Organizer, follow these maintenance guidelines:

- **Cleaning:** The waterproof and stain-resistant fabric allows for easy cleaning. Wipe down the exterior and interior surfaces with a damp cloth and mild soap as needed. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** If the organizer becomes wet, ensure it is thoroughly air-dried before storing to prevent mold or mildew. The shoe compartments' air holes aid in ventilation.
- **Storage:** When not in use, the organizer can be folded down for compact storage. Remove all internal support panels and dividers before folding.



Image: An overview of the organizer's construction, highlighting its durable and easy-to-maintain materials and features.

Troubleshooting

If you encounter any issues with your Z ZONAMA Golf Trunk Organizer, consider the following:

- **Organizer losing shape:** Ensure all movable support panels and hard PVC bottom plates are correctly inserted and positioned.
- **Zippers sticking:** Apply a small amount of zipper lubricant or rub a pencil lead along the zipper teeth to improve smoothness.
- **Odor in shoe compartments:** Verify that the air holes are not obstructed and ensure shoes are dry before storage. Regular cleaning can also help.

Specifications

Feature	Detail
Item Dimensions (LxWxH)	16.9 x 13 x 9.8 inches
Item Package Dimensions (LxWxH)	17.76 x 13.89 x 3.31 inches
Package Weight	1.61 Kilograms
Material	Polyester
Color	Blue
Number of Items	1
Included Components	1x Golf Trunk Organizer

Warranty and Support

For any issues with your order, please contact Z ZONAMA customer service. We are committed to resolving your concerns promptly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4D48XVX

More documents and user manuals: **https://manuals.plus/**