

IR Replacement Remote Control

Instruction Manual for Generic IR Replacement Remote Control

Model: IR Replacement Remote Control (B0F4DHPN7X)

INTRODUCTION

This manual provides comprehensive instructions for the Generic IR Replacement Remote Control. It is designed for use with specific BYINTEK projector models, including UFO P20, U70 PRO, and P70 5G Mini DLP Portable 1080P Movie Projectors. Please read this manual carefully before using the remote control to ensure proper operation and to maximize its lifespan.

Important Compatibility Note: This is an infrared (IR) replacement remote. Ensure your original remote control has the same appearance and button layout as depicted in this manual for full compatibility. Functionality may vary slightly from the original remote depending on your projector model.

SETUP

1. Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Gently slide the cover downwards or press the latch and lift to remove it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back of the remote control with the battery cover removed, illustrating the battery compartment. Two AAA battery slots are visible.

2. Initial Use

Once batteries are installed, the remote control is ready for use. Point the remote directly at the infrared receiver on your BYINTEK projector. There is no pairing process required for this IR remote.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions:



Image: Front view of the remote control, displaying the layout of all control buttons.

Button	Function
Power ()	Turns the projector On or Off.
F+ / F-	Adjusts the focus of the projector lens (Focus In / Focus Out).
Mute ()	Mutes or unmutes the projector's audio output.
Navigation Arrows (◀▶ ▲ ▼)	Navigates through menus and options.
OK	Confirms selections or enters sub-menus.
Back / Return (↵)	Goes back to the previous menu or screen.
Home (△)	Returns to the main home screen or menu of the projector.
Menu / Settings (☰)	Opens the projector's settings or options menu.
Volume Down / Up (/)	Decreases or increases the audio volume.
Source / Input (Projector Icon)	Selects the input source (e.g., HDMI, USB, AV).

Note: Specific button functions may vary slightly based on your BYINTEK projector model and its firmware.

MAINTENANCE

1. Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

2. Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

3. Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control is not responding.	<ul style="list-style-type: none"> Dead or incorrectly inserted batteries. Obstruction between remote and projector. Remote is out of range. 	<ul style="list-style-type: none"> Replace batteries with new AAA batteries, ensuring correct polarity. Remove any objects blocking the line of sight between the remote and the projector's IR receiver. Move closer to the projector.
Some functions do not work.	<ul style="list-style-type: none"> Incompatibility with specific projector model. Projector firmware limitations. 	<ul style="list-style-type: none"> Verify that your projector model is listed as compatible. Understand that some advanced functions might not be supported by a replacement remote.

SPECIFICATIONS

Brand: Generic

Manufacturer: SZHKHXD

Model Identifier (ASIN): B0F4DHPN7X

Power Source: 2 x AAA batteries (not included)

Color: Black

Special Feature: Ergonomic design, Infrared (IR) technology

Max Number of Supported Devices: 1 (for the specific projector it controls)

Compatible Devices: BYINTEK UFO P20, U70 PRO, P70 5G Mini DLP Portable 1080P Movie Projectors

First Available Date: April 10, 2025

WARRANTY AND SUPPORT

This product is a replacement remote control. For specific warranty information, please refer to the original purchase documentation or contact the seller directly. For technical support or inquiries regarding this remote control, please reach out to the manufacturer, SZHKHXD, or the retailer from whom you purchased the product. Please note that this remote is designed to replicate the functions of the original remote for the specified projector models. Full functionality is dependent on the projector's capabilities and may not include all features of the original remote if it was a more advanced type (e.g., Bluetooth or air mouse functionality).