

[Manuals.plus](#) /

> [YITAHOME](#) /

> YITAHOME 5-Tier Shoe Cabinet Instruction Manual

YITAHOME MAYIHrgMZ2

YITAHOME 5-Tier Shoe Cabinet Instruction Manual

Model: MAYIHrgMZ2

1. INTRODUCTION

Thank you for choosing the YITAHOME 5-Tier Shoe Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe storage organizer. Please read these instructions carefully before beginning assembly and retain them for future reference.

This modern freestanding wooden shoe rack cabinet is designed to enhance organization in your entryway, hallway, closet, or living room, featuring adjustable shelves and a compact, elegant design.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following safety guidelines:

- Always ensure the cabinet is stable and secure before use.
- Do not place heavy objects on the top shelf that exceed its weight capacity.
- Keep the cabinet away from direct heat sources and excessive moisture to prevent damage.
- This product is intended for indoor use only.
- To prevent tipping, especially in households with children, it is highly recommended to secure the cabinet to a wall using the provided anti-tip hardware.




Figure 2.1: Anti-Tipping Precaution. This image illustrates the importance of securing the shoe cabinet to the wall to prevent potential tipping hazards, especially with children present. The top portion shows a child attempting to climb an unsecured cabinet, marked with "POTENTIAL INJURY". The bottom portion shows a close-up of the anti-tip hardware installed, marked with "AVOID FALLING DANGER".

3. PRODUCT FEATURES

The YITAHOME Shoe Cabinet offers several key features designed for optimal shoe storage and aesthetic appeal:

- **Compact & Elegant Design:** Features a timeless brown and white wooden finish with textured doors and black feet, providing a modern and sophisticated look suitable for various spaces.
- **Sturdy & Long-Lasting Construction:** Manufactured from high-quality engineered wood, ensuring durability and stability for your entire footwear collection.
- **Effortless Access:** Equipped with spring-hinged magnetic doors that open smoothly for quick and convenient access to your shoes.
- **Smart Adjustable Storage:** Includes 5 tiers (4 shelves, 2 adjustable) to accommodate various shoe types, from sneakers to boots. The top shelf provides space for essentials, while the open bottom area is ideal for slippers.



Figure 3.1: Elegant Design. This image showcases the YITAHOME shoe cabinet's compact and elegant design, featuring its brown and white finish, patterned doors, and black legs, positioned in an entryway setting.

CUSTOMIZABLE SHOE CABINETS

The bottom shelf is removable and can be adjusted in three heights.



Figure 3.2: Customizable Storage. This image highlights the adjustable shelving feature of the shoe cabinet. It shows how the bottom shelf can be removed or adjusted to three different heights to accommodate various footwear, including tall boots.

UNIQUE PATTERN DESIGN FOR DOOR

Designed with a platinum modern pattern to bring elegance to your home.



Metal Door Handles



Magnetic Door



Black Rubberwood Legs

Figure 3.3: Door and Leg Details. This image provides a closer look at the unique pattern design on the cabinet doors, the metal door handles, the magnetic door closure mechanism, and the sturdy black rubberwood legs.

4. SPECIFICATIONS

Attribute	Detail
Brand	YITAHOME
Model Name	Shoe Cabinet
Model Number	MAYIHrgMZ2
Color	Brown & White
Product Dimensions (D x W x H)	13.77"D x 29.52"W x 41.33"H

Attribute	Detail
Item Weight	57.5 pounds
Material	Engineered Wood
Number of Shelves	4 (2 adjustable)
Number of Compartments	5
Mounting Type	Floor Mount
Installation Type	Freestanding
Assembly Required	Yes
Included Components	Hardware
Recommended Uses	Shoes
Room Type	Hallway, Living Room

PRODUCT SIZE



Figure 4.1: Product Dimensions. This diagram provides detailed measurements of the shoe cabinet, including its overall height, width, and depth, as well as internal shelf dimensions.

5. SETUP AND ASSEMBLY

The YITAHOME Shoe Cabinet is designed for quick and easy assembly. All necessary hardware is included, and parts are pre-labeled for your convenience.

5.1. Before You Begin

- Unpack all components and verify against the parts list provided in the packaging.
- Ensure you have a clear, spacious area for assembly.
- Gather necessary tools (e.g., screwdriver, hammer if needed).

5.2. Assembly Steps

1. Follow the step-by-step instructions provided in the assembly manual included in the product packaging.
2. Attach the black rubberwood legs securely to the base of the cabinet.
3. Assemble the main frame of the cabinet, ensuring all connections are tight.
4. Install the shelves. Note that two shelves are adjustable; refer to the manual for specific height settings.
5. Attach the magnetic doors, ensuring they open and close smoothly.
6. Install the metal door handles.
7. *Important:* Secure the cabinet to a wall using the anti-tip hardware provided. This step is crucial for stability and safety.

If you encounter any difficulties during assembly, please refer to the "7. Support and Warranty" section for assistance.

6. OPERATING INSTRUCTIONS

6.1. Storing Shoes

- Open the cabinet doors by gently pressing them to release the magnetic catch.
- Place shoes on the shelves. Utilize the adjustable shelves to accommodate taller footwear like boots.
- The open bottom section is ideal for frequently used slippers or smaller items.
- Close the doors firmly until the magnetic catch engages.

6.2. Utilizing the Top Surface

The spacious countertop is suitable for displaying home decor items or storing small personal belongings such as keys, wallets, or small bags. Ensure items placed on top do not exceed the cabinet's stability limits.



Figure 6.1: Spacious Countertop. This image demonstrates the utility of the cabinet's top surface, ideal for displaying decorative items or keeping small personal belongings organized and easily accessible.

7. MAINTENANCE

Proper care will ensure the longevity and appearance of your YITAHOME Shoe Cabinet:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dusting:** Regularly dust the cabinet to prevent buildup.
- **Moisture:** Immediately wipe away any spills to prevent water damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Re-tighten if necessary.

8. TROUBLESHOOTING

This section addresses common issues you might encounter:

Problem	Possible Cause	Solution
Cabinet wobbles or feels unstable.	Loose screws; uneven floor; anti-tip hardware not installed.	Ensure all screws are tightened. Move to a level surface or use shims. Install anti-tip hardware as per instructions.
Doors do not close properly.	Misaligned hinges; magnetic catch not engaging.	Check hinge alignment and adjust if necessary. Ensure magnetic catches are properly installed and aligned with the door.
Difficulty during assembly.	Missing parts; unclear instructions.	Double-check all parts against the list. Review the assembly manual carefully. Contact customer support if parts are missing or instructions are unclear.

9. SUPPORT AND WARRANTY

YITAHOME is committed to providing high-quality products and excellent customer service.

9.1. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact our dedicated support team. You can typically find contact information on the product packaging or the official YITAHOME website.

For general inquiries, you may also visit the [YITAHOME Store on Amazon](#).

9.2. Return Policy

This product is eligible for a 30-day easy return policy, offering a refund or replacement. Please refer to your purchase platform's return policy for detailed terms and conditions.