



Manuals.plus /

› Uuoeebb /

› Uuoeebb Foldable Toddler Kitchen Tower Step Stool with Whiteboard Instruction Manual

## Uuoeebb Stools-001

# Uuoeebb Foldable Toddler Kitchen Tower Step Stool with Whiteboard Instruction Manual

Model: Stools-001 | Brand: Uuoeebb

## 1. INTRODUCTION

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your Uuoeebb Foldable Toddler Kitchen Tower Step Stool. This product is designed to assist toddlers aged 1-6 years in reaching counter heights safely, fostering independence in activities such as cooking, washing hands, and creative play with the integrated whiteboard. Please read this manual thoroughly before use and retain it for future reference.

## 2. SAFETY INFORMATION

### Important Safety Warnings:

- **Adult Supervision Required:** Always ensure an adult is present and actively supervising the child when using the kitchen tower. Never leave a child unattended on the stool.
- **Stable Placement:** Place the kitchen tower on a flat, stable, and non-slip surface. Ensure all four feet are firmly on the ground before use.
- **Weight Limit:** Do not exceed the maximum weight limit of 200 pounds (approximately 90 kg).
- **Check Stability:** Before each use, verify that all connections, screws, and locking mechanisms are securely fastened and that the tower is stable. A wobbly tower is unsafe.
- **Folding Mechanism:** Exercise caution when folding and unfolding the tower to prevent finger pinching. Ensure the folding mechanism is fully engaged and locked in place when in use or folded for storage.
- **Height Adjustment:** Ensure the foot pedal is correctly installed and secured at the desired height before the child uses the tower.
- **Avoid Climbing:** Instruct children not to climb on the outside of the tower or stand on the safety railings.
- **Maintenance:** Regularly inspect the tower for any signs of wear, damage, or loose parts. Discontinue use immediately if any damage is found and contact customer support.

## 3. PACKAGE CONTENTS

Please verify that all components are present and undamaged before proceeding with assembly.

- Main Kitchen Tower Frame (pre-assembled folding sections)
- Adjustable Foot Pedal/Platform
- Magnetic Whiteboard
- Mounting Hardware for Whiteboard (if separate)
- Plum Blossom Screws for Height Adjustment
- Instruction Manual



*Image 1: Overview of the Uuoeebb Foldable Toddler Kitchen Tower, illustrating its assembled form, folded state, and the attached whiteboard.*

## 4. ASSEMBLY INSTRUCTIONS

The Uuoeebb Kitchen Tower is designed for quick setup. Most of the frame comes pre-assembled.

1. **Unfold the Frame:** Carefully unfold the main frame of the kitchen tower until it forms a stable A-frame structure. Ensure the side supports are fully extended and locked into position.

2. **Attach the Whiteboard:** If the whiteboard is separate, attach it to the designated hooks or slots on the upper part of the tower. Ensure it is securely hung and does not wobble.
3. **Adjust Foot Pedal Height:**
  - Locate the plum blossom screws on the side of the tower that secure the foot pedal.
  - Unscrew these by hand (no tools required).
  - Slide the foot pedal to one of the three available height levels (approximately 18", 14", or 11" from the ground).
  - Re-insert and tighten the plum blossom screws firmly by hand to secure the foot pedal at the chosen height. Ensure both sides are at the same level.
4. **Final Check:** Before first use, gently shake the assembled tower to confirm all parts are secure and stable.



Image 2: Key features of the kitchen tower, highlighting the smooth finish, three height adjustment levels, stable side supports, and the folding mechanism.

## 5. OPERATING INSTRUCTIONS

The Uuoeebb Kitchen Tower is designed to be user-friendly for both children and adults.

### 5.1 Using the Kitchen Tower

1. **Positioning:** Place the tower securely against a counter, sink, or table where the child will be assisting or

playing. Ensure there is no gap large enough for the child to fall through.

2. **Child Entry:** Guide your child to climb the steps onto the foot pedal. The design allows for easy climbing.
3. **Safety Railings:** The tower features safety railings to provide support and help prevent accidental falls. Ensure the child remains within the confines of the tower.
4. **Activities:** The tower enables children to participate in various activities such as:
  - Assisting with food preparation (e.g., washing fruits, mixing ingredients).
  - Washing hands at the sink.
  - Engaging in crafts or learning activities at counter height.



## Toddler Kitchen Stool Helper

Baby grows through interaction with families

*Image 3: A child actively participating in kitchen tasks from the safety of the Uuoeebb Kitchen Tower.*

## Best Toddler Step Stool to Train Kids' Independence



Image 4: Examples of children using the kitchen tower for various independent activities, including hygiene and reaching.

### 5.2 Using the Magnetic Whiteboard

The integrated magnetic whiteboard provides an additional activity space for your child.

- The whiteboard can be used with dry-erase markers and magnetic accessories.
- It can be used while the tower is standing or when folded, depending on the activity.
- To clean, simply wipe with a dry cloth or a whiteboard cleaner.

## Whiteboard with Magnetic Suction Function



Image 5: A child engaging in creative drawing on the magnetic whiteboard feature of the tower.

### 5.3 Folding for Storage

The tower features a foldable design for convenient storage and space-saving.

1. Ensure no child is on the tower.
2. Carefully disengage any locking mechanisms that hold the frame in its open position.
3. Gently fold the sides inwards until the tower is compact.
4. The whiteboard can remain attached when folded, helping to keep components together.
5. Store in a safe place where it will not accidentally unfold or tip over.

## 6. MAINTENANCE AND CARE

Proper care will extend the life of your Uuoeebb Kitchen Tower.

- **Cleaning:** Wipe down the wooden surfaces with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners. Dry immediately with a clean cloth.
- **Whiteboard Cleaning:** Use a dry-erase marker eraser or a soft cloth for daily cleaning. For stubborn marks, use a specialized whiteboard cleaner.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten any loose

fasteners by hand.

- **Storage:** When not in use, store the folded tower in a dry place away from direct sunlight or extreme temperatures to prevent warping or damage to the wood.
- **Avoid Moisture:** Do not immerse the tower in water or expose it to excessive moisture.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tower feels wobbly or unstable.	Loose screws or connections. Uneven surface.	Ensure all plum blossom screws and other fasteners are securely tightened. Move the tower to a flat, level surface.
Foot pedal height adjustment is difficult or slips.	Plum blossom screws not fully loosened or tightened.	Fully loosen the plum blossom screws before adjusting. Ensure they are fully tightened after setting the desired height.
Folding mechanism does not engage or disengage smoothly.	Obstruction in the mechanism. Misalignment.	Check for any debris or foreign objects. Ensure the parts are aligned correctly. Apply gentle, even pressure. Do not force.
Whiteboard is not secure.	Improper attachment.	Ensure the whiteboard is correctly seated on its hooks or in its designated slots.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	Stools-001
Brand	Uuoeebb
Product Dimensions (Open)	19.4"D x 18.3"W x 35.57"H
Product Dimensions (Folded)	Approximately 5.3"D x 18.3"W x 38.6"H
Material	Wood
Color	White
Special Features	Adjustable Height, Foldable, Magnetic Whiteboard
Age Range (Recommended)	Toddler, Kid (1-6 Years)
Maximum Height (Overall)	35.6 Inches
Weight Limit	200 Pounds
Foot Pedal Height Levels	3 levels (approx. 18", 14", 11" from ground)
Item Weight	18.74 pounds
UPC	717504188935

# Foldable Toddler Tower




Image 6: Detailed dimensions and adjustable height options for the kitchen tower.

## 9. WARRANTY AND SUPPORT

For warranty information, product support, or to report any issues, please contact Uuoeebb customer service through your original purchase platform or the official Uuoeebb website. Please have your model number (Stools-001) and purchase date available when contacting support.