

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Full Low Loft Bed Instruction Manual

Bellemave FST00211-F-AK1

Bellemave Full Low Loft Bed Instruction Manual

Model: FST00211-F-AK1

INTRODUCTION

Thank you for choosing the Bellemave Full Low Loft Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new loft bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information

- Always supervise children when using the ladder.
- Be cautious of sharp edges during assembly and use.
- Follow all assembly instructions carefully to prevent instability.
- Ensure the bed is placed on a level and stable surface.
- Do not exceed the maximum weight capacity specified by the manufacturer.
- Regularly check all connections and hardware to ensure they remain tight.

SETUP AND ASSEMBLY

The Bellemave Full Low Loft Bed is designed for straightforward assembly. Your bed is delivered in one package and includes all necessary hardware and a detailed assembly guide. Please ensure you have all components before starting.

Before You Begin

- Unpack all components and verify against the parts list provided in your separate assembly guide.
- Clear a spacious area for assembly.
- Keep children and pets away from the assembly area.
- Sort all hardware to easily identify each piece.

Assembly Steps

Refer to the separate assembly instruction booklet included in your package for step-by-step visual guidance. It is crucial to follow these instructions precisely to ensure the bed's structural integrity and safety.

UNIT INCH



This diagram illustrates the overall dimensions of the loft bed, including length (78.6 inches), width (56.3 inches), total height (44.3 inches), and under-bed clearance (29.6 inches).



This image highlights the ladder's design, featuring wide steps for easier and safer access to the bed.



Detail of the poplar plywood slats that provide strong support for the mattress, eliminating the need for a box spring.

OPERATING AND USAGE

The Bellemave Full Low Loft Bed is designed to maximize space and provide a secure sleeping environment. Its low

height enhances stability and reduces safety concerns, while the integrated ladder offers convenient access.

Key Features and Benefits

- **Low Loft Design:** Provides enhanced stability and a lower profile for easier access and reduced fall height.
- **Spacious Under-Bed Area:** The generous space beneath the loft bed can be utilized for storage, a play area, or additional furniture, optimizing room functionality.
- **Integrated Ladder:** Features a wider width and solid support for comfortable and safe climbing.
- **High Guard Rails:** Surrounding the sleeping area, these guard rails provide essential protection against accidental falls.
- **No Box Spring Required:** The bed platform is supported by 13 poplar plywood slats, providing ample mattress support without the need for a box spring.



An assembled view of the white Bellemave Full Low Loft Bed, showcasing its low profile and the open space beneath, suitable for play or storage.



Another perspective of the assembled loft bed, emphasizing the protective guardrails and the versatile space available beneath the sleeping area.

MAINTENANCE

Proper maintenance will ensure the longevity and safety of your Bellemave Full Low Loft Bed.

Cleaning

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- Dry immediately with a clean cloth to prevent moisture damage.

Regular Inspection

- Periodically check all bolts, screws, and connections to ensure they are tight. Retighten as necessary.
- Inspect the ladder for any signs of wear or damage.

- Examine the wooden frame and slats for cracks or structural weaknesses. Address any issues promptly.

TROUBLESHOOTING

This section addresses common issues you might encounter with your loft bed.

Bed Wobbles or Feels Unstable

- **Solution:** Ensure all assembly hardware (bolts, screws) are fully tightened. Check that the bed is placed on a flat, even surface. Uneven flooring can cause instability.

Missing or Unlabeled Hardware/Parts

- **Solution:** Before assembly, carefully sort all parts and hardware according to the included assembly guide. If any parts are genuinely missing or incorrectly labeled, contact Bellemave customer support.

Difficulty Assembling Parts

- **Solution:** Double-check the assembly instructions to ensure parts are oriented correctly. Sometimes, a part may appear similar but has a specific direction for installation. Do not force components together.

SPECIFICATIONS

Brand	Bellemave
Model Number	FST00211-F-AK1
Item Type Name	Low Loft Bed
Size	Full
Color	White With Ladder
Material	Wood (Premium Rubber Wood and Composite Wood)
Furniture Finish	White (Lacquered)
Product Dimensions (L x W x H)	78.6" x 56.3" x 44.3"
Under-Bed Clearance	29.6"
Compatible Mattress Size	Full
Special Feature	No Box Spring Needed
Included Components	Headboard, Slats
Item Weight (Package)	40 Pounds
Required Assembly	Yes

WARRANTY AND SUPPORT

For warranty information or customer support regarding your Bellemave Full Low Loft Bed, please refer to the

documentation included with your purchase or contact the retailer/manufacturer directly. Keep your purchase receipt for warranty claims.

For further assistance, you may visit the Bellemave Store online:[Bellemave Store](#)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question