

Vintage T9

Generic Vintage T9 Professional Hair Trimmer User Manual

Model: Vintage T9

INTRODUCTION

Thank you for choosing the Generic Vintage T9 Professional Hair Trimmer. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new device. Please read it thoroughly before first use and retain it for future reference.

The Vintage T9 Electric Hair Clipper is designed for various applications, including personal grooming, professional styling, and household use. It features a durable stainless steel blade and a long-lasting battery for extended use.

SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions:

- Always unplug the trimmer before cleaning.
- Keep the trimmer away from water sources. Do not use it near bathtubs, showers, basins, or other vessels containing water.
- Do not use on infants or near the face of young children.
- Always keep fingers away from the blades during operation.
- Always follow the recommended cleaning and maintenance procedures.
- Supervise children when the trimmer is in use or within their reach. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate the trimmer with a damaged cord or plug, or if it is not working properly, has been dropped, or damaged.
- Use this appliance only for its intended use as described in this manual.

PACKAGE CONTENTS

Please check the package for the following items:

- Vintage T9 Professional Hair Trimmer

- 4 Guide Combs (various sizes)
- USB Charging Cable

PRODUCT OVERVIEW

The Vintage T9 Trimmer features an all-metal body with an elegant dragon pattern engraving. It is equipped with sharp stainless steel blades for precise trimming.



Image: Close-up view of the Vintage T9 Trimmer highlighting its stainless steel cutter head, embossed dragon design, and the hidden USB charging port located at the bottom of the device.



Image: Diagram illustrating key features of the Vintage T9 Trimmer, including its stainless steel blades, sharp teeth, powerful motor, all-metal body, bottom USB charging port, and the included set of four limit combs.

- **Stainless Steel Blades:** Ensures durability and precise cutting.
- **All-Metal Body:** Provides a premium feel and robust construction.
- **Powerful Motor:** Delivers consistent cutting power.
- **USB Charging:** Convenient charging via a bottom port.
- **Guide Combs:** Four included combs for various hair lengths.

SETUP

Charging the Trimmer

1. Locate the USB charging port at the bottom of the trimmer.
2. Connect the provided USB charging cable to the trimmer's port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, wall adapter, power bank).

4. Allow the trimmer to charge fully before first use. A full charge provides approximately 90 minutes of runtime.

Attaching Guide Combs

1. Ensure the trimmer is turned off.
2. Select the desired guide comb for your preferred hair length.
3. Align the comb with the trimmer blade and push it firmly until it clicks into place.
4. To remove, gently pull the comb away from the blade.

OPERATING INSTRUCTIONS

Basic Operation

1. Ensure the trimmer is fully charged.
2. Press the power button to turn the trimmer on.
3. Hold the trimmer at a comfortable angle against the hair.
4. Move the trimmer slowly and steadily against the direction of hair growth for an even cut.
5. Press the power button again to turn the trimmer off after use.

Hair Trimming and Styling

The Vintage T9 Trimmer is suitable for various uses, including:

- **Beard Grooming:** Use without a guide comb for precise edging or with a comb for length.
- **Hair Trimming:** Attach the appropriate guide comb for desired hair length.
- **Professional Haircuts:** Ideal for detailing, outlining, and fading.




Image: A person using the Vintage T9 Trimmer to precisely trim hair, illustrating its application for detailed styling and grooming.

MAINTENANCE

Cleaning the Trimmer

Regular cleaning ensures optimal performance and hygiene.

1. Ensure the trimmer is turned off and unplugged from the charging cable.
2. Remove any attached guide comb.
3. Use the provided cleaning brush to remove loose hairs from the blades and the trimmer body.
4. The clipper is washable. You may rinse the blades under running water. Ensure the trimmer body is not submerged.
5. Allow the blades to air dry completely before reattaching combs or storing the trimmer.
6. Periodically apply a small drop of clipper oil (not included) to the blades to maintain sharpness and smooth operation.

Storage

Store the trimmer in a cool, dry place, away from direct sunlight and moisture. Keep it out of reach of children.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully using the provided USB cable.
Blades pull hair or cut unevenly.	Blades are dirty or dull. Hair buildup.	Clean the blades thoroughly. Apply clipper oil. Ensure blades are properly aligned.
Trimmer makes unusual noise.	Blades require lubrication. Internal issue.	Apply clipper oil to the blades. If noise persists, contact customer support.
Trimmer does not charge.	Faulty cable or power source. Charging port obstruction.	Try a different USB cable or power source. Check the charging port for debris.

SPECIFICATIONS

- **Model Name:** Vintage T9
- **Product Dimensions:** 7 x 1.5 x 7 inches
- **Weight:** 2.57 ounces
- **Blade Material:** Stainless Steel
- **Body Material:** Metal
- **Power Source:** Battery Powered (USB Charging)
- **Runtime:** Approximately 90 minutes (maximum)
- **Included Components:** Trimmer, 4 Guide Combs, Charging Cable
- **Recommended Uses:** Beard Grooming, Hair Trimming, Personal Grooming, Professional Styling
- **Target Audience:** Home Users, Professional Barbers, Stylists

CUSTOMER SUPPORT

For any questions, concerns, or issues not covered in this manual, please contact your retailer or the manufacturer for assistance. Please have your product model name (Vintage T9) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question