

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [KMBZOOPER](#) /
- › [KMBZOOPER Car Power Master Window Switch User Manual](#)

## KMBZOOPER W206 W254 W214 W223 Car Power Master Window Switch Replacement Fit for Benz C200 E300 S400

# KMBZOOPER Car Power Master Window Switch User Manual

Model: W206 W254 W214 W223 Replacement Switch

## INTRODUCTION

---

This user manual provides essential information for the installation, operation, and maintenance of your KMBZOOPER Car Power Master Window Switch. Please read this manual thoroughly before installation to ensure proper function and longevity of the product. This switch is designed as a direct replacement for the original power window master switch in compatible Mercedes-Benz models.

## PRODUCT OVERVIEW

---

The KMBZOOPER Car Power Master Window Switch is a high-quality replacement component for your vehicle's window control system. It is engineered to provide reliable and smooth operation for your electric power windows.



Figure 1: Front view of the KMBZOCPER Car Power Master Window Switch. This image displays the overall design and appearance of the replacement switch.



**Weight : 25.2g**

Figure 2: Dimensions of the KMBZOCPER Car Power Master Window Switch. This image illustrates the length (50mm), width (28mm), and height (40mm) of the switch, along with its weight (25.2g).



1 Pc

Figure 3: The KMBZOCPER Car Power Master Window Switch, indicating it is supplied as a single piece.

### Key Features:

- **Premium Quality Material:** Constructed from high-quality materials for durability and long-lasting performance.
- **Exceptional Performance:** Ensures smooth and efficient operation of your vehicle's electric power windows.
- **Perfect Replacement:** Engineered to seamlessly fit and function as a direct replacement for the original switch.

### SETUP AND INSTALLATION

This power window switch is designed for user-friendly installation. While professional assistance is not typically required, basic automotive repair knowledge and tools are recommended. Always ensure the vehicle's battery is disconnected before beginning any electrical work.

1. **Safety First:** Park the vehicle on a level surface and engage the parking brake. Disconnect the negative terminal of the vehicle's battery to prevent electrical shorts during installation.
2. **Access the Old Switch:** Carefully remove the door panel or trim piece that houses the existing power window switch. This usually involves removing screws and gently prying clips. Refer to your vehicle's specific service manual

for precise instructions on trim removal.

3. **Disconnect Old Switch:** Once the old switch is accessible, disconnect the electrical connector(s) by pressing any release tabs and pulling firmly.
4. **Remove Old Switch:** Unclip or unscrew the old switch from its housing.
5. **Install New Switch:** Insert the new KMBZOCOPER switch into the housing, ensuring it clicks securely into place.
6. **Connect Electrical Connector:** Reconnect the electrical connector(s) to the new switch. Ensure a firm connection.
7. **Test Functionality:** Before reassembling the door panel, reconnect the vehicle's battery. Test the functionality of the new window switch for all windows it controls (up, down, auto functions if applicable).
8. **Reassemble:** If the switch functions correctly, carefully reattach the door panel or trim piece, ensuring all clips and screws are properly secured.

**Note:** Always ensure compatibility with your vehicle model before purchasing and installing. This switch is suitable for the front left driver side in compatible Mercedes-Benz models (W206, W254, W214, W223, C200, E300, S400).

## OPERATING INSTRUCTIONS

---

Operating the KMBZOCOPER Car Power Master Window Switch is straightforward and mirrors the functionality of your original equipment.

- **To Lower a Window:** Gently press down on the corresponding switch button. Release the button when the window reaches the desired position.
- **To Raise a Window:** Gently pull up on the corresponding switch button. Release the button when the window reaches the desired position.
- **Auto Up/Down (if applicable):** For windows with an auto function, press or pull the button firmly past the first detent and release. The window will automatically go all the way down or up. To stop the window mid-travel, briefly press or pull the button again.

## MAINTENANCE

---

The KMBZOCOPER Car Power Master Window Switch requires minimal maintenance to ensure its longevity and proper function.

- **Cleaning:** Periodically wipe the surface of the switch with a soft, damp cloth to remove dust and grime. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic and electronic components.
- **Avoid Liquid Exposure:** Prevent liquids from spilling onto or into the switch, as this can cause electrical damage.
- **Regular Inspection:** Occasionally check the switch for any signs of physical damage or loose connections.

## TROUBLESHOOTING

---

If you encounter issues with your KMBZOCOPER Car Power Master Window Switch, consider the following troubleshooting steps:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Window does not move when switch is pressed.	<ul style="list-style-type: none"> <li>Loose electrical connection.</li> <li>Blown fuse.</li> <li>Faulty window motor.</li> <li>Incorrect switch installation.</li> </ul>	<ul style="list-style-type: none"> <li>Check and secure all electrical connections to the switch.</li> <li>Inspect the vehicle's fuse box for a blown window fuse and replace if necessary.</li> <li>If the motor is suspected, professional diagnosis may be required.</li> <li>Review installation steps to ensure correct fitment.</li> </ul>
Window moves slowly or intermittently.	<ul style="list-style-type: none"> <li>Friction in window tracks.</li> <li>Weak electrical connection.</li> <li>Aging window motor.</li> </ul>	<ul style="list-style-type: none"> <li>Clean and lubricate window tracks.</li> <li>Verify secure electrical connections.</li> <li>Consider professional inspection of the window motor.</li> </ul>
Switch feels loose or unresponsive.	<ul style="list-style-type: none"> <li>Improper seating in housing.</li> <li>Internal damage to switch.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure the switch is fully clipped into its housing.</li> <li>If physical damage is apparent, replacement may be necessary.</li> </ul>

If these steps do not resolve the issue, it is recommended to consult a qualified automotive technician.

## SPECIFICATIONS

Attribute	Value
Brand	KMBZOCPER
Model Name	W206 (as per product description, also compatible with W254, W214, W223)
Item Type	Window Control Switch
Special Features	Replacement
Material	Plastic
Item Diameter	2.8cm
Item Weight	25.2g (0.89 ounces)
Item Height	4cm
Item Width	2.8cm
Item Length	5cm
Part Number (NO.)	22390519039051

Attribute	Value
Compatibility	Fit for Benz C200 E300 S400 (W206, W254, W214, W223 models)

## WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the terms and conditions provided by the seller at the time of purchase. Typically, replacement parts like this switch come with a limited warranty against manufacturing defects.

**Return Policy:** This product is eligible for a 30-day return/replacement policy from the date of purchase, as per standard retail terms.

**Customer Support:** For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact the seller directly through the platform where the purchase was made. The seller for this product is ZHONGX SHOP.

You may also consider purchasing extended protection plans for additional coverage, if available, such as 3-Year or 4-Year Protection Plans.



© 2025 KMBZOCOPER. All rights reserved.

*Information in this manual is subject to change without notice.*