

[manuals.plus](#) /› [roborock](#) /› [roborock H60 Ultra Cordless Stick Vacuum Cleaner User Manual](#)**roborock H60 Ultra**

# roborock H60 Ultra Cordless Stick Vacuum Cleaner User Manual

Model: H60 Ultra | Brand: roborock

## 1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before using the roborock H60 Ultra Cordless Stick Vacuum Cleaner. Keep it for future reference.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dustbin and/or filters in place.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not handle charger or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Turn off all controls before unplugging.
- Exercise extra care when cleaning on stairs.
- Do not use to pick up large, hard, or sharp objects.

## 2. PACKAGE CONTENTS

The roborock H60 Ultra package includes the following components:

- roborock H60 Ultra Vacuum (Main Body)
- Adapter
- Bendable Tube
- Multi-Surface Brush (Floor Brush)
- Motorized Mini-Brush
- 2-in-1 Crevice Brush

- Wall Mount
- User Manual

## Specialized Motorized Mini-Brush

Perfect for cleaning bedding, blankets, fabrics for a deeper clean



Figure 1: All components included in the roborock H60 Ultra package, laid out for easy identification.

### 3. PRODUCT OVERVIEW

The roborock H60 Ultra is a powerful and versatile cordless stick vacuum cleaner designed for efficient home cleaning.

#### Key Features:

- **Powerful 210AW Suction:** Lifts embedded dirt, debris, and pet hair from various surfaces.
- **Zero-Tangle Brush:** Features a shark tooth-inspired design to actively detangle hair, minimizing maintenance.
- **Extended 90-Minute Runtime:** High-capacity pouch battery allows for extensive cleaning on a single charge. The battery is detachable for easy swapping.
- **Flexible 90° Bendable Tube:** Enables easy access under furniture and into tight corners without bending.
- **140° Green LED Dust Detection:** Illuminates fine dust and hidden particles on floors for thorough cleaning.
- **5-Stage Filtration & 9-Cyclone Technology:** Captures 99.95% of fine dust, maintains strong suction, and reduces filter clogs.

- **Three Cleaning Modes & LED Display:** Select from ECO, MED, and MAX modes. The LED screen displays the current mode and battery level.
- **Versatile Tools:** Includes a Multi-Surface Brush, Motorized Mini-Brush, and 2-in-1 Crevice Brush for various cleaning tasks.



Figure 2: The roborock H60 Ultra vacuum cleaner in its full assembly with various attachments.

Video 1: Demonstrates the precision and maneuverability of the Roborock H60 Ultra during cleaning tasks.

## 4. SETUP AND ASSEMBLY

### 4.1 Initial Charging

Before first use, fully charge the vacuum cleaner. Connect the adapter to the charging port on the main body or the wall mount. The LED display will indicate charging status.



Figure 3: The detachable pouch battery being inserted into the main vacuum body for charging or use.

## 4.2 Assembling the Vacuum

1. Insert the Bendable Tube into the main body until it clicks into place.
2. Attach the desired cleaning head (e.g., Multi-Surface Brush) to the other end of the Bendable Tube until it clicks.
3. For handheld cleaning, attach the Motorized Mini-Brush or 2-in-1 Crevice Brush directly to the main body.

## 4.3 Wall Mount Installation

The included wall mount allows for convenient storage and charging. Choose a suitable location near a power outlet and secure the wall mount using appropriate fasteners (not included, but typically screws and wall anchors).



Figure 4: The roborock H60 Ultra conveniently stored on its wall mount, ready for charging.

# 5. OPERATING INSTRUCTIONS

## 5.1 Power On/Off and Mode Selection

- Press the power button on the handle to turn the vacuum on or off.
- Use the mode selection button on the handle to cycle through ECO, MED, and MAX cleaning modes. The LED display will show the selected mode.

## 5.2 Cleaning Tips

- For general cleaning on hard floors and carpets, use the Multi-Surface Brush in ECO or MED mode.
- For deep cleaning or stubborn dirt, switch to MAX mode.
- Utilize the 90° Bendable Tube to easily clean under beds, sofas, and other low-clearance areas.
- The 140° Green LED Dust Detection feature helps reveal hidden dust, ensuring no spot is missed.
- For pet hair on upholstery or stairs, attach the Motorized Mini-Brush directly to the main body.
- The 2-in-1 Crevice Brush is ideal for tight spaces, corners, and car interiors.

# Freedom of Movement

Clean everywhere without bending over



Figure 5: The flexible bendable tube allows the vacuum to reach under furniture for comprehensive cleaning.

Video 2: An overview of the roborock H60 Ultra Stick Vacuum Cleaner's features and usage.

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### 6.1 Emptying the Dustbin

Empty the dustbin after each use or when the MAX line is reached. Press the dustbin release button and empty contents into a trash receptacle.

### 6.2 Cleaning Filters

The 5-stage filtration system includes washable filters. Regularly remove and rinse the filters under running water. Allow them to air dry completely before reinserting.

## 5-Stage Filtration for Cleaner Air



\*Tested by TÜV Rheinland based on ASTM F1977-22 standard. Test report number: CN253JHD001.

Figure 6: Exploded view of the 5-stage filtration system, highlighting the Multi-Cyclone Component, Metal Mesh, Cyclone Filtration, Sponge Filter, and Post-Motor Filter.

### 6.3 Cleaning the Brush Roll

The Zero-Tangle Brush is designed to prevent hair tangles. However, periodically check the brush roll for any accumulated hair or debris and remove it as needed. The brush roll can be easily detached for cleaning.

# Anti-Tangle Brush with Shark Tooth Design

Prevents hair tangling with 0% tangle rate while efficiently cleaning hard floors



Figure 7: The Anti-Tangle Brush with its unique shark tooth design, minimizing hair entanglement.

## 7. TROUBLESHOOTING

If you encounter any issues with your roborock H60 Ultra, please refer to the following common problems and solutions:

- **No Power:** Ensure the battery is fully charged. Check if the adapter is properly connected.
- **Reduced Suction:** Check if the dustbin is full and needs emptying. Inspect filters for clogs and clean them. Ensure the brush roll is free of obstructions.
- **Brush Roll Not Rotating:** Check for tangled hair or debris obstructing the brush roll. Ensure the cleaning head is properly attached.
- **Unusual Noise:** Turn off the vacuum and check for any foreign objects in the brush roll or air ducts.

For further assistance, please contact roborock customer support.

## 8. SPECIFICATIONS

| Feature | Specification |
|---------|---------------|
|---------|---------------|

|                      |  |
|----------------------|--|
| Brand                | robolock   |
| Model Name           | H10A1A (H60 Ultra)   |
| Suction Power        | 210AW  |
| Battery Life         | Up to 90 minutes   |
| Dustbin Capacity     | 500 Milliliters  |
| Filtration System    | 5-Stage Filtration & 9-Cyclone Tech  |
| Special Features     | Lightweight, 90° Bendable Tube, 140° Green LED Dust Detection, LED Display |
| Recommended Surfaces | Carpet, Hard Floor   |
| Item Weight          | 7.7 pounds   |
| Product Dimensions   | 9.8" L x 11" W x 45" H   |

## 9. WARRANTY AND SUPPORT

The robolock H60 Ultra comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting, or warranty claims, please visit the official robolock website or contact their customer service directly.