

[Manuals.plus](#) /

› [Soohow](#) /

› Soohow RC005 Upholstered Rocker Recliner Chair User Manual

Soohow RC005

Soohow RC005 Upholstered Rocker Recliner Chair User Manual

Model: RC005 | Brand: Soohow

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- **Maximum Weight Recommendation:** This recliner chair has a maximum weight recommendation of 330 pounds (150 kg). Do not exceed this limit to prevent damage or injury.
- Always ensure the chair is stable and fully assembled before use, especially when reclining.
- Keep children and pets away from the moving parts of the recliner mechanism.
- Avoid standing on the footrest or armrests.
- Do not place fingers or hands near the reclining mechanism to prevent pinching.

PACKAGE CONTENTS

Upon opening the package, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support immediately.

- Main Chair Body (Seat with armrests and reclining mechanism)
- Backrest
- Legs (if separate)
- Hardware Pack (bolts, washers, Allen wrench)
- Assembly Instructions Sheet (separate document)

ASSEMBLY INSTRUCTIONS

This product requires assembly. Please refer to the separate assembly instructions sheet included in your package for detailed, step-by-step guidance. The general assembly process typically involves:

1. Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches.
2. Attach the backrest to the main chair body by sliding it onto the metal brackets until it clicks into place.

3. Attach any separate legs to the base of the chair using the provided hardware. Ensure all bolts are tightened securely.
4. Confirm all connections are secure before using the chair.

Note: For optimal stability and safety, it is recommended to have two people for assembly.

OPERATING THE RECLINER

The Soohow RC005 recliner chair offers adjustable comfort with a simple lever mechanism.

Reclining and Footrest Operation

- To recline the chair and extend the footrest, locate the lever on the side of the chair (typically on the right side). Pull the lever upwards.
- Lean back gently to achieve your desired reclining angle, between 110° and 160°. The chair offers multiple positions for reading, watching TV, or sleeping.
- To return to the upright position and retract the footrest, push the footrest down with your legs until it locks into place. Simultaneously, lean forward to bring the backrest upright.



This image details the key features of the Soohow Recliner Chair RC005, including its 110°-160° adjustable recline, convenient side pocket, extended footrest, soft cushion seat, and thickened armrests.

Side Pocket Usage

The integrated side pocket provides convenient storage for small items such as remote controls, magazines, or books.



An overhead view of the Sohow Recliner Chair RC005 in its fully reclined position, demonstrating the extended footrest and backrest angle.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your recliner chair.

Upholstery Care (Chenille Fabric)

- **Regular Cleaning:** Vacuum the fabric regularly using a soft brush attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for chenille, testing on an inconspicuous area first. Follow the cleaner's instructions carefully.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading. Position your chair away from direct sun exposure or use window coverings.

Frame and Mechanism Care

- Periodically check all bolts and screws to ensure they are tight. Retighten if necessary.
- Avoid spilling liquids on the reclining mechanism. If a spill occurs, wipe it dry immediately.
- Do not apply excessive force to the reclining mechanism. Operate it smoothly.

TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Footrest is difficult to close or retract.	Mechanism stiffness; insufficient downward pressure.	Apply firm, consistent downward pressure with your legs on the footrest while leaning forward. Ensure no obstructions are blocking the mechanism. Regular use may help loosen the mechanism.
Armrests feel unstable or detach.	Velcro attachment is loose or worn.	Ensure the velcro on the armrests is securely fastened. Avoid putting excessive weight or pressure on the armrests when getting up or sitting down, as this can dislodge the velcro.
Chair makes unusual noises (squeaking, grinding).	Loose bolts; mechanism needs lubrication.	Check and tighten all visible bolts. If the noise persists, a small amount of silicone-based lubricant can be applied to the moving parts of the reclining mechanism (avoiding fabric).
Chair does not recline smoothly.	Obstruction in mechanism; lever issue.	Inspect the area around the reclining mechanism for any obstructions. Ensure the reclining lever is fully engaged when pulled.

If these solutions do not resolve the issue, please contact Soohow customer support for further assistance.

PRODUCT SPECIFICATIONS

Dimensions



This image illustrates the key dimensions of the Soohow Recliner Chair RC005, including height, width, depth, seat height, and reclined length.

Specification	Detail
Brand	Soohow
Model Number	RC005
Color	Chenille, Beige
Product Dimensions (Upright)	39"D x 36"W x 41.7"H (99cm D x 91cm W x 106cm H)
Item Weight	81 pounds (36.7 kg)
Maximum Weight Recommendation	330 Pounds (150 kg)
Material	Chenille fabric, Foam fill
Reclining Position Count	3 (adjustable 110°-160°)

Specification	Detail
Included Components	Cushion
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

Soohow is committed to providing quality products and customer satisfaction. While specific warranty details are typically provided with your purchase documentation, we offer comprehensive after-sales support.

- **Missing Parts:** If any parts are missing from your package upon delivery, please contact us immediately.
- **Product Issues:** For any operational issues, defects, or concerns not covered in the troubleshooting section, please reach out to our customer service team.
- **Contact Information:** Please refer to your purchase receipt or the seller's information on the platform where you purchased the product for direct contact details.

We strive to ensure you have a positive experience with your Soohow recliner chair.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question