

[Manuals.plus](#) /

› [LEDIARY](#) /

› LEDIARY 24 Inch Low Profile Ceiling Fan with Lights and Remote Instruction Manual

LEDIARY 24 Inch Low Profile

LEDIARY 24 Inch Low Profile Ceiling Fan with Lights and Remote

Instruction Manual - Model: 24 Inch Low Profile

1. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Retain this manual for future reference.

1.1 General Safety

- Ensure the power supply is disconnected at the circuit breaker before installation, maintenance, or cleaning.
- Installation should be performed by a qualified electrician or a professional to ensure safety and compliance with local electrical codes.
- Do not bend the fan blades during installation or cleaning.
- Keep children away from the fan during operation and maintenance.
- Do not insert any objects into the fan blades while the fan is operating.

1.2 Electrical Safety

- This product is designed for 120 Volts AC power supply.
- Ensure all electrical connections are secure and properly insulated.
- Consult a qualified electrician if you are unsure about wiring procedures.

2. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- Main Body Components (4 parts)
- Ceiling Plate (1)
- Fan Blade Set (8 blades)
- DC Motor (1)
- Remote Control (1, with 2 AAA batteries included)
- Integrated LED Lights

- Instruction Manual (this document)
- Mounting Hardware (screws, wire nuts, etc.)

3. SPECIFICATIONS

Feature	Specification
Brand	LEDIARY
Model Name	24 Inch Low Profile
Product Dimensions	24"D x 24"W x 5.2"H
Color	White
Power Source	DC Motor
Voltage	120 Volts
Number of Blades	8
Number of Fan Speeds	6
Light Output	3200 Lumens
Color Temperature	3000K (Warm), 4500K (Natural), 6000K (Cold White)
Dimming Range	10%-100%
Control Method	Remote, Bluetooth App
Special Features	3CCT, 6 Speed, Dimmable, Reversible DC Motor, Timer, Memory Function
Room Type	Bedroom, Kids Room, Kitchen, Living Room, Study Room
Indoor/Outdoor Usage	Indoor
Item Weight	7.41 pounds
Batteries	2 AAA batteries (included for remote)

4. SETUP AND INSTALLATION

Professional installation is recommended for this ceiling fan. Ensure all safety precautions are followed.

4.1 Pre-Installation Checklist

- Verify that the power supply is turned off at the circuit breaker.
- Ensure you have all necessary tools (screwdriver, wire strippers, ladder, etc.).
- Confirm all package contents are present and undamaged.

4.2 Assembly Overview

The fan features a modular design for assembly. The main body components, fan blades, and DC motor will need to be assembled before mounting.



Figure 1: Modular components for quick assembly.

4.3 Mounting Steps

1. **Secure Ceiling Plate:** Mount the ceiling plate securely to the existing ceiling junction box using the provided screws. Ensure it is firmly attached and can support the fan's weight.
2. **Connect Wiring:** Connect the electrical wires from the ceiling to the fan's wiring according to the wiring diagram in the full installation guide (not provided here, but typically included with the product). Ensure proper grounding and secure all connections with wire nuts.
3. **Assemble Fan Body:** Assemble the main body components and attach the 8 fan blades to the DC motor. Refer to the detailed component image for guidance.
4. **Attach Fan Assembly:** Carefully lift the assembled fan and attach it to the mounted ceiling plate. Secure all connections and ensure the fan is firmly mounted and stable.
5. **Restore Power:** Once installation is complete and all connections are checked, restore power at the circuit breaker.



Figure 2: Detailed view of fan components and construction.

5. OPERATING INSTRUCTIONS

The LEDIARY ceiling fan offers versatile control options via remote and a Bluetooth app.




Figure 3: Remote and App Control Interface.

5.1 Remote Control Functions

- **Power On/Off:** Press the dedicated power button to turn the fan and light on or off.
- **Fan Speed Adjustment:** Select from 6 fan speeds. Speeds 1-2 provide a soft wind, 3-4 a natural wind, and 5-6 a cool wind.
- **Light Settings:**
 - **Color Temperature (CCT):** Cycle through 3000K (Warm), 4500K (Natural), and 6000K (Cold White) settings.
 - **Brightness Dimming:** Adjust the light brightness smoothly from 10% to 100%.
 - **Night Light:** Activate a low-intensity light mode suitable for nighttime.
- **Timer Setting:** Set a 2-hour sleep timer for automatic shutdown.
- **Reversible DC Motor:** Switch the fan direction for seasonal use. Downdraft mode (Summer) creates a cooling breeze, while updraft mode (Winter) helps circulate warm air.




Figure 4: Adjustable Color Temperature and Dimming.

24 Inch Ceiling Fans with Lights



Figure 5: Reversible All-Season Motor Function.

5.2 Bluetooth App Control

- **Download App:** Search for the LEDIARY app on your smartphone's app store.
- **Enable Bluetooth:** Ensure Bluetooth is active on your mobile device.
- **Pairing:** Follow the in-app instructions to pair your fan with the Bluetooth app. Typically, this involves ensuring the light switch is on, turning the fan off with the remote, and then turning it on via the app to initiate pairing.
- **Full Control:** The app provides comprehensive control over fan speeds, light settings (CCT and dimming), timer functions, and the reversible motor.

5.3 Memory Function

The fan is equipped with a memory function. When the fan is turned off and then back on, it will recall and resume the last used color temperature and brightness settings.

5.4 Quiet Operation

The DC motor is designed for low noise operation, typically below 30dB, ensuring a comfortable environment.




Figure 6: Low Noise Design for Quiet Operation.

6. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

6.1 Cleaning

- Always turn off the power supply at the circuit breaker before cleaning.
- Wipe the fan blades, motor housing, and light fixture with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.
- Ensure the fan is completely dry before restoring power.

6.2 General Care

- Periodically check all mounting screws and electrical connections to ensure they remain tight.
- Keep the fan blades free from dust and debris to maintain efficient airflow and prevent imbalance.

7. TROUBLESHOOTING

If you encounter any issues with your LEDIARY ceiling fan, refer to the following common problems and solutions.

- **Fan does not turn on:**
 - Check if the power supply is on at the circuit breaker.
 - Ensure all wiring connections are secure.
 - Verify that the remote control batteries are correctly installed and have sufficient charge.
- **Light does not turn on or dim:**
 - Confirm the power supply is active.
 - Check remote control batteries.
 - Ensure the light setting is not at the minimum brightness level.
- **Fan makes excessive noise:**
 - Tighten all mounting screws.
 - Check for any obstructions around the fan blades.
 - Ensure the fan blades are balanced and the fan is installed on a flat, stable surface.
- **Remote control not responding:**
 - Replace the remote control batteries.
 - Ensure there are no physical obstructions between the remote and the fan's receiver.
 - If necessary, re-pair the remote control with the fan (refer to the full manual for specific pairing instructions).
- **Bluetooth app control not working:**
 - Verify that Bluetooth is enabled on your mobile device.
 - Ensure the LEDIARY app is updated to the latest version.
 - Attempt to re-pair the fan with the app following the in-app instructions.

8. WARRANTY AND SUPPORT

LEDIARY is committed to providing quality products and customer satisfaction.

- **Warranty:** This product includes a 2-year after-sales service.
- **Customer Support:** If you have any issues, questions, or require technical assistance, please contact LEDIARY customer service. We aim to respond to all inquiries within 24 hours.

9. PRODUCT VIDEO

Watch this video for a visual overview of the LEDIARY 24 Inch Low Profile Ceiling Fan.

Your browser does not support the video tag.

Video: Overview of the LEDIARY 24 Inch Low Profile Ceiling Fan's features and design.

© 2026 LEDIARY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F4KFB9DG>

More documents and user manuals: <https://manuals.plus/>