

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rosieres](#) /

› [Rosières RFC3O3351IN Catalytic Oven User Manual](#)

## Rosieres RFC3O3351IN

# Rosières RFC3O3351IN Catalytic Oven User Manual

Model: RFC3O3351IN | Brand: Rosières

## 1. INTRODUCTION AND OVERVIEW

The Rosières RFC3O3351IN is a high-performance built-in electric oven designed for efficiency, simplicity, and modern aesthetics. Featuring a catalytic cleaning system, an intuitive LED display, and 8 cooking functions including circulating heat, grill, and defrost, this oven offers versatile cooking options and easy maintenance. Its elegant stainless steel finish integrates seamlessly into any kitchen design.




Figure 1.1: Front view of the Rosières RFC3O3351IN catalytic oven, showcasing its sleek design and control panel.

## 2. SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the oven is properly grounded. Do not use extension cords. Disconnect power before any maintenance or cleaning.
- **Hot Surfaces:** The oven and its accessible parts become very hot during use. Always use oven mitts when handling hot dishes or parts. Keep children away.
- **Ventilation:** Ensure adequate ventilation around the oven as specified in the installation instructions. Do not block ventilation openings.
- **Cleaning:** Use only recommended cleaning agents. Do not use abrasive cleaners or sharp metal scrapers to clean the oven door glass, as they can scratch the surface, which may result in shattering.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons

with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

### 3. PRODUCT FEATURES

The Rosières RFC3O3351IN oven is equipped with features designed for convenience and optimal cooking results:

- **Catalytic Cleaning:** Automatic catalytic cleaning for simplified maintenance.
- **Generous Capacity:** 74-liter volume, suitable for various cooking needs.
- **8 Cooking Functions:** Includes circulating heat for homogeneous cooking, grill, and defrost.
- **Intuitive LED Programmer:** Clear and easy-to-use LED display with timer function.
- **User-Friendly Controls:** Rotary knobs with retractable handles for precise control and a sleek appearance.
- **Energy Efficiency:** Class A energy rating for reduced energy consumption.
- **Modern Design:** Elegant stainless steel finish.



Figure 3.1: The Rosières RFC3O3351IN oven seamlessly integrated into a kitchen cabinet, highlighting its built-in design.



Figure 3.2: Detailed view of the oven's control panel, showing the LED display and rotary knobs.




Figure 3.3: Energy efficiency label for the Rosières RFC303351IN oven, indicating its Class A rating and 74L capacity.

## 4. INSTALLATION AND SETUP

The Rosières RFC303351IN is a built-in appliance and should be installed by a qualified technician to ensure proper functioning and safety. Refer to the separate installation guide for detailed instructions and dimensions.

- **Cabinet Dimensions:** Ensure the cabinet opening meets the required dimensions for a secure fit.
- **Electrical Connection:** The oven requires a dedicated electrical circuit. Note that the power plug is not supplied with the oven and must be connected to the oven's cabling by a qualified electrician.

- **Ventilation:** Ensure proper air circulation around the oven to prevent overheating.

## 5. OPERATING INSTRUCTIONS

Familiarize yourself with the oven's controls and functions for optimal cooking results.

### 5.1. Control Panel Overview

The control panel consists of two rotary knobs and a central LED display with touch controls.

- **Left Rotary Knob:** Used to select cooking functions (e.g., circulating heat, grill, defrost).
- **Right Rotary Knob:** Used to set the temperature.
- **LED Display:** Shows current time, cooking duration, temperature, and selected functions. The touch controls below the display are used for timer settings and menu navigation.

### 5.2. Basic Operation

1. **Turn On:** Rotate either knob to activate the oven.
2. **Select Function:** Turn the left rotary knob to choose the desired cooking function.
3. **Set Temperature:** Turn the right rotary knob to set the desired temperature. The LED display will show the selected temperature.
4. **Set Timer (Optional):** Use the touch controls on the LED display to set a cooking duration or a delayed start time.
5. **Start Cooking:** The oven will begin heating once the function and temperature are set.
6. **Turn Off:** Rotate both knobs to the 'off' position or wait for the timer to complete.

### 5.3. Cooking Functions

- **Circulating Heat:** Ideal for cooking multiple dishes simultaneously on different levels, ensuring even heat distribution.
- **Grill:** Perfect for browning, toasting, or grilling thin cuts of meat.
- **Defrost:** Gently thaws frozen food using circulating air without heat.
- *Refer to the full manual for details on all 8 functions.*

## 6. CLEANING AND MAINTENANCE

The Rosières RFC3O3351IN oven features a catalytic cleaning system for easy maintenance.

### 6.1. Catalytic Cleaning

The catalytic liners absorb and oxidize grease splashes during normal cooking at temperatures above 200°C (392°F). For optimal performance:

- After cooking, allow the oven to cool slightly.
- If significant grease build-up occurs, run the oven at its maximum temperature for approximately 1 hour to activate the catalytic process.
- Wipe away any remaining ash or residue with a damp cloth once the oven has cooled completely. Do not use abrasive cleaners on catalytic surfaces.

### 6.2. General Cleaning

- **Exterior:** Clean the stainless steel exterior with a soft cloth and a mild, non-abrasive cleaner.

- **Oven Door Glass:** Use a glass cleaner specifically designed for ovens. Avoid harsh chemicals or abrasive materials that could scratch the glass.
- **Accessories:** Remove oven racks and trays and wash them with warm soapy water.

## 7. TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and their potential solutions:

Problem	Possible Cause	Solution
Oven does not heat up.	No power supply; incorrect settings.	Check circuit breaker. Ensure function and temperature are correctly set.
LED display is blank.	Power outage; oven not turned on.	Check power supply. Rotate a knob to activate the display.
Food not cooking evenly.	Incorrect rack position; oven overloaded.	Use recommended rack positions. Avoid overcrowding the oven. Ensure circulating heat function is used for multi-level cooking.
Oven smells during first use.	Residue from manufacturing process.	This is normal. Run the oven empty at maximum temperature for 30-60 minutes before first use to burn off residues. Ensure good ventilation.

## 8. SPECIFICATIONS

Technical specifications for the Rosières RFC3O3351IN Built-in Oven:

Feature	Specification
Brand	Rosières
Model Number	RFC3O3351IN
Type	Electric Built-in Oven
Cleaning Mode	Catalysis
Volume	74 Liters
Number of Functions	8 (including circulating heat, grill, defrost)
Display	LED with Timer
Controls	Rotary Knobs with Retractable Handles
Energy Class	A
Color	Stainless Steel
Dimensions (H x W x D)	59.5 x 59.5 x 57.0 cm

Feature	Specification
Weight	40 Kilograms

## 9. WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your appliance or contact Rosières customer service.

Our responsive customer service team is available to assist you with installation, usage, or any technical support requests. Please have your model number (RFC3O3351IN) and purchase date ready when contacting support.

For further assistance, visit the official Rosières website or contact your local authorized service center.