

- Manuals.plus /
- › Marsail /
 - › Marsail 6-Drawer Wooden Dresser (Natural Oak) Instruction Manual

Marsail YUNSHENG-USAMDC07N-US-59

Marsail 6-Drawer Wooden Dresser (Natural Oak) Instruction Manual

Model: YUNSHENG-USAMDC07N-US-59

- Introduction
- Safety Information
- Setup & Assembly
- Operation
- Care & Maintenance
- Specifications
- Troubleshooting & Support

1. INTRODUCTION

Thank you for choosing the Marsail 6-Drawer Wooden Dresser. This modern storage solution is designed to enhance your bedroom, living room, or hallway with its elegant natural oak finish and practical design. This manual provides essential information for safe assembly, proper use, and effective maintenance to ensure the longevity and optimal performance of your dresser.

Your browser does not support the video tag.

Video 1: Marsail Modern Fluted Dresser Overview. This video provides a general overview of the Marsail Modern Fluted Dresser, highlighting its design and features.

2. SAFETY INFORMATION

To prevent serious or fatal injuries from furniture tip-over, this product must be permanently attached to the wall with the included anti-tip kit. Always ensure the dresser is placed on a stable, level surface. Keep children away from the assembly area. Do not allow children to climb on or play with the dresser. Always open only one drawer at a time to maintain stability.

Stable & Secure

Feel safe even with kids at home,
thanks to the anti-tip design



**Anti-Tip
Strap**



Metal Feet



Figure 2.1: Stable and Secure Design. This image illustrates the anti-tip strap and metal feet designed to enhance the dresser's stability and security, especially in homes with children or pets.



Figure 2.2: Anti-Tip Kit Installation Diagram. This diagram shows the correct method for installing the anti-tip kit to prevent furniture tip-over, contrasting it with an incorrect, unstable setup.

3. SETUP & ASSEMBLY

Before beginning assembly, ensure all parts and hardware are present and undamaged. Refer to the included parts list and hardware diagram. It is recommended to assemble the dresser on a soft, clean surface to prevent scratches. Two people are recommended for assembly.

3.1 Assembly Video Guide

Your browser does not support the video tag.

Video 2: Marsail Fluted Wooden Dresser Assembly. This video provides a detailed, step-by-step guide for assembling your Marsail Fluted Wooden Dresser.

3.2 Key Assembly Steps (Visual Guide)

Below are visual representations of key assembly stages. For complete instructions, please refer to the full assembly video above and the printed manual included with your product.

- Step 1: Prepare Drawer Bottoms.** Attach the necessary hardware to the drawer bottom panels. Ensure all connections are secure.



Figure 3.1: Attaching hardware to drawer bottom panels (C x 6).

- Step 2: Install Drawer Glides.** Secure the drawer glide rails to the side panels of the dresser. Use the provided screws and screwdriver.



Figure 3.2: Installing drawer glide rails (A x 20).

- Step 3: Construct Drawer Sides.** Assemble the side and back panels of the drawers.



Figure 3.3: Assembling drawer side and back panels (B1 x 10, C x 6).

- Step 4: Attach Drawer Fronts.** Secure the fluted drawer fronts to the assembled drawer boxes.



Figure 3.4: Attaching fluted drawer fronts (B1 x 5).

- Step 5: Install Anti-Tip Strap.** Secure the anti-tip strap to the top rear of the dresser.



Figure 3.5: Securing the anti-tip strap to the dresser.

- Step 6: Secure to Wall.** Attach the anti-tip strap to a wall stud or use appropriate anchors for solid concrete walls.

Figure 3.6: Anti-tip strap secured to a wood stud.

Figure 3.7: Anti-tip strap secured to a solid concrete wall.

4. OPERATION

The Marsail 6-Drawer Dresser features smooth-glide drawers for easy access to your belongings. Each drawer is designed for efficient storage of clothing, accessories, blankets, or toys. To open a drawer, gently pull the metal handle. To close, push the drawer firmly until it is fully seated. Avoid overloading drawers to ensure smooth operation and prevent damage to the glide mechanisms.



Figure 4.1: Smooth-Glide Drawers. This image highlights the smooth operation of the drawers, equipped with metal rails for effortless opening and closing.

5. CARE & MAINTENANCE

The dresser is constructed from high-quality, eco-conscious P2 engineered wood with a waterproof, scratch-resistant, and stain-resistant surface. To maintain its appearance and durability:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining, especially on the natural oak finish.
- **Protection:** Use coasters or mats under hot items or liquids to protect the top surface.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking of the wood.




Figure 5.1: Durable and Easy-to-Clean Surface. This image emphasizes the dresser’s robust surface, designed for easy cleaning and resistance to scratches and stains.

6. SPECIFICATIONS

Feature	Detail
Brand	Marsail
Model Name	DRESSER (YUNSHENG-USAMDC07N-US-59)
Product Dimensions	15.7"D x 47.2"W x 31.7"H
Color	Natural Oak
Room Type	Bedroom, Living Room
Assembly Required	Yes
Item Weight	96.3 Pounds
Material	Engineered Wood
Finish Type	Polished
Number of Drawers	6
Included Components	Installation Manuals and Accessories

Figure 6.1: Product Dimensions. This diagram provides detailed measurements for the dresser and its drawers.

7. TROUBLESHOOTING & SUPPORT

7.1 Common Issues

- **Color Variation:** Please note that product colors may vary slightly due to lighting conditions and differences in display equipment. This is normal and not a defect.
- **Drawer Sticking:** Ensure drawers are not overloaded. Check that all glide rails are properly aligned and free of obstructions. Re-tighten any loose screws on the drawer glides or panels.
- **Instability:** Verify that the dresser is on a level surface. Confirm that the anti-tip kit is correctly installed and securely fastened to both the dresser and the wall.

7.2 Customer Support

If you encounter any problems with your Marsail dresser that are not resolved by the troubleshooting steps, or if you have questions regarding assembly or parts, please contact Marsail customer support. Our team is ready to assist you. For assistance, please refer to the contact information provided with your purchase or visit the official Marsail store online.

8. WARRANTY INFORMATION

No specific warranty information is provided in the product details. For details regarding product warranty, please contact Marsail customer support directly or refer to the warranty documentation included with your purchase.

© 2026 Marsail. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F4KSWQ5Z>

More documents and user manuals: <https://manuals.plus/>