

[Manuals.plus](#) /

› [AHENOD](#) /

› AHENOD G16 MP3 Player User Manual

AHENOD G16

AHENOD G16 MP3 Player User Manual

Model: G16

1. INTRODUCTION

Thank you for choosing the AHENOD G16 MP3 Player. This device is designed to provide a versatile and enjoyable multimedia experience, combining high-fidelity audio playback with smart features. This manual will guide you through the setup, operation, and maintenance of your new player.



AHENOD Continuous Music Player: Key features include 2.4G & 5G WiFi, Bluetooth 4.1, Android 9, 2000mAh battery, 144GB storage, MTK 8-core processor, and a 4.02-inch 720 HD screen.

2. PRODUCT OVERVIEW

The AHENOD G16 is an advanced MP3/MP4 player running on Android 9 OS, powered by an MTK 8-core chip. It features a 4.02-inch IPS HD touch screen, offering a clear and responsive interface for all your multimedia needs.

Key Features:

- **Operating System:** Android 9
- **Processor:** MTK 8-core

- **Display:** 4.02-inch IPS HD Touch Screen
- **Storage:** 144GB (16GB ROM + 128GB TF card included), expandable up to 512GB
- **Connectivity:** Wi-Fi (2.4G & 5G), Bluetooth 4.1 (Duplex)
- **Battery:** 2000mAh Li-ion (up to 25 hours music, 5 hours video)
- **Pre-installed Apps:** Spotify, Deezer, Amazon Music, Play Store
- **Special Features:** FM Radio, Parental Control



Front view of the AHENOD G16 MP3 Player.

3. WHAT'S IN THE BOX

Please check the package contents upon unboxing:

- 1 x AHENOD G16 MP3 Player
- 1 x 128GB Micro SD Card (pre-installed or separate)
- 1 x User Manual
- 1 x USB Type-C Charging Cable
- 1 x Earphones
- 1 x Silicone Protective Case
- 1 x Screen Protector (pre-applied or separate)

Google App Store préinstallé

Vous pouvez installer et désinstaller l'application à tout moment pour répondre à vos différents besoins.



The AHENOD G16 MP3 Player shown with included accessories: earphones, USB-C cable, and silicone case.

4. SETUP

4.1 Initial Charge

Before first use, fully charge the device using the provided USB Type-C cable and a compatible USB power adapter (not included). The charging indicator will show progress.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button on the side of the device until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select "Power Off" from the options on the screen.

4.3 Wi-Fi Connection

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list and enter the password if prompted.

4.4 Bluetooth Pairing

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth **On**.
3. Ensure your Bluetooth device (headphones, speaker) is in pairing mode.
4. Select your device from the list of available devices to pair.



Duplex Bluetooth 4.1: Offers stronger stability and improved compatibility for connecting various Bluetooth devices.

5. OPERATING INSTRUCTIONS

5.1 Music Playback

The device supports various audio formats including MP3, WAV, APE, FLAC, AAC, OGG, and WMA. Use the pre-installed music player app or download your preferred streaming service from the Play Store.

- **Playing Music:** Open the music app, browse by folder, artist, or album, and select a song to play.
- **Playback Modes:** Sequential play, single song loop, and shuffle playback modes are available.

A7ENOD

Lecteur de musique en continu



WIFI 2.4G&5G



Bluetooth 4.1



Android 9.0



2000mAh



144 Go de
stockage



MTK 8 cœurs



Écran de 4,02
pouces



720 HD



High Fidelity Sound: Supports MP3, WAV, APE, FLAC, AAC, OGG, WMA formats. Features sequential play, single song loop, and shuffle playback modes.

5.2 Video Playback

The 4.02-inch IPS HD touch screen supports 1080P video playback. Compatible video formats include AVI, MKV, RMVB, MP4, MPG, MOV, RM, and FLY.

- **Playing Videos:** Open a video player app, navigate to your video files, and select one to play.

Puissant lecteur de musique local

Prise en charge des formats MP3, WAV, APE, FLAC, AAC, OGG, WMA

⇒ lecture séquentielle

① cycle unique (musique)

⌂ Boucle de liste

∞ lecture aléatoire



Vous pouvez sélectionner des modes de lecture tels que Album, Dossier, Artiste, etc.




L'égaliseur vous permet de profiter d'une musique plus parfaite

1080P HD Touch Screen Player: Supports video formats including AVI, MKV, RMVB, MP4, MPG, MOV, RM, FLY. Features a 4.02-inch screen, 640x1136 resolution, 2GB RAM, and an MTK 8-core processor.

5.3 App Management

The device comes with the Google Play Store pre-installed, allowing you to download and install a wide range of applications. You can also uninstall apps as needed.



Puissant processeur MTK à 8 coeurs

Android 9.0 améliore considérablement la vitesse de réponse du lecteur, il fonctionne plus rapidement et de manière plus fluide.

RAM
2GB

ROM
16GB

Micro SD
128GB

30% ↑
vitesse de course

Pre-installed Google App Store: Install and uninstall applications as needed to suit your preferences.

5.4 Parental Control

Parents can manage app installations, removals, and activate parental controls through Google Family Link in the device settings. This allows for setting passwords, browser access, app access, and other restrictions.



Parental Control Setup: Screenshot showing options for setting up parental controls via Google's Family Link.

5.5 FM Radio

The device includes an FM Radio feature. To use it, connect the earphones (which act as an antenna) and open the FM Radio application.

6. CHARGING AND BATTERY

The AHENOD G16 is equipped with a 2000mAh Li-ion battery. A full charge provides approximately 25 hours of music playback or 5 hours of video playback. Use the provided USB Type-C cable for charging.



**WiFi double bande
et Bluetooth 2 voies 4.1**

L'appareil peut être compatible en amont ou en aval avec d'autres versions d'appareils Bluetooth, tels que des écouteurs, des haut-parleurs ou des autoradios.



Integrated 2000mAh Battery: Low power consumption design provides up to 25 hours of continuous music playback or 5 hours of video playback.

7. STORAGE

The player comes with 16GB of internal ROM and a 128GB Micro SD card, totaling 144GB of storage. The storage can be expanded further using a Micro SD card up to 512GB.



Expandable Storage up to 512GB: The device includes 2GB RAM, 16GB ROM, and a 128GB SD card, supporting expansion up to 512GB.

8. MAINTENANCE

- Keep the device dry. Avoid exposure to moisture or liquids.
- Clean the screen and body with a soft, dry cloth. Do not use abrasive cleaners.
- Avoid extreme temperatures. Do not expose the device to direct sunlight or very cold environments.
- Protect the screen with the provided screen protector and use the silicone case to prevent physical damage.
- Regularly back up important data to prevent loss.

9. TROUBLESHOOTING

9.1 Device Does Not Turn On

- Ensure the battery is charged. Connect the device to a charger for at least 30 minutes.
- Press and hold the Power button for 10-15 seconds to perform a forced restart.

9.2 Cannot Connect to Wi-Fi/Bluetooth

- Verify that Wi-Fi/Bluetooth is enabled in Settings.
- Ensure the network password is correct for Wi-Fi.
- Place the device closer to the Wi-Fi router or Bluetooth accessory.
- Restart the device and try connecting again.

9.3 Apps Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache and data in **Settings > Apps > [App Name] > Storage**.
- Uninstall and reinstall the app.
- Ensure the device has sufficient free storage space.

9.4 Poor Audio Quality

- Check the earphones or speaker connection.
- Ensure the audio file is not corrupted.
- Adjust equalizer settings if available in the music player.

10. SPECIFICATIONS

Feature	Detail
Model Number	G16
Operating System	Android 9

Processor	MTK 8-core
Display	4.02-inch IPS HD Touch Screen
Memory (RAM)	2GB
Internal Storage (ROM)	16GB
Expandable Storage	Up to 512GB via Micro SD card (128GB included)
Connectivity	Wi-Fi (2.4G & 5G), Bluetooth 4.1
Battery	2000mAh Lithium-ion
Battery Life (Music)	Up to 25 hours
Battery Life (Video)	Up to 5 hours
Supported Audio Formats	MP3, WAV, APE, FLAC, AAC, OGG, WMA
Supported Video Formats	AVI, MKV, RMVB, MP4, MPG, MOV, RM, FLY
Dimensions (L x W x H)	10 x 5.8 x 1.1 cm
Special Features	FM Radio, Parental Control

11. WARRANTY AND SUPPORT

11.1 Warranty Information

This AHENOD G16 MP3 Player comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

Please retain your proof of purchase for warranty claims.

11.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact AHENOD customer support through the retailer where you purchased the product or visit the official AHENOD website for contact information.

Please have your model number (G16) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question