Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Glymnis BT-SK02

Glymnis Pop Up Beach Tent Instruction Manual

Model: BT-SK02

Introduction

This manual provides comprehensive instructions for the safe and effective use, setup, maintenance, and storage of your Glymnis Pop Up Beach Tent. Please read all instructions carefully before initial use.



Image: The Glymnis Pop Up Beach Tent in blue, shown with its included accessories: tent pegs, guy ropes, and a circular carrying bag.

Safety Information

- **UV Protection:** The tent features 190T silver coated polyester providing UPF 50+ protection, blocking over 98% of UV rays. While offering significant protection, prolonged exposure to direct sunlight should still be limited.
- **Wind Stability:** Always use the provided guy ropes and tent pegs to secure the tent, especially in windy conditions. Fill the integrated sandbags for additional stability on sandy surfaces.
- **Ventilation:** Ensure adequate airflow by utilizing the mesh window to prevent overheating inside the tent.
- **Fire Safety:** Keep the tent away from open flames and heat sources. The fabric is not fireproof.
- **Not for Extreme Weather:** This tent is designed for sun shade and light weather conditions. Do not use in heavy rain, strong winds, or thunderstorms.



Image: The beach tent with arrows indicating UV rays being blocked by the UPF 50+ silver coated polyester fabric.

Package Contents

Your Glymnis Pop Up Beach Tent package should include the following items:

- 1 x Glymnis Pop Up Beach Tent
- 4 x Guy Ropes
- 10 x Tent Pegs
- 1 x Storage Bag

Setup Instructions

The Glymnis Pop Up Beach Tent is designed for quick and easy setup:

1. **Unpack:** Remove the tent from its storage bag. It will automatically spring open.
2. **Position:** Place the tent in your desired location, ensuring the extended floor is laid out flat.
3. **Secure (Optional but Recommended):**
    - **Sandbags:** Fill the integrated pockets on the corners with sand for added stability on beaches.
    - **Tent Pegs:** Use the provided tent pegs to secure the tent to the ground through the loops at the base, especially on grass or soft earth.
    - **Guy Ropes:** Attach the guy ropes to the designated points on the tent and stake them into the ground at an angle to provide extra wind resistance.



Image: A man demonstrating the quick pop-up feature of the beach tent, showing it unfolding from its compact disc shape.



Image: Close-ups illustrating the wind-proof design, including guy rope attachment points, zippered door, sandbags, and tent pegs.

Operating the Tent

Ventilation

The Glymnis Pop Up Beach Tent features a large mesh window for optimal ventilation. This allows for air circulation, keeping the interior cool and comfortable while providing a view of your surroundings.



Image: The beach tent showing arrows indicating airflow through the large mesh window, highlighting good ventilation.

Privacy

The tent includes a zippered door that can be fully closed to provide complete privacy. This feature is ideal for changing clothes or for moments when you desire seclusion.



Image: The beach tent with its front door fully zipped closed, demonstrating the privacy feature.

Maintenance

- **Cleaning:** After each use, especially at the beach, shake off any sand or debris. Wipe down the tent with a damp cloth and mild soap if necessary. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Always ensure the tent is completely dry before folding and storing it to prevent mold and mildew growth. Air dry in a shaded, well-ventilated area.
- **Storage:** Store the tent in its original carrying bag in a cool, dry place away from direct sunlight and extreme temperatures.

Folding and Storage

Folding the pop-up tent requires a specific technique to return it to its compact disc shape. Practice these steps to master the process:

1. **Step 1: Close the Tent:** Bring the two sides of the tent together, folding it flat from the top.
2. **Step 2: Bend the Top:** Step on one side of the tent's base and gently bend the top of the tent down towards the ground.
3. **Step 3: Align the Top:** Align the top section of the tent with the brand logo, ensuring it forms a loop.
4. **Step 4: Form an '8' Shape:** Hold the upper and lower sides of the tent and twist it to form a figure-eight shape. The tent's frame will naturally want to coil.
5. **Step 5: Collapse into a Circle:** Continue to collapse the figure-eight until it forms a compact circle.
6. **Step 6: Store:** Place the folded tent into the provided storage bag.



Image: A six-step visual guide demonstrating the process of folding the pop-up beach tent back into its circular storage shape.

Troubleshooting

- **Difficulty Folding:** If you find it hard to fold the tent, ensure you are following the figure-eight twisting motion correctly. The frame is designed to coil, so a gentle but firm twist is needed. Do not force it. Refer to the folding instructions and practice.
- **Tent Instability in Wind:** Ensure all tent pegs are securely driven into the ground and guy ropes are properly tensioned. For sandy conditions, fully fill the integrated sandbags.
- **Condensation Inside:** This can occur due to temperature differences. Ensure the mesh window is open for maximum ventilation to reduce condensation.

Specifications

Feature	Detail
Brand	Glymnis
Model Name	Beach Tent
Model Number	BT-SK02
Style	S (1-2 Persons)
Open Size (S)	72.83 x 55.12 x 45.28 inches (185 x 140 x 115 cm)
Material	190T Silver Coated Polyester
Frame Material	Fiberglass
UV Protection	UPF 50+ (blocks more than 98% of UV rays)
Water Resistance Level	Waterproof
Item Weight	1.15 Kilograms
Number of Guy Ropes	4
Assembly Required	No (Pop-up design)



Image: The beach tent on a sandy beach with two children inside, illustrating its size and dimensions for 1-2 persons.

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the seller's policies on the platform where the product was purchased. Glymnis also offers optional protection plans for extended coverage:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect: One plan covers all eligible past and future purchases (monthly billing)

For further assistance, please visit the official Glymnis store or contact customer service through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4MV7RDG

More documents and user manuals: **https://manuals.plus/**