

Reebok BS7860

Reebok F/s Hi Cb Womens Shoes Size-7
USER MANUAL

1. Product Overview

The Reebok F/s Hi Cb Womens Shoes are designed with a high-top silhouette, inspired by the classic '80s Freestyle series. These shoes feature a plush, ribbed collar for enhanced ankle comfort and a signature strap for a secure fit. They are suitable for everyday wear, offering both style and comfort.



Image: Side view of the Reebok F/s Hi Cb Womens Shoes, showcasing the high-top design and strap.

2. Key Features

- **EVA Midsole:** Provides lightweight cushioning and shock absorption for comfortable wear.

- **High-Top Design:** Offers ankle support and a distinctive retro aesthetic.
- **Puffy Ribbed Collar:** Ensures plush comfort around the ankle area.
- **Signature Strap:** Enhances fit and adds to the classic Freestyle look.
- **Leather Outer Material:** Durable and stylish construction.
- **Lace-Up Closure:** Allows for adjustable and secure fitting.

3. Specifications

Attribute	Detail
Item Model Number	BS7860
Department	Womens
Sole Material	Rubber
Outer Material	Leather
Closure Type	Lace-Up
Water Resistance Level	Not Water Resistant
First Available Date	April 12, 2025

4. Setup and First Use

1. **Unboxing:** Carefully remove the shoes from their packaging. Inspect them for any visible damage or defects.
2. **Lacing:** Ensure the laces are properly threaded through all eyelets. Adjust the lacing tension to achieve a comfortable and secure fit across your foot.
3. **Ankle Strap:** Fasten the ankle strap securely around your ankle. The strap should be snug but not overly tight, allowing for comfortable movement.
4. **Initial Fit Check:** Walk around in the shoes for a few minutes to ensure they feel comfortable and provide adequate support. Your toes should have a small amount of space at the front, and your heel should not slip excessively.



Image: Side view of the shoe, highlighting the ankle strap and lacing system.

5. Wearing and Use

These Reebok F/s Hi Cb Womens Shoes are designed for casual wear and light activities. To ensure longevity and comfort:

- **Proper Fit:** Always ensure the shoes are properly laced and the ankle strap is fastened before wearing to prevent discomfort or injury.
- **Intended Use:** These shoes are not designed for rigorous athletic activities or extreme weather conditions, especially given their 'Not Water Resistant' rating.
- **Rotation:** If possible, rotate your footwear to allow shoes to air out and recover, which can extend their lifespan.

6. Care and Maintenance

Proper care will help maintain the appearance and extend the life of your Reebok F/s Hi Cb Womens Shoes:

- **Cleaning Leather:** For the leather outer material, wipe clean with a damp cloth. For tougher spots, use a specialized leather cleaner according to its instructions. Avoid harsh chemicals or abrasive materials.
- **Cleaning Soles:** The rubber sole can be cleaned with a brush and mild soap and water.
- **Drying:** If shoes get wet, allow them to air dry naturally at room temperature. Do not use direct heat sources like radiators or hair dryers, as this can damage the leather and adhesives.
- **Storage:** Store shoes in a cool, dry place away from direct sunlight. Using shoe trees can help maintain their shape.







Image: Back view of the shoe, showing the padded collar and heel structure.

7. Troubleshooting

Here are some common issues and their potential solutions:

- **Squeaking Noise:** If the shoes squeak, it might be due to moisture trapped between the insole and the sole. Remove the insole, clean and dry both surfaces, then reinsert.
- **Discomfort/Rubbing:** Ensure the shoes are the correct size and fit. Adjust lacing and strap tension. Consider wearing appropriate socks. If discomfort persists, consult a footwear specialist.
- **Odor:** Allow shoes to air out after each use. Use shoe deodorizers or sprinkle baking soda inside the shoes overnight to absorb odors.
- **Stains on Leather:** Address stains promptly. For minor stains, a damp cloth may suffice. For more stubborn stains, use a leather cleaner specifically designed for the material.

8. Warranty and Support

For information regarding warranty coverage, product support, or to address any concerns not covered in this manual, please contact Reebok customer service through their official website or the retailer from whom the product was purchased. Please have your model number (BS7860) and purchase details ready when contacting support.

© 2025 Reebok. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F4NG94GM>

More documents and user manuals: <https://manuals.plus/>