

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WISHOLY](#) /

› [WISHOLY X10 Smart Projector User Manual](#)

## WISHOLY X10

# WISHOLY X10 Smart Projector User Manual

Model: X10

## 1. INTRODUCTION

---

Thank you for purchasing the WISHOLY X10 Smart Projector. This compact and versatile projector is designed to provide an immersive viewing experience with its advanced features, including built-in Android TV, 1080P Full HD resolution with 4K support, 270° rotation, Wi-Fi, Bluetooth 5.4, and automatic keystone correction. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device to ensure optimal performance.



Image 1.1: WISHOLY X10 Smart Projector with streaming applications.

## 2. SAFETY INFORMATION

---

Please read all safety instructions carefully before using the projector. Keep this manual for future reference.

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Do not expose the projector to rain, moisture, or extreme temperatures.
- Use only the power adapter provided with the device.
- Keep the projector away from water and other liquids.
- Do not attempt to disassemble or repair the projector yourself. Contact customer support for assistance.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the package. If any items are missing or damaged, please contact customer support.

- WISHOLY X10 Smart Projector
- Remote Control
- Power Adapter
- HDMI Cable
- User Manual
- Screwdriver (Note: Earlier versions of the manual incorrectly listed an Allen wrench. The correct accessory is a screwdriver.)

## 4. PRODUCT OVERVIEW

Familiarize yourself with the projector's components and ports.



Image 4.1: Projector ports and connections.

- **Lens:** Projects the image onto the screen or surface.
- **Power Button:** Turns the projector on/off.
- **Focus Wheel:** Manual focus adjustment.
- **HDMI Port:** Connects to external devices like laptops, game consoles, or TV boxes.
- **USB Port:** Connects to USB storage devices for media playback.
- **3.5mm Audio Jack:** Connects to external speakers or headphones.
- **DC IN Port:** Connects to the power adapter.
- **270° Rotating Stand:** Allows flexible projection angles, including ceiling projection.

## 5. SETUP

Follow these steps to set up your WISHOLY X10 Smart Projector.

1. **Power Connection:** Connect the power adapter to the DC IN port on the projector and then plug it into a power outlet.
2. **Placement:** Place the projector on a stable, flat surface. The 270° rotating stand allows for flexible placement on tables, floors, or even for ceiling projection.



Image 5.1: Flexible projection angles with the 270° rotating stand.

3. **Power On:** Press the power button on the projector or the remote control to turn on the device.
4. **Initial Setup:** Follow the on-screen instructions to complete the initial Android TV setup, including language selection and Wi-Fi network connection.
5. **Automatic Keystone Correction:** The projector features automatic keystone correction, which will adjust the image shape automatically. Manual adjustment is generally not required.
6. **Focus Adjustment:** Use the manual focus wheel on the projector to achieve a clear image.
7. **Zoom Function:** Adjust the projection size from 50% to 100% using the remote control or on-screen settings.



Image 5.2: High-resolution projection quality.

## 6. OPERATING INSTRUCTIONS

### 6.1 Android TV Features

The WISHOLY X10 comes with Android TV built-in, allowing direct access to a wide range of streaming applications.

- **App Installation:** Download popular apps like Netflix, YouTube, Prime Video, and Hulu directly from the Google Play Store.
- **Content Streaming:** Enjoy movies, TV shows, and videos on a large screen without needing to connect external devices like smartphones or PCs.

# Android TV 搭載・10000+アプリ付き

スマホ不要！ Android tv内蔵で、好きなアプリをインストールできます



Image 6.1: Android TV interface with available applications.

## 6.2 Connectivity

The projector offers various connectivity options for seamless integration with your devices.

- **Wi-Fi:** Connect to your home Wi-Fi network for internet access and screen mirroring from iOS, Android, and Windows devices. The latest Wi-Fi standards ensure high-speed, low-latency connections for smooth online gaming and video streaming.

# Bluetooth5.4・より高速な通信

より安定した接続、より広い無線通信範囲、より速い通信速度！

# 5.4



## Bluetooth5.2

電量消費が早い音割り、  
遅延あり

## Bluetooth5.4

+30%  
通信速度

+20%  
通信距離

+18%  
省電力性

Image 6.2: High-speed Wi-Fi for gaming and streaming.

- **Bluetooth 5.4:** Connect wireless headphones or external speakers for enhanced audio. Bluetooth 5.4 provides improved transmission speed and connection stability, ensuring perfect audio-video synchronization.



Image 6.3: Bluetooth 5.4 connectivity with audio devices.

- **HDMI:** Use the HDMI port to connect devices such as laptops, PCs, game consoles (e.g., Switch, PS), TV boxes, and DVD players.
- **USB:** Plug in USB storage devices to play media files directly.
- **3.5mm Audio:** Connect wired headphones or external speakers.

**Note:**

- This projector is not compatible with Google Pixel devices for screen mirroring.
- Some Android devices (e.g., AQUOS) may not have screen mirroring functionality, preventing connection to the projector. Please check your smartphone's specifications.
- Due to version compatibility, certain apps like KiT Player and TELASA may not be downloadable from the Google Play Store. For these, consider purchasing an Amazon Fire TV Stick separately.

### 6.3 Projection Adjustments

- **Automatic Keystone Correction:** The projector automatically corrects image distortion (trapezoidal effect) when placed at an angle. This eliminates the need for manual adjustments.
- **Manual Focus:** Rotate the focus wheel on the projector to sharpen the image.
- **Digital Zoom (50%-100%):** Adjust the projection size without moving the projector using the remote control or

settings menu.

- **270° Rotation:** The integrated stand allows you to rotate the projector up to 270 degrees, enabling projection onto walls, ceilings, or any desired surface.



Image 6.4: Automatic keystone correction and zoom function.

## 7. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your projector.

- **Lens Cleaning:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive cleaners or harsh chemicals.
- **Dust Removal:** Regularly clean the projector's exterior with a soft, dry cloth. Use a can of compressed air to gently clear dust from ventilation openings.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Fan Noise:** The projector is designed for quiet operation. If you notice unusual fan noise, ensure ventilation is not obstructed.



Image 7.1: Quiet operation for undisturbed viewing.

## 8. TROUBLESHOOTING

If you encounter issues with your projector, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No image or blurry image	Loose cable connection, incorrect input source, out of focus	Check HDMI/USB connections. Select correct input source. Adjust focus wheel.
No sound	Volume too low, incorrect audio output, external speaker not connected	Increase volume. Check audio settings. Ensure Bluetooth speaker is paired or wired speaker is connected.
Remote control not working	Dead batteries, obstruction, out of range	Replace batteries. Remove obstructions. Ensure remote is pointed at the projector.
Wi-Fi connection issues	Incorrect password, weak signal, router issues	Verify Wi-Fi password. Move projector closer to router. Restart router.
Screen mirroring not working	Device incompatibility, network issues	Check device compatibility (Google Pixel and some AQUOS models are not supported). Ensure both devices are on the same Wi-Fi network.

If the problem persists after trying these solutions, please contact WISHOLY customer support.

## 9. SPECIFICATIONS

Detailed technical specifications for the WISHOLY X10 Smart Projector.

Feature	Specification
Brand	WISHOLY
Model Number	X10
Brightness	21000 Lumens
Native Resolution	1920 x 1080 (1080P Full HD)

Feature	Specification
Supported Resolution	Up to 4K
Contrast Ratio	12000:1
Operating System	Android TV
Connectivity	Wi-Fi, Bluetooth 5.4, HDMI, USB, 3.5mm Audio
Keystone Correction	Automatic
Projection Size	Up to 200 inches
Zoom Function	50% - 100%
Rotation Angle	270°
Built-in Speaker	Yes (HiFi)
Dimensions	25.4 x 18.6 x 14.7 cm
Weight	1.1 kg

## 10. WARRANTY AND SUPPORT

---

WISHOLY is committed to providing high-quality products and excellent customer service.

- **Warranty:** The WISHOLY X10 Smart Projector comes with a 2-year warranty. An extended warranty option may be available. Please refer to the product registration information for details.
- **Customer Support:** Our professional support team is available year-round to assist you with any questions regarding setup, operation, or troubleshooting. Please contact our support center for assistance.