

## Motorola Moto G 2025

# Motorola Moto G 2025 User Manual

Comprehensive guide for your smartphone

## INTRODUCTION

---

Welcome to the user manual for your new Motorola Moto G 2025 smartphone. This guide will help you understand the features and functions of your device, ensuring you get the most out of your mobile experience. Please read this manual carefully before using your phone.

## 1. DEVICE SETUP

---

### 1.1 Unboxing and Initial Charge

Carefully remove all items from the packaging. Before first use, fully charge your Moto G 2025 using the provided USB-C cable and power adapter. Connect the cable to the phone's charging port and the adapter to a power outlet.

### 1.2 Inserting SIM and microSD Cards

1. Locate the SIM tray on the side of your phone.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the tray with the gold contacts facing down. Ensure they are correctly seated.
4. Carefully push the tray back into the phone until it clicks into place.

### 1.3 Powering On and Initial Configuration

Press and hold the Power button until the Motorola logo appears. Follow the on-screen prompts to select your language, connect to Wi-Fi, sign in with your Google account, and set up security features like fingerprint unlock or face recognition.

## 2. OPERATING YOUR DEVICE

---

### 2.1 Navigating the Android 14 Interface

Your Moto G 2025 runs on Android 14. Use gestures to navigate: swipe up from the bottom for the app

drawer, swipe down from the top for notifications and quick settings, and swipe from the left or right edge to go back.

## 2.2 Making Calls and Managing Contacts

Tap the **Phone** icon to make calls. Enter a number or select a contact. To add a new contact, open the **Contacts** app and tap the + icon. Fill in the contact details and save.

## 2.3 Camera Functions

Open the **Camera** app to capture photos and videos. Tap the shutter button to take a picture. Swipe left or right to switch between modes like **Photo**, **Video**, **Portrait**, and **Night Vision**. Tap on the screen to focus, and pinch to zoom.

## 2.4 Connecting to Networks and Devices

- **Wi-Fi:** Go to **Settings > Network & internet > Internet**. Select a network and enter the password if required.
- **Bluetooth:** Go to **Settings > Connected devices > Connection preferences > Bluetooth**. Toggle Bluetooth on and pair with available devices.
- **Mobile Data:** Ensure your SIM card is active. Go to **Settings > Network & internet > SIMs** and enable mobile data for your preferred SIM.

## 2.5 Security and Privacy

Protect your device with screen lock options (PIN, pattern, password), fingerprint unlock, or face recognition. Access these settings via **Settings > Security & privacy**. Use **Find My Device** to locate, lock, or erase your phone remotely if it's lost or stolen.

# 3. MAINTENANCE

---

## 3.1 Software Updates

Keep your phone's software up to date for optimal performance and security. Go to **Settings > System > System updates** to check for and install available updates.

## 3.2 Battery Care

To prolong battery life, avoid extreme temperatures, use the original charger, and consider enabling **Adaptive Battery** in **Settings > Battery**.

## 3.3 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid harsh chemicals or abrasive materials. For stubborn smudges, slightly dampen the cloth with water.

# 4. TROUBLESHOOTING

---

## 4.1 Common Issues and Solutions

Issue	Solution
Phone not turning on	Ensure the battery is charged. Press and hold the Power button for 10-15 seconds to force a restart.

Issue	Solution
Apps crashing or freezing	Clear the app's cache ( <b>Settings &gt; Apps &gt; [App Name] &gt; Storage &amp; cache &gt; Clear cache</b> ). Restart the phone.
Poor Wi-Fi connection	Restart your router and phone. Forget and reconnect to the Wi-Fi network ( <b>Settings &gt; Network &amp; internet &gt; Internet</b> ).
Battery draining quickly	Check battery usage in <b>Settings &gt; Battery</b> to identify power-hungry apps. Reduce screen brightness.

## 4.2 Factory Reset

If issues persist, you may need to perform a factory reset. **Warning:** This will erase all data on your phone. Back up important data before proceeding. Go to **Settings > System > Reset options > Erase all data (factory reset)**.

## 5. SPECIFICATIONS

---

The following are general specifications for the Moto G 2025. For precise details, please refer to the official Motorola product page or your device's packaging.

- **Model:** Moto G 2025
- **Operating System:** Android 14
- **Display:** Screen size and type
- **Processor:** CPU model and core count
- **RAM:** Installed memory
- **Internal Storage:** Storage capacity, expandable options
- **Rear Camera:** Megapixels and lens configuration
- **Front Camera:** Megapixels
- **Battery:** Capacity in mAh
- **Connectivity:** Cellular bands, Wi-Fi standards, Bluetooth version, GPS, USB type
- **Sensors:** List of integrated sensors (e.g., fingerprint, accelerometer)
- **Dimensions:** Height, width, depth
- **Weight:** Device weight

## 6. WARRANTY AND SUPPORT

---

### 6.1 Limited Warranty

Your Motorola Moto G 2025 comes with a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Motorola website for detailed terms and conditions. This warranty typically covers defects in materials and workmanship under normal use.

### 6.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Motorola customer support. You can find contact information, FAQs, and support resources on the official Motorola support website: [www.motorola.com/support](http://www.motorola.com/support).

