

## Seemagic SMPH-ZJD06C

# Seemagic Pro 2.0 Electric Nail Trimmer User Manual

Model: SMPH-ZJD06C

## 1. INTRODUCTION

Thank you for choosing the Seemagic Pro 2.0 Electric Nail Trimmer. This innovative 2-in-1 automatic fingernail trimmer is designed for safe and efficient nail care for individuals of all ages, including kids, teenagers, and adults. Featuring advanced safety mechanisms like D-Eyes infrared safety technology and SkinGuard instant-stop tech, it ensures a precise and worry-free trimming experience. Its quiet operation and integrated nail dust catcher make it convenient for use anytime, anywhere.

This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your device to ensure optimal performance and longevity.

## 2. SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using the device to prevent injury or damage.

- **Sharp Blade:** Keep children away unless supervised by an adult.
- **Secure Storage:** Store out of children's reach to prevent accidents.
- **Avoid Contact with Blade:** Only fingernails should touch the blade during operation.
- **Foreign Object Warning:** Never place non-nail items near the blade while the device is running, as this may damage the blade or cause malfunction.
- **Power On/Off:** Press and hold the power button for 2 seconds to power on or off the device.
- **Not Washable:** This device is not waterproof and cannot be washed. Do not immerse in water or rinse under a tap.
- **Age Recommendation:** Suitable for kids 1 year and older.
- **Nail Type:** Best for regular nails. Not suitable for thicker or hard nails, or toenails. If you have thick nails, try soaking them in warm water first.



**Others**  
Be careful, be afraid

## HIGHLY SAFE FOR YOUR PEACE OF MIND



*Image: Foolproof Safety Master features, including SkinGuard Instant-Stop Tech and LED-Guided Precision Cutting.*

### 3. PRODUCT FEATURES

- **Official 2nd Gen Pro Upgrade:** Features D-Eyes infrared safety tech and triple protection (auto-stop, touch control, 2-min shutdown).
- **Foolproof Safety Master:** Patented "SkinGuard" technology stops blades instantly upon skin contact. Embedded cutter head and LED light prevent over-trimming.
- **Ergonomic Smart Control:** Curved blade design for perfect nail shape fit, intuitive touch control, and 2-second hold to start.
- **2-in-1 Trim & Polish:** Professional-grade alloy blades cut and grind nails seamlessly, leaving smooth edges without extra filing.
- **Zero-Mess Grooming:** Built-in nail dust catcher collects clippings, with a cleaning brush included.
- **Whisper-Quiet Operation:** Operates at 40dB, suitable for use during naps or at night.
- **Long Battery Life & Fast Charge:** Upgraded 1500mAh battery provides 60+ uses per charge, with Type-C fast charging.
- **Dual Speed Modes:** Includes a kids-safe speed mode and a turbo adult setting.

# QUIET DESIGN & SOFT LIGHT



*Image: Quiet Design & Soft Light features, illustrating 40dB low noise and LED auxiliary light.*

## 2-IN-1 TRIM & POLISH



Alloy Blades  
+ 17-Step Polish



Salon Finish  
at Home



Zero-Filing  
Edges




Image: 2-in-1 Trim & Polish capability, showing smooth nail results.

### 4. SETUP

- 1. Unpack:** Carefully remove the nail trimmer and all accessories from the packaging.
- 2. Charge:** Before first use, fully charge the device using the provided Type-C cable. Connect the Type-C end to the trimmer's charging port and the USB-A end to a compatible USB power adapter (not included). The indicator light will show charging status.
- 3. Familiarize:** Identify the power button, touch key, indicator light, auxiliary lighting, and nail debris storage box.



*Image: Product packaging and included accessories, including the Type-C charging cable.*



## SMALL AND LIGHTWEIGHT

- Trimming Nails Anytime & Anywhere
- Compact Travel Ready



*Image: Ergonomic Product Details, showing various parts of the trimmer.*

## 5. OPERATING INSTRUCTIONS

1. **Power On:** Open the top cover. Press and hold the power button on the side for 2 seconds to turn on the device. The indicator light will illuminate.
2. **Select Speed:** Press the power button again to switch between speed modes (Speed 1 for kids/gentle, Speed 2 for adults/turbo).
3. **Position Finger:** Place your fingernail near the cutter head. The device features D-Eyes infrared safety tech and SkinGuard, which will activate the blade upon proper contact and stop if skin is detected.
4. **Trim Nails:** Slowly move your fingernail along the cutter head to trim and polish. The curved blade is designed to hug your nail shape. The LED auxiliary light will help you see clearly.
5. **Repeat:** Continue for all fingernails.
6. **Power Off:** After use, press and hold the power button for 2 seconds to turn off the device. The device will also auto-shutdown after 2 minutes of inactivity.

**Seemagic****2-IN-1** TRIM & POLISH **Not Washable** **Press and Hold (2s) to Power On or Off**

## INFRARED PROTECTION

**Automatic Nail Clippers**

2-Speed Modes



LED Light Design



40dB Low Noise



Nail Scraps Storage



Safety Mechanism

*Image: How to Use the Seemagic Electric Nail Clipper.*

## 6. MAINTENANCE

- Empty Nail Debris Storage Box:** After trimming, press the half of the lid to open the storage box and discard the collected nail clippings. Use the provided cleaning brush to completely rid the unit of shavings. Do not attempt to open the entire lid.
- Cleaning:** The device is not washable. Do not use water or liquid cleaners. Use the provided small cleaning brush to remove any remaining debris from the cutter head and surrounding areas. Wipe the exterior with a dry, soft cloth.
- Storage:** Store the device in a cool, dry place, away from direct sunlight and moisture. Ensure it is out of reach of children.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is low or depleted. Power button not pressed correctly.	Charge the device fully using the Type-C cable. Press and hold the power button for 2 seconds.
Blade does not operate when finger is inserted.	Sensors are covered by something other than the nail. Device is not properly positioned. Nail is too thick or hard.	Ensure only the fingernail is touching the blade area and not covering the infrared sensors. Reposition your finger. This device is best for regular nails. For thicker nails, try soaking them in warm water first. It is not suitable for toenails.
Nails have ragged edges after trimming.	Nail not moved slowly enough. Nail type not suitable for the trimmer.	Move your fingernail slowly and steadily along the cutter head. This trimmer is designed for regular fingernails. For very thick or hard nails, results may vary.
Nail clippings are not collected.	Storage box is full or improperly closed.	Empty the nail debris storage box. Ensure it is properly closed after emptying.

## 8. SPECIFICATIONS

**Product Name:** Electric Nail Clipper

**Model Name:** Electric Nail Clipper

**Item Model Number:** SMPH-ZJD06C

**Brand:** Seemagic

**Color:** Pearl White

**Material:** Plastic+Alloy

**Product Dimensions (L x W x H):** 2.73 x 2.73 x 1.28 inches

**Product Weight:** 85g (4.66 ounces)

**Batteries:** 1 Lithium Ion battery required (included)

**Battery Capacity:** 1500mAh

**Rated Input:** 5V ⇒ 0.2A

**Rated Power:** 1W

**Charging Interface:** Type-C

**Noise Level:** 40dB (Whisper-Quiet)



*Image: Product Details and Specifications.*

## 9. WARRANTY AND SUPPORT

Seemagic stands behind the quality of its products. Your Pro 2.0 Electric Nail Trimmer comes with the following:

- 30-Day Trial:** Experience the product risk-free.
- 1-Year Replacement Time:** Enjoy a 365-day replacement policy for any manufacturing defects.

For any questions, concerns, or support needs, please refer to the official Seemagic website or contact their customer service directly. Please retain your proof of purchase for warranty claims.

## 90-Day Battery + Fast Charge

-  1500mAh Marathon Power
-  Type-C Quick Recharge
-  Baby/Turbo Dual Modes



The product does not include a power adapter.

## PRODUCT DETAILS



69.5mm

69.5mm



32.7mm



Product Name: Electric Nail Clipper

Product Size: 69.5mm\*69.5mm\*32.7mm

Rated Input: 5V == 0.2A

Charging Interface: Type-C

Product Mode: SMPH-ZJD06C

Product Weight: 85g

Rated Power: 1W

*Image: Trust & Assurance, highlighting product certifications and warranty.*

© 2025 Seemagic. All rights reserved.

For more information, visit [Seemagic Store](#)