Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KOPIDOE X8

KOPIDOE X8 IP68 Waterproof Bone Conduction Headphones User Manual

Model: X8 | Brand: KOPIDOE

1. Important Safety Information

- Do not attempt to disassemble or modify the device.
- Keep the headphones away from extreme temperatures and direct sunlight.
- Ensure the charging port is dry before charging to prevent damage.
- Avoid listening at high volumes for extended periods to prevent hearing damage.
- When swimming, switch to MP3 mode as Bluetooth signals do not transmit effectively underwater.

2. Product Overview

The KOPIDOE X8 headphones are designed for active lifestyles, featuring bone conduction technology, IP68 waterproofing, and a built-in 32GB MP3 player. They offer an open-ear design for situational awareness and Bluetooth 5.4 connectivity for stable wireless audio.



Image: KOPIDOE X8 headphones in use by a swimmer, demonstrating their IP68 waterproof capability for underwater activities.




Image: An overview of the KOPIDOE X8 headphones' main features, including battery life, Bluetooth version, waterproof rating, charging method, storage capacity, weight, and open-ear design.

Your browser does not support the video tag.

Video: An official product video from KOPIDOE demonstrating the IP68 waterproof rating and bone conduction technology of the swimming headphones.

3. Package Contents

- KOPIDOE X8 Bone Conduction Headphones
- Magnetic Charging Cable
- User Manual
- Earplugs (for swimming)

4. Controls and Functions

The KOPIDOE X8 headphones feature intuitive controls for easy operation.



Image: A detailed diagram illustrating the function of each button on the KOPIDOE X8 headphones.

- **Power Button (Multi-function Button):**
  - Long press 3 seconds: Power On/Off, Reject Calls.
  - Click once: Play/Pause music, Answer/Hang Up Calls.
  - Click twice: Switch between Bluetooth and MP3 modes.
  - Click 3 times: Activate voice assistant (e.g., Siri on iPhone).
- **Volume Down Button (-):**
  - Click once: Decrease volume.
  - Long press: Previous song.
- **Volume Up Button (+):**
  - Click once: Increase volume.
  - Long press: Next song.

5. Setup

5.1 Charging the Headphones

Before first use, fully charge the headphones. Use the provided magnetic charging cable.

1. Connect the magnetic end of the charging cable to the charging port on the headphones.
2. Connect the USB end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge takes approximately 2 hours.



Image: The KOPIDOE X8 headphones with the magnetic charging cable attached to the charging port.

5.2 Power On/Off

- **To Power On:** Long press the Power button for 3 seconds until the LED indicator flashes.
- **To Power Off:** Long press the Power button for 3 seconds until the LED indicator turns off.

5.3 Bluetooth Pairing

Pair the headphones with your Bluetooth-enabled device for wireless audio.

1. Ensure the headphones are powered off.
2. Long press the Power button for 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device, enable Bluetooth and search for "KOPIDOE X8".
4. Select "KOPIDOE X8" from the list of available devices to connect.
5. Once connected, the LED indicator will flash blue slowly.



Image: A visual representation of the Bluetooth 5.4 technology integrated into the headphones, emphasizing connection stability and speed.

5.4 MP3 Mode (Internal Storage)

The headphones have 32GB of built-in memory for storing music, ideal for use where Bluetooth signals are unreliable, such as underwater.

1. **To Transfer Music:** Connect the headphones to a computer using the magnetic charging cable. The headphones will appear as a removable disk. Drag and drop your MP3 audio files into the headphone's storage.
2. **To Switch to MP3 Mode:** While the headphones are on, double-click the Power button. The headphones will announce "MP3 Mode".
3. **To Switch back to Bluetooth Mode:** Double-click the Power button again. The headphones will announce "Bluetooth Mode".



Image: A visual highlighting the 32GB internal MP3 storage, allowing users to store a large number of songs directly on the device.



Image: Demonstrates the flexibility of switching between 32GB MP3 mode for swimming and Bluetooth 5.4 mode for other activities like running.

6. Operating Instructions

6.1 Wearing the Headphones

Place the headphones with the transducers resting on your cheekbones, just in front of your ears. The band should wrap around the back of your head.



Image: A swimmer demonstrating the proper way to wear the KOPIDOE X8 headphones for optimal bone conduction audio.

6.2 Music Playback

- **Play/Pause:** Click the Power button once.
- **Next Song:** Long press the Volume Up (+) button.

- **Previous Song:** Long press the Volume Down (-) button.

6.3 Volume Control

- **Increase Volume:** Click the Volume Up (+) button once.
- **Decrease Volume:** Click the Volume Down (-) button once.

6.4 Call Management

- **Answer/End Call:** Click the Power button once during an incoming call.
- **Reject Call:** Long press the Power button for 3 seconds during an incoming call.

6.5 Voice Assistant

- **Activate Voice Assistant:** Click the Power button three times.

7. Maintenance

Proper care ensures the longevity and performance of your KOPIDOE X8 headphones.

- **Cleaning:** After use, especially after swimming or intense workouts, rinse the headphones with fresh water and wipe them dry with a soft cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Charging Port:** Always ensure the magnetic charging port is clean and dry before connecting the charging cable.
- **Liquid Silicone:** The liquid silicone coating is designed for durability and easy cleaning.



Image: Illustrates the durable and skin-friendly liquid silicone construction, highlighting its abrasion resistance and ease of cleaning.

8. Troubleshooting

If you encounter issues, refer to the following common problems and solutions.

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Long press the Power button for 3 seconds.
Cannot pair via Bluetooth.	Ensure headphones are in pairing mode (LED flashes red/blue). Check if Bluetooth is enabled on your device and try re-pairing. Move closer to your device.

Problem	Solution
No sound.	Check volume levels on both headphones and your device. Ensure headphones are connected via Bluetooth or in MP3 mode.
Poor sound quality underwater.	Bluetooth signals do not transmit well underwater. Switch to MP3 mode for optimal audio performance while swimming. Ensure earplugs are used for best sound experience underwater.
Headphones not recognized by computer.	Ensure the magnetic charging cable is securely connected. Try a different USB port or cable.

9. Specifications

Feature	Detail
Model Number	X8
Material	Silicone
Water Resistance Level	IP68 Waterproof
Audio Driver Type	Bone Conduction Driver
Internal Storage	32GB (up to 8,000 songs)
Bluetooth Version	5.4
Bluetooth Range	Up to 10 meters
Battery Life	Up to 8 hours continuous playtime
Charging Time	Approximately 2 hours
Battery Capacity	180mAh
Control Method	Touch/Button
Earpiece Shape	Open-ear
Item Weight	6.4 ounces (approx. 24.3g)

10. Warranty and Support

KOPIDOE products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or the official KOPIDOE website. Please retain your proof of purchase for warranty claims.

© 2025 KOPIDOE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4QJRZ4K

More documents and user manuals: **https://manuals.plus/**