

[manuals.plus](#) /

› [SANSUI](#) /

› [SANSUI W28 Wireless Earbuds User Manual](#)

**SANSUI W28**

# SANSUI W28 Wireless Earbuds User Manual

Model: W28

## 1. INTRODUCTION

Thank you for choosing the SANSUI W28 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Active Noise Cancellation (ANC), crystal-clear call quality, and extended battery life. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.



Image: SANSUI W28 Wireless Earbuds and Charging Case in Dolomite White.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- SANSUI W28 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Silicone Ear Tips (S, M, L sizes)
- User Manual

## 3. PRODUCT OVERVIEW

### Earbud Components

- **Touch Control Area:** For playback, call management, and mode switching.
- **Microphones:** Multiple microphones for ANC and ENC (Environmental Noise Cancellation) during calls.
- **Light Sensor:** For advanced in-ear detection, automatically pausing/playing audio.
- **Ear Tip:** Soft silicone tips for comfort and secure fit.

## Advance In-Ear Detection

Feature a state-of-the-art Light Sensor strategically placed on the ear-facing side. This innovative sensor intuitively perceives the earbuds' wearing state with remarkable precision. It instantaneously triggers automatic play or pause functions.



Image: SANSUI W28 Earbuds highlighting the advanced in-ear detection sensor.

### Charging Case

- **Charging Port:** USB-C port for charging the case.
- **Indicator Light:** Displays charging status and battery level.
- **Reset Button:** Located inside the case, used for factory reset.

# 28Hrs Paytime

Up to 28 hours of playtime with the charging case for extended listening.



Image: SANSUI W28 Earbuds and Charging Case illustrating up to 28 hours of total playtime.

## 4. SETUP

### 4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the case and a power source. The indicator light on the case will show charging status.

### 4.2 Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by a flashing light on the case.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "SANSUI W28" in the list of available Bluetooth devices.
5. Select "SANSUI W28" to connect. Once connected, the indicator light on the case will turn off or show a steady light, depending on the model.


The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

## 5. OPERATING INSTRUCTIONS

### 5.1 Touch Controls

The SANSUI W28 earbuds feature intuitive touch controls. Refer to the diagram below for specific functions:

## key operation



One-click factory reset

Open the lid of the charging case, press and hold the button at the bottom of the charging case for 5S, wait for the white light on the outside of the charging case to flash 5 times, and the earphones will be turned off and disconnected from the Bluetooth connection to reset successfully.

**ReSet:** Open the charging case lid, then long-press the button under the charging case for 5 seconds. When the external blue indicator light on the case flashes quickly 5 times and the earbuds power off while disconnecting from Bluetooth, the reset is successful.

🕒 :Click   🕒 :Long Press    PS : ANC Off = Normal Mode

Image: Detailed guide for SANSUI W28 Earbuds touch controls and reset procedure.

- **Volume + (R):** Single tap on the Right earbud.
- **Volume - (L):** Single tap on the Left earbud.
- **Pause/Play (L/R):** Double tap on either earbud.
- **Answer Calls/Hang Up (L/R):** Double tap on either earbud.
- **Previous Song (L):** Triple tap on the Left earbud.
- **Next Song (R):** Triple tap on the Right earbud.
- **Voice Assistant (L):** Long press for 2 seconds on the Left earbud.
- **ANC ON/ANC OFF/Transparency Mode (R):** Long press for 2 seconds on the Right earbud to cycle through modes.
- **Reject Calls (L/R):** Long press for 2 seconds on either earbud.
- **Power ON (L/R):** Long press for 3 seconds on either earbud (when off).
- **Power OFF (L/R):** Long press for 5 seconds on either earbud (when on).

## 5.2 Active Noise Cancellation (ANC) & Transparency Mode

The SANSUI W28 offers three listening modes:

- **ANC Mode:** Reduces external noise by up to -52dB, ideal for noisy environments like subways or airplanes.
- **Transparency Mode:** Allows you to hear your surroundings clearly without removing the earbuds, enhancing safety during outdoor activities.
- **Normal Mode:** Standard listening mode without active noise cancellation or transparency.

Cycle through these modes by long-pressing the touch control area on the Right earbud for 2 seconds.

# Transparency Mode

Stay aware of your surroundings when needed, allowing you to hear important sounds without taking off your ear buds, making it safer for outdoor activities.



Image: A person using SANSUI W28 Earbuds in Transparency Mode, indicating awareness of surroundings.

## 5.3 In-Ear Detection

The earbuds feature smart light sensors that detect when they are in your ears. Audio playback will automatically pause when you remove an earbud and resume when you put it back in.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your SANSUI W28 earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the silicone ear tips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Water Resistance:** The earbuds are IPX4 waterproof, meaning they are resistant to splashes and sweat. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly if they get wet.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.

## 7. TROUBLESHOOTING

If you encounter any issues with your SANSUI W28 earbuds, please refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are in the charging case and the lid is open. Check if Bluetooth is enabled on your device. Try resetting the earbuds (see below).
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Disconnection issues:** Ensure the earbuds are within the Bluetooth range of your device. Avoid obstacles that might interfere with the signal.

## Factory Reset

If issues persist, a factory reset can often resolve them:

1. Open the charging case lid.
2. Locate the small button inside the charging case (refer to the 'Key Operation' image in section 5.1).
3. Long-press this button for 5 seconds.
4. The external blue indicator light on the case will flash 5 times, and the earbuds will power off while disconnecting from Bluetooth.
5. The reset is successful. You can now re-pair the earbuds with your device.

## 8. SPECIFICATIONS

Feature	Specification
Model Name	W28
Noise Control	Active Noise Cancellation (-52dB Hybrid ANC)
Connectivity Technology	Wireless (Bluetooth 5.4)
Battery Life	Up to 28 Hours (with charging case)
Water Resistance Level	IPX4 Waterproof
Control Method	Touch
Frequency Range	20-18,000 Hz
Earpiece Shape	Bud (In-Ear)
Impedance	32 Ohm
Item Weight	5.6 ounces

## 9. WARRANTY AND SUPPORT

SANSUI products are designed and manufactured to the highest quality standards. For warranty information and customer support, please refer to the warranty card included in your package or visit the official SANSUI website. If you have any questions or require assistance, please contact our customer service team.

**SANSUI Official Store:** [Visit the SANSUI Store on Amazon](#)

## Related Documents - W28

	<p><a href="#"><u>SANSUI W28 Hybrid Noise Cancelling TWS Earbuds User Manual</u></a></p> <p>User manual for SANSUI W28 TWS earbuds, detailing first use, power operations, wireless pairing, factory reset, indicator light status, additional functions, and important safety precautions.</p>
	<p><a href="#"><u>SANSUI DT11 ANC Wireless Headphones User Manual</u></a></p> <p>User manual for the SANSUI DT11 ANC Wireless Bluetooth Headphones, detailing features like - 45dB Active Noise Reduction, 50-hour playtime, and comfortable over-ear design.</p>
	<p><a href="#"><u>Sansui 50dB ANC Wireless Bluetooth 5.4 Headphones User Manual</u></a></p> <p>User manual for Sansui 50dB ANC Wireless Bluetooth 5.4 Over-Ear Headphones. Learn about features like Active Noise Cancellation, detachable microphone, Bluetooth 5.4, pairing, controls, and troubleshooting.</p>
	<p><a href="#"><u>SANSUI T19 Wireless Earbuds User Manual and Operation Guide</u></a></p> <p>Comprehensive user manual for SANSUI T19 wireless earbuds, covering setup, operation, features like spatial audio and dual connection, indicator status, troubleshooting, and precautions.</p>
	<p><a href="#"><u>SANSUI Wireless Earbuds OW03 User Manual - Features, Operation, and Specifications</u></a></p> <p>Comprehensive user manual for SANSUI OW03 wireless earbuds. Learn about first use, power management, Bluetooth pairing, music/game modes, button controls, indicator lights, and FCC compliance.</p>
	<p><a href="#"><u>Sansui AU-101 Stereo Amplifier Service Manual</u></a></p> <p>Comprehensive service manual for the Sansui AU-101 stereo amplifier, providing technical specifications, circuit analysis, troubleshooting guides, and maintenance procedures. Includes comparisons to models like the AU-555A.</p>